

OWNER'S MANUAL

125 lb. Laundry Dryer



MODELS

GAS

L125URDG
C125G

STEAM

L125URDS
C125S

ELECTRIC

L125URDE
C125E

CISELL MANUFACTURING COMPANY

HEADQUARTERS
831 SOUTH FIRST ST.
P.O. BOX 32270
LOUISVILLE, KY 40232-2270

PHONE: (502) 587-1292
SALES FAX: (502) 585-3625
SERVICE/PARTS FAX: (502) 681-1275

THIS MANUAL MUST BE GIVEN TO THE EQUIPMENT OWNER.

IMPORTANT NOTICES—PLEASE READ

For optimum efficiency and safety, we recommend that you read the Manual before operating the equipment. Store this manual in a file or binder and keep for future reference.



WARNING: For your safety, the information in this manual must be followed to minimize the risk of fire or explosion or to prevent property damage, personal injury, or loss of life.

- Do not store or use gasoline or other flammable liquids or vapors in the vicinity of this or any other appliance.

- WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliances.
- Do not touch any electrical switch; do not use any phone in your building.
- Clear the room, building, or area of all occupants.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach the gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.



WARNING: In the event the user smells gas odor, instructions on what to do must be posted in a prominent location. This information can be obtained from the local gas supplier.



WARNING: Wear Safety Shoes to prevent injuries.



WARNING: Purchaser must post the following notice in a prominent location:



FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.



WARNING: A clothes dryer produces combustible lint and should be exhausted outside the building. The dryer and the area around the dryer should be kept free of lint.



WARNING: Be safe, before servicing machine, the main power should be shut off.



WARNING: To avoid fire hazard, do not dry articles containing foam rubber or similar texture materials. Do not put into this dryer flammable items such as baby bed mattresses, throw rugs, undergarments (brassieres, etc.) and other items which use rubber as padding or backing. Rubber easily oxidizes causing excessive heat and possible fire. These items should be air dried.



WARNING: Synthetic solvent fumes from drycleaning machines create acids when drawn through the dryer. These fumes cause rusting of painted parts, pitting of bright or plated parts, and completely removes the zinc from galvanized parts, such as the tumbler basket. If drycleaning machines are in the same area as the tumbler, the tumbler's make-up air must come from a source free of solvent fumes.



WARNING: Do not operate without guards in place.



WARNING: Check the lint trap often and clean as needed but at least a minimum of once per day.



WARNING: Alterations to equipment may not be carried out without consulting with the factory and only by a qualified engineer or technician. Only **Manufacturer's** parts may be used.



WARNING: Remove clothes from dryer as soon as it stops. This keeps wrinkles from setting in and reduces the possibility of spontaneous combustion.



WARNING: Be Safe - shut main electrical power and gas supply off externally before attempting service.



WARNING: Never use drycleaning solvents, gasoline, kerosene, or other flammable liquids in the dryer. ***FIRE AND EXPLOSION WILL OCCUR. NEVER PUT FABRICS TREATED WITH THESE LIQUIDS INTO THE DRYER. NEVER USE THESE LIQUIDS NEAR THE DRYER..***



WARNING: Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.



WARNING: Never let children play near or operate the dryer. Serious injury could occur if a child should crawl inside and the dryer is turned on.



WARNING: Never tumble fiberglass materials in the dryer unless the labels say they are machine dryable. Glass fibers break and can remain in the dryer. These fibers cause skin irritation if they become mixed with other fabrics.



WARNING: Before operating gas ignition system - purge air from natural gas or propane gas lines per manufacturer's instructions.



WARNING: To reduce the risk of electric shock, disconnect this appliance from the power supply before attempting any user maintenance other than cleaning the lint trap. Turning the controls to the OFF position does not disconnect this appliance from the power supply.

**ATTENTION: L'ACHETEUR DOIT PLACER L'AVERTISSEMENT
SUIVANT DANS UN ENDROIT CLAIR ET VISIBLE:**

AVERTISSEMENT. Assurez-vous de bien suivre les instructions donnees dans cette notice pour reduire au minimum le risque d'incendie ou d'explosion ou pour eviter tout dommage materiel, toute blessure ou la mort.

— Ne pas entreposer ni utiliser d'essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil ou de tout autre appareil.

— **QUE FAIRE SI VOUS SENTEZ UNE
ODEUR DE GAZ:**

- Ne pas tenter d'allumer d'appareil.
- Ne touchez a aucun interrupteur. Ne pas vous servir des telephones se trouvant dans le batiment ou vous vous trouvez.
- Evacuez la piece, le batiment ou la zone.
- Appelez immediatement votre fournisseur de gaz depuis un voisin. Suivez les instructions du fournisseur.
- Si vous ne pouvez rejoindre le fournisseur de gaz, appelez le service des incendies.

— l'installation et l'entretien doivent etre assures par un installateur ou un service d'entretien qualifie ou par le fournisseur de gaz.

**ATTENTION: L'ACHETEUR DOIT PLACER L'AVERTISSEMENT
SUIVANT DANS UN ENDROIT CLAIR ET VISIBLE:**

POUR VOTRE SECURITE

Ne pas entreposer ni utiliser d' essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil ou de tout autre appareil.

CISSELL DRYER WARRANTY

The Cissell Manufacturing Company (Cissell) warrants all new equipment (and the original parts thereof) to be free from defects in material or workmanship for a period of two (2) years from the date of sale thereof to an original purchaser for use, except as hereinafter provided. With respect to non-durable parts normally requiring replacement in less than two (2) years due to normal wear and tear, and with respect to all new repair or replacement parts for Cissell equipment for which the two (2) year warranty period has expired, or for all new repair or replacement parts for equipment other than Cissell equipment, the warranty period is limited to ninety (90) days from date of sale. The warranty period on each new replacement part furnished by Cissell in fulfillment of the warranty on new equipment or parts shall be for the unexpired portion of the original warranty period on the part replaced.

With respect to electric motors, coin meters and other accessories furnished with the new equipment, but not manufactured by Cissell, the warranty is limited to that provided by the respective manufacturer.

Cissell's total liability arising out of the manufacture and sale of new equipment and parts, whether under the warranty or caused by Cissell's negligence or otherwise, shall be limited to Cissell repairing or replacing, at its option, any defective equipment or part returned f.o.b. Cissell's factory, transportation prepaid, within the applicable warranty period and found by Cissell to have been defective, and in no event shall Cissell be liable for damages of any kind, whether for any injury to persons or property or for any special or consequential damages. The liability of Cissell does not include furnishing (or paying for) any labor such as that required to service, remove or install; to diagnose troubles; to adjust, remove or replace defective equipment or a part; nor does it include any responsibility for transportation expense which is involved therein.

The warranty of Cissell is contingent upon installation and use of its equipment under normal operating conditions. The warranty is void on equipment or parts; that have been subjected to misuse, accident, or negligent damage; operated under loads, pressures, speeds, electrical connections, plumbing, or conditions other than those specified by Cissell; operated or repaired with other than genuine Cissell replacement parts; damaged by fire, flood, vandalism, or such other causes beyond the control of Cissell; altered or repaired in any way that effects the reliability or detracts from its performance, or; which have had the identification plate, or serial number, altered, defaced, or removed.

No defective equipment or part may be returned to Cissell for repair or replacement without prior written authorization from Cissell. Charges for unauthorized repairs will not be accepted or paid by Cissell.

CISSELL MAKES NO OTHER EXPRESS OR IMPLIED WARRANTY, STATUTORY OR OTHERWISE, CONCERNING THE EQUIPMENT OR PARTS INCLUDING, WITHOUT LIMITATION, A WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, OR A WARRANTY OF MERCHANTABILITY. THE WARRANTIES GIVEN ABOVE ARE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. CISSELL NEITHER ASSUMES, NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT, ANY OTHER WARRANTY OR LIABILITY IN CONNECTION WITH THE MANUFACTURE, USE OR SALE OF ITS EQUIPMENT OR PARTS.

For warranty service, contact the Distributor from whom the Cissell equipment or part was purchased. If the Distributor cannot be reached, contact Cissell.

IDENTIFICATION NAMEPLATE



The Identification Nameplate is located on the rear wall of the dryer. It contains the dryer serial number, product number, model number, electrical specifications and other important data that may be needed when servicing and ordering parts, wiring diagrams, etc. Do not remove this nameplate.

TABLE OF CONTENTS
125 LB. LAUNDRY DRYER


	PAGE
Model Numbers & Company Address	1
Important Notices	2-4
Dryer Warranty	5
Table of Contents	6
Warnings, Cautionary Notes and Symbols	7-8
Unpacking/General Installation	9
Dryer Specifications	10-12
Electrical Connections	13
Gas Piping	14-15
Gas Pipe Size Chart	16
Gas Piping Installation	17
Steam Piping Installation	18-19
Exhaust Installation - Multiple Exhaust	20-22
Dryer Make-up Air Requirements	23
Exhaust Installation - Separate Exhaust	24
Dryer Air Flow Installation	25
Rules for Safe Operation of Dryer	26
Energy Saving Tips	27
Two Timer Models - Instructions	28-30
Moisture Control Models - Instructions	31-32
Service Savers	33
Troubleshooting Charts	34-36
Direct-Spark Ignition Operation	37-38
General Maintenance	39
Burner Air Inlet Adjustment	40
Basket Alignment	41-42
Shimming the Basket and Spider Assembly	43
Air Switch Adjustment	44
Dryers with Reversing Control Timer	45-46
Large Gear Reducer Maintenance	47
Front Exploded View	48-49
Double Motor Model	50-51
Front Panel and Door Assembly	52
Thermostat Assembly	53
Air Switch Assembly	54
Thermistor Assembly	54
Reversing Control Panel Assembly	55
Permanent Press Control Panel Assembly	56
Moisture Control Panel Assembly	57
Large Gear Reducer	58
Gas Bonnet Assembly	59
Steam Bonnet Assembly	60-62

SYMBOLS

The following symbols are used in this manual and/or on the machine. The numbers between () refer to the numbers on the machine surveys.

Symbol	Description	Part/Measurement
	NOTE!	
	Hot! Do Not Touch Heiß! Nicht Berühren Haute temperature! Ne pas toucher Caliente! no tocar	
	dangerous voltage tension dangereuse Gefährliche elektrische Spannung tension peligrosa	
	on marche Ein conectado	
	off arrêt Aus desconectado	
	start demarrage Start arranque de un movimiento	
	emission of heat in general émission de chaleur en general Warmeabgabe allgemein emisión de calor	
	cooling refroidissement Kühlen enfriamiento	

SYMBOLS

Symbol	Description	Part/Measurement
	<p>rotation in two directions rotation dans les deux sens Drehbewegung in zwei Richtungen movimiento rotativo en los dos sentidos</p>	
	<p>direction of rotation sens de mouvement continu de rotation Drehbewegung in Pfeilrichtung movimiento giratorio o rotatorio en el sentido de la flecha</p>	
	<p>End of Cycle</p>	
	<p>caution attention Achtung atencion; precaucion</p>	

Unpacking/General Installation (All Dryers)

UNPACKING

This dryer is packed in a large wooden crate.

Upon arrival of the equipment, any damage in shipment should be reported to the carrier immediately.

Upon locating permanent location of a unit, care should be taken in movement and placement of equipment.

See outline clearance diagrams for correct dimensions.

Remove all packing material such as: tape, manuals, skid, etc.

Leveling: Use spirit level on top of dryer. The use of shims are acceptable for this procedure.

Check voltage and amperes on rating plate before installing the dryer.

On gear reducer models, remove screw and insert red vent attached to reducer.

The construction of the dryers permits installation side-by-side to save space or to provide a wall arrangement. Position dryer for the least amount of exhaust piping and elbows, and allow free access to the rear of dryer for future servicing of belts, pulleys and motors. Installation clearance from all combustible material is 12" (305 mm) ceiling clearance, 24" (610 mm) rear clearance, and 0" side clearance.

Before operating dryer, open basket door and remove blocking between front panel and basket. Read the instruction tags, owner's manual, warnings, etc.

GENERAL INSTALLATION (ALL DRYERS)



IMPORTANT

Opening the clothes loading door deactivates the door switch to shut off the motors, fan, gas, steam, or electric element. To restart the dryer, close the door and press in the push to start button for approximately 2 seconds.



IMPORTANT

This dryer is designed for a capacity maximum load. Overloading it will result in long drying times and damp spots on some clothes.



IMPORTANT

Maximum operating efficiency is dependent upon proper air circulation. The lint screen must be kept clean daily to insure proper air circulation throughout the dryer.




IMPORTANT


Provide adequate clearance for air opening into the combustion chamber.

125 lb. General Dimensions (Illustration)


FRONT VIEW DIMENSIONS




RIGHT VIEW DIMENSIONS




REAR VIEW DIMENSIONS



**TOP VIEW DIMENSIONS
50 CYCLE**




**TOP VIEW DIMENSIONS
60 CYCLE**




125 lb. Steam Heated Dryer Dimensions (Illustration)

FRONT VIEW DIMENSIONS



RIGHT VIEW DIMENSIONS



Specifications


GENERAL SPECIFICATIONS FOR 125 lb. DRYERS

Floor Space	
<i>Gas</i>	67" Deep x 47" W x 89-1/8" H (1702 mm x 1194 mm x 2264 mm)
<i>Steam</i>	67" Deep x 47" W x 93-3/4" H (1702 mm x 1194 mm x 2382 mm)
Door Opening	31-1/4" diameter (794 mm)
Basket Size	44" diameter x 42" Deep (1118 mm x 1067 mm)
Basket Load Capacity	125 lbs. (56.7 kg) dryweight
Basket Motor	1 HP (.75 kW)
Fan Motor	1-1/2 HP (1.12 kW)
Basket RPM	
<i>Reversing</i>	28 (3.2 reversals per minute)
<i>Non-Reversing</i>	34
Exhaust Duct	12" diameter (305 mm)
Maximum Air Displacement	
<i>Steam</i>	2000 cfm (3400 m ³ /h)
<i>Gas</i>	2000 cfm (3400 m ³ /h)
Recommended Operating Range	1800-2000 cfm (3060-3400 m ³ /h)
Net Weight (approximate)	
<i>Steam</i>	1,614 lbs. (492 kg)
<i>Gas</i>	1,515 lbs. (462 kg)
Shipping Weight	
<i>Steam - 1 crate (approx.)</i>	1,764 lbs. (538 kg)
<i>Gas - 1 crate (approx.)</i>	1,665 lbs. (507 kg)
Export Shipping Dimensions	93" L x 53" W x 78" H -232.7 cu. ft. (2363 mm x 1347 mm x 1982 mm) - (6.59 m ³)
BTU Input Rating	300,000 Btu/h (75,600 kcal/h) (nat., mixed and mfg. gases) 300,000 Btu/h (75,600 kcal/h) (propane and butane gases)
Gas Supply	3/4" (20 mm) pipe connection
Electric Ignition	Direct Spark Ignition System
Manifold Gas Pressure	3.5" w.c. (8.8 mbar) Max. (Nat. Gas); 11" w.c. (27.4 mbar) (LP Gas)
Drying Time (dry weight)	120 lbs. (49.9 kg) (Indian Head)
<i>(Approximate - testing in laboratory)</i>	70% water retention - 25 min. 50% water retention - 22 min.

STEAMHEATED DRYERS ONLY

Operating Steam Pressure	100 PSIG (6.9 bar) Max.
Boiler HP (w/normal ld.) (<i>14FPI</i>)	10.4 (7.76 kW)
(<i>4-Coil</i>)	7.87 (5.88 kW)
(<i>6-Coil</i>)	9.5 (5.88 kW)
Steam Coils	(2) 40-1/2"L x 15-3/4"H x 6"W (2) (1029 mm x 401 mm x 153 mm)
Traps for Steam Heating Coils	3/4" (20 mm) (2)
Steam Supply Line	3/4" (20 mm)
Steam Return Line	3/4" (20 mm)

Electrical Connections (with Grounding Instructions Illustration)



ELECTRICAL CONNECTIONS FOR ALL DRYERS

Dryers must be electrically grounded by a separate #14 or larger green wire from the **grounding terminal** within the service connection box, to a cold water pipe. In all cases, the grounding method must comply with **local electrical code requirements**; or in the absence of local codes, with the *National Electrical Code, ANSI/NFPA 70* or the *Canadian Electrical Code, CA C22.1*.

See wiring diagram furnished with dryer. Your dryer is completely wired at the factory and it is only necessary for the electrician to connect the power leads to the wire connectors within the service connection box on the rear of the dryer. **Do not change wiring without consulting the factory, as you may void the factory warranty. DO NOT CONNECT THE DRYER TO ANY VOLTAGE OR CURRENT OTHER THAN THAT SPECIFIED ON THE DRYER RATING PLATE.** (Wiring diagram is located on rear wall of dryer.)

All panels must be in position before operation of dryer.

«Attention. Lors des opérations d'entretien des commandes, étiqueter tous les fils avant de les déconnecter. Toute erreur de câblage peut être une source de danger et de panne»

Gas Piping

GASSERVICE INSTALLATION INFORMATION

The size of the gas service pipe is dependant upon many variables, such as tees, lengths, etc. Specific pipe size should be obtained from the gas supplier. Refer to the *Gas Pipe Size Chart* in this manual for general *gas pipe size* information.



CAUTION

Gas loop piping must be installed as shown in Illustration, to maintain equal gas pressure for all dryers connected to a single gas service.

Other gas using appliances should be connected upstream from the loop.





WARNING

(LIQUIFIED PETROLEUM GASES ONLY)

A Gas Pressure Regulator for Liquefied Petroleum Gases is not furnished on Gas Heated Clothes Dryers. This regulator is normally furnished by the installer. In accordance with American Gas Association (AGA) standards, a gas pressure regulator, when installed indoors, must be equipped with a vent limiter, or a vent line must be installed from the gas pressure regulator vent to the outdoors.

Gas Loop Piping and Gas Supply Piping System (Illustrations)



Gas Pipe Size Chart

TOTAL BTU/HR (for LP Gas correct total BTU/HR below by multiplying by .6)	TOTAL KCAL	GAS PIPE SIZE FOR 1000 BTU (250 KCAL) NATURAL GAS AT 7" W.C. (17.5 MBAR) PRESSURE					
		In figuring total length of pipe, make allowance for tees and elbows.					
		(25 ft.) 7,62 m	(50 ft.) 15,24 m	(75 ft.) 22,86 m	(100 ft.) 30,48 m	(125 ft.) 38,1 m	(150 ft.) 45,72 m
60,000	15000	3/4	3/4	3/4	3/4	3/4	3/4
80,000	20000	3/4	3/4	3/4	1	1	1
100,000	25200	3/4	3/4	1	1	1	1
120,000	30200	3/4	1	1	1	1	1
140,000	35200	3/4	1	1	1	1	1 1/4
160,000	40300	3/4	1	1	1 1/4	1 1/4	1 1/4
180,000	45300	1	1	1	1 1/4	1 1/4	1 1/4
200,000	50400	1	1	1 1/4	1 1/4	1 1/4	1 1/2
300,000	75600	1	1 1/4	1 1/4	1 1/2	1 1/2	1 1/2
400,000	100800	1 1/4	1 1/4	1 1/2	1 1/2	1 1/2	2
500,000	126000	1 1/4	1 1/2	1 1/2	2	2	2
600,000	151200	1 1/2	1 1/2	2	2	2	2
700,000	176400	1 1/2	2	2	2	2	2 1/2
800,000	202000	1 1/2	2	2	2	2 1/2	2 1/2
900,000	230000	2	2	2	2 1/2	2 1/2	2 1/2
1,000,000	250000	2	2	2	2 1/2	2 1/2	2 1/2
1,100,000	270000	2	2	2 1/2	2 1/2	2 1/2	2 1/2
1,200,000	300000	2	2	2 1/2	2 1/2	2 1/2	2 1/2
1,300,000	330000	2	2 1/2	2 1/2	2 1/2	2 1/2	3
1,400,000	350000	2	2 1/2	2 1/2	2 1/2	3	3
1,500,000	380000	2	2 1/2	2 1/2	2 1/2	3	3
1,600,000	400000	2	2 1/2	2 1/2	3	3	3
1,700,000	430000	2	2 1/2	2 1/2	3	3	3
1,800,000	450000	2 1/2	2 1/2	3	3	3	3
1,900,000	480000	2 1/2	2 1/2	3	3	3	3
2,000,000	504000	2 1/2	2 1/2	3	3	3	3 1/2
2,200,000	550000	2 1/2	3	3	3	3 1/2	3 1/2
2,400,000	605000	2 1/2	3	3	3	3 1/2	3 1/2
2,600,000	650000	2 1/2	3	3	3 1/2	3 1/2	3 1/2
2,800,000	705000	2 1/2	3	3	3 1/2	3 1/2	3 1/2
3,000,000	750000	2 1/2	3	3 1/2	3 1/2	3 1/2	4
3,200,000	806000	3	3	3 1/2	3 1/2	3 1/2	4
3,400,000	850000	3	3 1/2	3 1/2	3 1/2	4	4
3,600,000	907000	3	3 1/2	3 1/2	3 1/2	4	4
3,800,000	960000	3	3 1/2	3 1/2	4	4	4
4,000,000	1000000	3	3 1/2	3 1/2	4	4	4

Gas Piping Installation

GAS PIPING INSTALLATION

1. The installation must conform to **local codes** or in absence of local codes, with the ***National Fuel Gas Code, ANSI Z223 or the CAN/CGA-B149, Installation Codes.***
2. Check with utilities for proper gas pressure and gas supply line.
3. Check for altitude elevation of the dryer.
4. The dryer and its individual shut-off valve must be disconnected from the gas supply piping system at test pressures in excess of 1/2 PSIG (.04 bar).
5. The dryer must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system, at test pressures equal to or less than 1/2 PSIG (.04 bar).



NATURAL GAS ONLY

Check the gas pressure inlet supply to the dryer, 11"WC (27.4 bar) Pressure maximum. Check the manifold pressure, 3.5"WC (8.8 bar) Pressure inside the dryer.



CAUTION

Low gas pressure and intermittent gas will cause gas ignition problems and inadequate drying of the clothes load.

Steam Piping Installation


INSTALLATION INSTRUCTIONS

1. Set and anchor dryer in position. **Machine should be level to assure proper steam circulation.**
2. To prevent condensate draining from headers to dryer, piping should have a minimum 12" (305 mm) above respective header. **Do not make steam connection to header with a horizontal or downwardly facing tee or elbow.**
3. Whenever possible, horizontal runs of steam lines must drain, by gravity, to respective steam header. Water pockets, or an improperly drained steam header will provide wet steam, causing improper operation of dryer. If pockets or improper drainage cannot be eliminated, install a bypass trap to drain condensate from the low point in the steam supply header to the return.
4. In both steam supply and steam return line, it is recommended that each have a 3/4" (20 mm) union and 3/4" (20 mm) globe valve. This will enable you to disconnect the steam connections and service the dryer while your plant is in operation.
5. Before connecting trap and check valve to dryer, open globe valve in steam supply line and allow steam to flow through dryer to flush out any dirt and scale from dryer. This will assure proper operation of trap when connected.
6. After flushing system, install bucket trap (with built-in strainer) and check valve. For successful operation of dryer, install trap 18" (458 mm) below coil and as near to the dryer as possible. Inspect trap carefully for inlet and outlet markings and install according to trap manufacturer's instructions. If steam is gravity returned to boiler, omit trap but install check valve in return line near dryer.
7. Install union and globe valve in return line and make final pipe connections to return header.

PIPING RECOMMENDATIONS


1. Trap each dryer individually. Always keep the trap clean and in good working condition.
2. When dryer is on the end of a line of equipment, extend header at least 4 feet (2 m) beyond dryer. Install globe valve, union, check valve and bypass trap at end of line. If gravity returned to boiler, omit trap.
3. **Insulate steam supply and return line for safety of operator and safety while servicing dryer.**
4. Keep dryer in good working condition. Repair or replace any worn or defective parts.

Steam Piping Installation (Illustration)



Exhaust Installation—Multiple Manifold Duct

For Exhaust Duct less than 14 feet (5m) and 2 elbows equivalent and less than 0.3 inches (8 mm) static pressure.



DRYER EXHAUSTS

Area of section "A-A" must be equal to the sum of dryer exhaust pipes entering multiple exhaust pipe. (See chart below.)

MODELS: L28FD30, L28US30, L36FD30, L36US30, L36US36, L44FD42

No. of Dryers
Duct Diameter
(in inches)
(in CM)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
6	9	11	12	14	15	16	17	18	19	20	21	22	23	23	24	25	26	26	27	28	28	29	30
15	23	27	30	35	38	41	43	46	48	51	53	56	58	58	61	63	66	66	68	71	71	73	76

MODELS: L28CD30, L28UR30, L36CD30, L36UR30, L36UR36, L36AR36, L44FD42

No. of Dryers
Duct Diameter
(in inches)
(in CM)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
8	12	14	16	18	20	22	23	24	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
20	30	25	41	46	51	56	58	61	66	68	71	73	76	78	81	84	86	89	91	94	97	99	100


MODELS: L44CD42, L50CD42

No. of Dryers
Duct Diameter
(in inches)
(in CM)


1	2	3	4	5	6	7	8	9	10	11	12
12	17	21	24	27	30	32	34	36	38	40	42
30	43	53	61	68	76	81	86	91	97	100	106

AUTOMATIC ELECTRICAL CONTROL FOR EXHAUST FAN

For one or more dryers to start fan.



Dryer Installation with Multiple Exhaust (Illustration)



Dryer Installation with Multiple Exhaust

EXHAUST INSTALLATION— MULTIPLE MANIFOLD DUCT

For Exhaust Duct more than 14 feet (5 m) and 2 elbows equivalent and more than 0.3 inches (8 mm) static pressure.

1. Make-up air from outside building may enter enclosure from top or side walls. (*See Dryer Make-Up Air Requirements Chart*)
2. Use constant diameter duct with area equal to the sum of dryer duct areas.

EXAMPLE: 6-8 in. (153-204 mm) diameter duct = 1-19.6 in. (26-498 mm) diameter duct in area. Use 20 in. (508 mm) diameter duct or diameter to match tube-axial fan.

3. Enclosure (plenum) with service door. This separates the dryer air from room comfort air. If dryers use room air instead of outside air, the heat loss can be another 25 Btu/h (6.3 kcal/h) for each cubic foot per minute (cfm) used.

EXAMPLE: 125 lb. dryer, 2000 cfm (3400 m³/h) = 50,000 Btu/h (12,600 kcal/h) loss.

4. Zero inches clearance to combustible material allowed on sides and at points within 4 inches (102 mm) of front on top.
5. Heat loss into laundry room from dryer fronts *only* is about 60 Btu/h (16 kcal/h) per square foot.
6. Flange mounted, belt driven tube-axial fan. **Fan must run when one or more dryers are running.** *See suggested Automatic Electrical Control Wiring Diagram on page 23.* Must meet local electrical codes. Fan air flow (cfm) is equal to sum of dryer air flows, but static pressure (SP) is dependent on length of pipe and number of elbows.
7. **Barometric Bypass Damper**—Adjust to *closed flutter position* with all dryers and exhaust fan running. **Must be located within enclosure.**



CAUTION

Never install hot water heaters or other gas appliances in the same room as dryers. Never install cooling exhaust fans in the same room as dryers.



CAUTION

Never exhaust dryers with other types of equipment.


Suggested Minimum Dryer Make-up Air Requirements

Dryer Model	Dryer Pocket Capacity		Maximum Air Flow Rate per Pocket		Duct Size For Service Connection		Required Make-up Air Area per Pocket	
	lb	kg	cfm	m3/h	inch	mm	sq. inch	cm2
C 30 ST	30	13.6	450	765	6	153	87	561
C 75 ST	75	34	1000	1700	12	305	192	1240
C 110	110	50	2200	3740	12	305	422	2723
C 110 E/S	110	50	850	1445	8	203	163	1052
C 125	125	56.7	2000	3400	12	305	384	2477
C 150	150	68	2250	3825	12	305	432	2787
HD175	175	79.4	2780	4726	12	305	534	3445
HD190	190	86.2	3000	5100	12	305	576	3716
HD20.1	20	9.1	450	765	6	153	87	561
HD30SL	30	13.6	600	1020	8	203	116	748
HD30.1	30	13.6	625	1063	8	203	120	774
HD50.1	50	22.7	850	1445	8	203	164	1058
HD75.1	75	34	1000	1700	8	203	192	1240
HD80.1	80	36.3	1000	1700	10	254	192	1240

Notes:

- 1) The Model C 30 ST has 2 pockets per dryer, each pocket has the above listed characteristics; each pocket is exhausted separately with a 6" (153mm) duct.
- 2) The Model C 75 ST has 2 pockets per dryer, each pocket has the above listed characteristics; both pockets have one 8" (203mm) exhaust manifolded into one 12" (305mm) exhaust duct for exhaust connection.
- 3) For the C 30 ST and the C 75 ST Models, the Required Make-up Air Area shown in the table should be doubled since it is shown per pocket,only.

Dryer Installation with Separate Exhaust (Preferred) (Illustration)



DRYER INSTALLATION WITH SEPARATE EXHAUST (PREFERRED)

DRYER INSTALLATION WITH SEPARATE EXHAUST (PREFERRED)

For Exhaust Duct less than 14 feet (5 m) and 2 elbows equivalent and less than 0.3 (8 mm) inches static pressure.



NEVER exhaust the dryer into a chimney.



NEVER install wire mesh screen over the exhaust or make-up air area.



NEVER exhaust into a wall, ceiling, or concealed space.

1. Make-up air opening from outside the building may enter the enclosure from the top or side walls. *(See Dryer Make-Up Air Requirements Chart)*
2. Enclosure (plenum) with service door. This separates the dryer air from the room comfort air. If dryers use room air instead of outside air, the heat loss can be another 25 Btu/h (6.3 kcal/h) for each cubic foot per minute (cfm) used.
EXAMPLE: A 125 lb. dryer with 2000 cfm (3400 m³/h) = heat loss of 50,000 Btu/h (12,600 kcal/h).
3. Zero inches clearance to combustible material allowed on sides and at points within 4 inches (102 mm) of front on top.
4. Heat loss into laundry room from dryer fronts *only* is about 60 Btu/h (15.2 kcal/h) per square foot.

Dryer Air Flow Installation

DRYER AIR FLOW INSTALLATION

Nothing is more important than air flow for the proper operation of a clothes dryer. A dryer is a pump which draws make-up air from the out-of-doors, through the heater, through the clothes and then forces the air through the exhaust duct back to the out-of-doors. Just as in a fluid water pump, there must be a fluid air flow to the inlet of the dryer, if there is to be the proper fluid air flow out of the exhaust duct.

In summary, there must be the proper size out-of-doors inlet air opening (4-6 times the combined areas of the air outlet) and an exhaust duct, size and length of which allows flow through the dryer with no more than 0.3 inches water column (.8 mbar) static pressure in the exhaust duct.

In some instances, special fans are required to supply make-up air, and/or boost exhaust fans are required for both regular and energy saving models.

EXHAUSTING DUCT

FOR BEST DRYING:

1. Exhaust duct maximum length 14 feet (5 m) of straight duct and maximum of two 90° bends.
2. Use 45° and 30° elbows wherever possible.
3. **Exhaust each dryer separately.**
4. **Do not** install wire mesh or other restrictions in the exhaust duct.
5. Use clean-outs in the exhaust duct and clean periodically when needed.
6. **Never** exceed 0.3 inches water column (.8 mbar) static pressure in the exhaust duct without a booster fan.
7. Inside surface of the duct **must be smooth.**
8. Recommend pop rivets for duct assembly.

MAKE-UP AIR

FOR BEST DRYING:

1. Provide opening to the out-of-doors in accordance with the following:
For each dryer—
8 inches (204 mm) diameter exhaust requires 2 square feet (.1858 m²) make-up air.
12 inches (305 mm) diameter exhaust requires 4 square feet (.3716 m²) make-up air.
2. Use barometric shutters in the inlet air opening to control air when dryers are not running.

OTHER RECOMMENDATIONS TROUBLESHOOTING

Other Recommendations

To assure compliance, consult local building code requirements.

Troubleshooting

Hot dryer surfaces, scorched clothes, slow drying, lint accumulations, or air switch malfunction are indicators of exhaust duct and/or make-up air problems.

Rules for Safe Operation of Dryer

RULES FOR SAFE OPERATION OF DRYER

1. **Be sure** your dryer is installed properly in accordance with the recommended instructions.
2. **CAUTION**
Be safe—**shut main electrical power supply and gas supply off externally before attempting service.**
3. **CAUTION**
Never use drycleaning solvents: gasoline, kerosene, or other flammable liquids **in the dryer. *Fire and explosion will occur.***
Never put fabrics treated with these liquids into the dryer. Never use these liquids near the dryer.
Always keep the lint screen clean.
Never use heat to dry items that contain plastic, foam or sponge rubber, or rags coated with oils, waxes or paints. The **heat may damage the material or create a fire hazard.**
Rubber easily oxidizes, causing excessive heat and possible fire.
Never dry the above items in the dryer.
4. **Never let children play near or operate the dryer. Serious injury will occur if a child should crawl inside and the dryer is turned on.**
5. **Never** use dryer door opening and top as a step stool.
6. **Read** and follow manufacturer's instructions on packages of laundry and cleaning aids. Heed any **warnings** or **precautions**.
7. **Never** tumble fiberglass materials in the dryer unless the labels say they are machine dryable. Glass fibers break and can remain in the dryer and could cause skin irritation if they become mixed into other fabrics.
8. **Reference**
Lighting and shut-down instructions and wiring diagrams are located on the rear wall of the dryer cabinet.
9. **The dryer must not be installed or stored in an area where it will be exposed to water and/or weather.**

Energy Saving Tips

ENERGY SAVING TIPS

1. Install dryer so that you can use short, straight venting. Turned elbows and long vent tubing tend to increase drying time. Longer drying time means the use of more energy and higher operating costs.
2. Operate dryer using full-size loads. Very large loads use extra energy. Very small loads waste energy.
3. Dry light-weight fabrics separately from heavy fabrics. You will use less energy and get more even drying results by drying fabrics of similar weight together.
4. Clean the lint screen area daily. A clean lint screen helps give faster, more economical drying.
5. **Do not** open the dryer door while drying. You let warm air escape from the dryer into the room.
6. Unload the dryer as soon as it stops. This saves having to re-start your dryer to remove wrinkles.



NOTE

It is best to run a properly sized bag of rags and/or old towels through one or two cycles prior to drying in service. This process will remove any films or residual coatings left by the manufacturing process.



CAUTION

Synthetic solvent *fumes* from dry cleaning machines create acids when drawn through the dryer. These acid fumes cause rusting of painted parts, pitting of bright plated parts and completely removes the zinc from galvanized metal parts, such as the tumbler basket.

If the dry cleaning machines are in the same area as the tumbler, then the tumbler *make-up air* must come from a source free of solvent fumes.

ABOVE 2,000 FEET (610 M)

ELEVATIONS ABOVE 2,000 FEET (610 M)

Input ratings shown on the rating plate (serial tag) are for elevations up to 2,000 feet (610 m). For elevations above 2,000 feet (610 m), rating should be reduced at a rate of 4% for each 1,000 feet (305 m) above sea level.

Two Timer Models—Figures 1, 2, and 3 (Illustrations)




Fig. 1



Fig. 2 Temperature Selection





Fig. 3 Thermometer



**OPERATING
INSTRUCTIONS—TWO
TIMER MODELS**

OPERATINGINSTRUCTIONS—TWOTIMERMODELS

1. After loading the dryer tumbler with the water washed clothes load, close the loading door. For better drying, do not load dryer with combination of garments that twist.
2. Turn the 60-minute drying timer to the desired drying time. The drying cycle light will be on and indicate the drying. The light shuts off when drying time is complete. (figure 1 on page 26.)
3. Turn the 15-minute cooling cycle timer to the desired cool down time. (**Note: Dryer will not start unless some cooling time is selected!**). After the drying cycle is completed, then the cooling cycle time will automatically operate. The cooling light will be on and indicate the cooling of the clothes load. The light shuts off when cooling time is completed. (figure 1 on page 26.)
4. **Temperature Selector**—Select temperature per type of load being dried in the dryer. (figure 2 on page 26.)
High Heat—Mixed and heavy fabrics, set dial to 195°F (77°C).
Normal—Cottons and linens, set dial to 170°F (77°C).
Permanent Press Heat—Poly knit synthetics, blends, light-weight fabrics, set dial to 150°F (66°C).
Low Heat—Delicate, sheer fabrics, easy-to-dry, set dial to 135°F (58°C).
5. **Thermometer**—Use this with your temperature selection. Note what temperature is too hot or too cold. (figure 3 on page 26.)
6. Turn switch to “ON” or “I” position. (figure 1 on page 26.)
7. Close the dryer door, but the basket **will not rotate** until the **PUSH-TO-START BUTTON** is pressed. Press in the **PUSH-TO-START BUTTON** (approximately 2 seconds) until the dryer starts running and then release button. (figure 1 on page 26.)

**OPERATING
INSTRUCTIONS—TWO
TIMER MODELS**

**OPERATING INSTRUCTIONS—TWO TIMER MODELS
(continued)**


What is happening to the drying operation:

- a. The fan motor will operate.
- b. The basket will rotate.
- c. The heat source will be energized.
- d. The heated air will mix with the water washed clothes to evaporate the moisture from the garments.
- e. The thermostats will function to maintain a safe temperature throughout the drying cycle.
- f. The heat will be shut off and the motor will continue to run to cool the dry load to a desired handling temperature.

8. When the drying timer completes its time, then the cooling timer will be energized and the cooling light will be “On”. When the cooling timer completes its time, the cooling light will turn “Off” and the “End-of-Cycle” light will be “On”. The “End-of-Cycle” light will go off when the “Start/Stop” switch is turned to “Off” or “O”. At the end of the cool-down cycle, the clothes load is dry.
9. To shut the dryer “Off”, move the “Start/Stop” switch to “Off” or “O” position. This switch is a safety switch to immediately stop the dryer's operation.

Special Reversing Feature—Set the “Reversing/Non-Reversing” switch to “Reversing”. See service manual for setting of time of each reversal. Reversing of the basket is designed for loads that twist (**example**—bed sheets and large mixed loads). “Non-Reversing” is for small or medium-size items that don't twist.

Moisture Control (Illustration)



Operating Instructions - Moisture Control Models (Optional)

OPERATING INSTRUCTIONS- MOISTURE CONTROL MODELS (OPTIONAL)

NOTE:

Machines with Moisture Control option can be used like regular two-timer models. To dry with Two Timer method, flip switch on Control Panel to “Time Drying”. To dry with the Moisture Control method, flip the switch to “Automatic Drying”. The indicator light will be on while the machine is in operation.

1. After loading the dryer tumbler with water washed clothes load, close the loading door. For better drying, do not load dryer with combination of garments that twist.
2. Select desired Moisture level to remain in “the load from the selector switch on the Control Panel (see page 26). The numbers are relative with “10” being the most wet and “0” being the most dry. After a number of loads have been run and desired moisture level has been determined, record and reuse the same setting on similar loads.
3. Turn the 15-minute cooling cycle timer to the desired cool down time. After the drying cycle is completed, then the cooling cycle time will automatically operate. The cooling light will be on and indicate the cooling of the clothes load. The light shuts off when cooling time is completed. (See page 26.)
4. **Temperature Selector** - Select temperature per type of load being dried in the dryer. (See page 23.)
High Heat - Mixed and heavy fabrics, set dial to 195° F (91° C).
Normal - Cottons and linens, set dial to 170° F (77° C).
Permanent Press Heat - Poly knit synthetics, blends, lightweight fabrics, set dial to 150° F (66° C).
Low Heat - Delicate, sheer fabrics, easy-to-dry, set dial to 135° F (58 °C).
5. **Digital Temperature Read Out** - Use this with your temperature selection. Note what temperature is too hot or too cold. (See figure 1 on page 23.)
6. Turn switch to “ON” or “P” position. (See page 26.)
7. Close the dryer door. The basket **will not rotate** until the **PUSH-TO-START BUTTON** is pressed. Press the **PUSH-TO-START BUTTON** until the dryer starts running (approximately 2 seconds) and then release button. (See figure 1 on page 26.)
8. The machine cycle will stop drying and switch to cool-down when the desired set moisture level has been reached. The machine will run for the amount of time set on the cool-down timer.

Service Savers

TROUBLESHOOTING

To help you troubleshoot the dryer, we list below the most common reasons for service calls and some answers to the problems. **Before you call service**, please review the following items:

DRYER WON'T START

1. Is the door completely closed?
2. Are the controls set to the “**ON**” or “**I**” position?
3. Did you push the “**start**” control?
4. Has a fuse blown or a circuit breaker tripped?
5. Are the fuses tight?
6. Check for low voltage.

DRYER WON'T HEAT

1. Is the dryer set for “**cooling time**” rather than “**drying time**”?
2. Are the gas valve in the dryer and the valve on the main gas line turned on?
3. Check for low or intermittent **gas pressure**.

CLOTHES ARE NOT SATISFACTORILY DRY

1. *Timed cycle*—Did you allow enough heating time before the cool-down part of the cycle?
2. Is the lint screen blocked?
3. Is the exhaust duct to the outside clean and not blocked? (*A blocked exhaust will cause slow drying and other problems.*)

GAS DRYER IGNITION

The dryer has a safety device which automatically shuts off the gas if the burner fails to light in a short time. If this happens, turn the dryer off. Check and see if the manual gas valve is open. **Wait 5 minutes for the safety device to reset.** Then reset the dryer controls. If the dryer still fails to heat, call for service. **All panels, covers and doors must be in place and closed before starting the dryer.**

VERY IMPORTANT

When calling the factory for service, always refer to the model number and serial number.

Troubleshooting Chart

TROUBLE	CAUSE	REMEDY
Motor will not start.	No power.	Check fuses on Circuit Breakers. Make sure Main Control Switch is ON.
	Incorrect power.	Check power source; voltage, phase and frequency must be the same as specified on Electrical Rating Plate.
	Time off.	Turn timer clockwise to desired time setting.
	Loose wiring connections.	Check wire connections in electrical box on rear of dryer.
	Defective starting relay.	Check coils and contacts.
Motor tripping on thermal overload.	Low voltage.	Check voltage at motor terminals. Voltage must be within + 10% of voltage shown on Motor Rating Plate. If not, Check with local power company for recommended corrective measures.
	Inadequate wiring.	Check with local power company to insure that wiring is adequately sized for load.
	Loose connections.	Check all electrical connections and tighten any loose connections.
	Inadequate air.	Check Installation Sheet in Service section for recommended make-up air openings.
	Poor housekeeping.	Clean lint accumulation on and around motors.
Basket motor will not run.	Loading door OPEN.	Close door.
	Door Switch out of adjustment.	Adjust switch by removing cover and bend Actuator Lever to clear Switch Button 3/8" (10mm) with cover in place.
	Defective Door Switch.	Replace switch.
	Defective Basket Motor Contractor.	Replace contactor.
Motor runs, but basket will not revolve.	V-Belt broken.	Replace V-Belt.
	V-Belt loose.	Adjust belt tension.
	Motor Pulley loose.	Tighten set screw.
	Basket overloaded.	Remove load.
Dryer noisy or vibrating.	Not leveled.	Check manual for proper leveling procedures.
	Fan out of balance.	Accidental damage to the fan blade can change the dynamic balance. Damaged fans should be replaced.
	Basket rubbing.	Adjust basket clearance.
	V-Belt sheaves.	Tighten set screws. Make sure sheaves are in proper alignment.
	Belt.	Adjust belt tension.
	Foreign objects.	Occasionally screws, nails, etc., will hang in the basket perforations and drag against the sweep sheets surrounding the basket. Such foreign objects should be removed immediately.

Troubleshooting Chart

TROUBLE	CAUSE	REMEDY
Dryer runs, but no heat.	Incorrect voltage.	Check for correct control voltage - 24V.
	No voltage.	Check power supply, check secondary voltage on transformer and check wiring and wiring diagram.
	Lint Door OPEN.	CLOSE Lint Door.
	Defective Gas Valve.	Replace Valve Assembly.
	Gas turned OFF.	Turn Manual Gas Valve ON.
	Line fuse or heater circuit fuse blown to unit.	Replace fuse.
	Defective Door Switch.	Replace Door Switch.
	Spark Igniter not igniting gas.	Check ground.
	Air Switch not operating.	Clean out lint compartment daily. Check Back Draft Damper for foreign objects, lint accumulation or other causes that may prevent damper from operating. Check duct work for lint build-up. Check installation sheet to insure that duct work and make-up air openings are adequately sized. Check exhaust outlet. If a screen has been improperly installed on the outlet, it may be clogged with lint or frozen over in winter. Never install a screen on the exhaust outlet. Vacuum within dryer drops to .09 inches or water column, or less, for normal operation of dryer, vacuum reading can be made with a Vacuum U-Gauge by removing a sheet metal screw in the front panel of dryer, and inserting the rubber tube of the vacuum gauge into screw opening.
	Air Switch out of adjustment.	See Air Switch Adjustment Sheet in Service Manual.
	Air Switch defective.	Replace Air Switch.
	Gas pressure too low.	Check manifold pressure and adjust to pressure specified on Rating Plate. If this pressure cannot be obtained, have gas supplier check main pressure.
	Improper orifice.	Dryer is orificed for type of gas specified on Rating Plate. Check with gas supplier to determine specifications for gas being used. If different from Rating Plate, Contact factory and obtain proper orifices.
	Electric power to heating unit turned OFF.	Turn power ON.
	Defective relay.	Replace relay.
	Defective thermostat.	Replace thermostat.
Defective Safety Overload Thermostat.	Replace thermostat.	
Lint compartment door OPEN.	CLOSE door.	

Troubleshooting Chart

TROUBLE	CAUSE	REMEDY
Main Burners burning improperly.	Dirt in burner.	Blow out.
	High gas pressure.	Adjust gas pressure per Rating Plate.
	Orifice too large.	Send to factory for correct orifices.
	Restricted or blocked exhaust.	Clean exhaust.
Main Burner cycles ON and OFF.	Defective Ground.	Check Ground.
Low or high gas flame.	Incorrect Main Burner orifices.	Replace orifices. Check factory for correct size.
Dryer too hot.	Incorrect Main Burner orifice.	Replace orifices. Check factory for correct size.
	Inadequate make-up air.	Make-up air must be 4 to 6 times the exhaust area of the dryer.
	Lint accumulated.	Remove lint.
	Exhaust duct dampers.	Must be full OPEN or replace.
	High gas pressure.	Adjust gas pressure as specified on Rating Plate.
	Partially restricted or inadequately sized exhaust system.	Check Service section for recommended sizes. Remove obstructions or lint build up from duct work. NEVER use smaller size exhaust duct. ALWAYS use larger size.
	Defective thermostat.	Replace thermostat.
Dryer does not stop at end of time period (6).	Defective timer.	Replace timer.
Dryer runs no steam to coils.	Valve CLOSED.	Check all valves in steam supply and return. Make sure they are OPEN.
	Steam Trap blocked.	Remove and clean. Replace if defective.
	Solenoid Valve.	On dryers using solenoid temperature control, thermostat controls operation of Solenoid Valve by advancing thermostat.
	Thermostat.	On dryers using solenoid temperature control, thermostat controls operation of Solenoid Valve. If defective, replace thermostat.
	Check Valve installed incorrectly.	Check for inlet and outlet marking on Check Valve and invert if necessary.
	Strainer clogged.	Remove plug and blow down Strainer or remove and clean thoroughly if heavily clogged.
Water in Steam Line.	Steam Piping installed incorrectly.	Check piping per Steam Installation Instructions.
	Trap not functioning.	Check trap for size and capacity. If dirty and sluggish, clean thoroughly or replace. Check return line for high back pressure, or another trap charging against the trap functioning improperly.


Direct-Spark Ignition Operation

DIRECT SPARK IGNITION OPERATION

NOTE: Some models are equipped with a dual ignition system. The dual ignition system contains two Direct Spark Ignition modules in parallel. Each module has its own Flame Sense circuit and acts independently of the other. If either Bonnet Limit Thermostat opens because of high heat or flame impingement, the entire ignition system will shut down.

1. When a call for heat is received from the control supplying 24VAC to the Ignition Control Module, the pre-purge delay timer begins. This delay time allows any air/sediment to be ejected prior to burner ignition. Following the pre-purge delay period, the gas valve is energized and the spark ignitor sparks for the trial for ignition period.
2. When a flame is detected during the trial for ignition period, the spark ignitor shuts off and the gas valve remains energized.
3. If no flame is detected by the Flame Sense Circuit, the Ignition Control Module will go into safety lockout. The valve will be turned off immediately. If the module has multiple retries and no flame is detected, the gas valve is de-energized and the module goes into an interpurge delay. After this delay, the module will attempt another trial for ignition period. This will continue until the number of retries has been used up. At that time, the module will go into safety lockout.
4. Recovery from safety lockout requires one of the following:
 - a. A manual reset by opening and closing the loading door.
 - b. After one hour if the Control Thermostat is still calling for heat, the module will automatically reset and the trial for ignition period will start over.
5. Opening the loading door will cause the flame to extinguish. Closing the door and starting the dryer will restart the trial for ignition period.
6. Once the Control Thermostat has been satisfied and/or the Drying Timer has been timed out, the Ignition Control Module(s) will be de-energized, the gas valve(s) will be de-energized and the flames will extinguish.
7. The machine will continue to run in a cooldown mode without heat. This process will cool the load to the touch and help to eliminate wrinkling.

**DIRECTSPARK
IGNITION OPERATION
FLOWCHART**



Maintenance—General


MAINTENANCE

MAINTENANCE

1. **CLEAN LINT TRAP DAILY.** Remove lint before starting day's operation. A clean lint trap will increase the efficiency of the dryer, as the moisture-laden air will be exhausted more quickly.
2. **CLEAN BASKET AND SWEEP SHEETS.** Clean periodically and/or as often as required. The basket and sweep sheets are easily accessible by removing the front panel of the dryer.
3. **GEAR REDUCER.** Maintain the correct oil level. See separate page on Gear Reducer Operation and Maintenance, for detailed information.
4. **PULLEYS AND BELTS.** Keep belts clean. Oil and dirt will shorten the useful life of the belt. Never allow a belt to run against the belt guard. Check periodically for alignment. Pulley shafts must be parallel and the grooves must be aligned. Check and re-tighten pulley set screws periodically. Check belt tension periodically. Lower motor to increase tension by adjusting the nuts fastening the motor plate to the rod connected to the Gear Reducer.
5. **ELECTRIC MOTORS.** Keep motors clean and dry. Motors having ball bearings are packed with sufficient grease for approximately five years of normal operation. After five years, the bearings and housing should be cleaned thoroughly. Repack each bearing and the cavity in back of the bearing one-third full with Chevron Grease No. SR1-2.
Motors having wool packed sleeve bearings are oiled at the factory for one year of normal operation. After one year, add annually one-half teaspoon of electric motor oil or S.A.E.#10 to each bearing. For 24 hour per day operation, add one teaspoon of oil annually.
If motors overheat, check voltage and wiring. Low voltage, inadequate wiring, and loose connections are the main cause of motor failure.
6. **STEAM HEATING UNITS.** Keep steam coils clean. Check periodically and clean often, as required. Remove lint and dirt build-up from fins. Dirty fins decrease the efficiency of steam heated units.
7. **GAS BURNERS.** Keep burners clean. Check periodically and clean often.
8. **EXHAUST SYSTEM.** Periodically check and clean.
9. **CLEAN OUT PANEL.** (Energy Saver Gas Models) Remove this panel, located on the heating unit, and clean the inside area of lint and dirt on a regular basis.
10. **DRYER AREA.** Keep dryer area clean and free from combustible materials, gasoline and other flammable vapors and liquids.
11. **MAKE-UP AIR.** Do not obstruct the flow of combustion (make-up) air and ventilating air.
12. **GAS PRESSURE.** Periodically check gas pressure.
13. **DRYER VOLTAGE.** Periodically check dryer voltage per dryer Rating Plate.

Burner Air Inlet Adjustment (with Illustration)

**BURNER AIR INLET
ADJUSTMENT**



Basket Alignment for 125 lb. Dryers (Illustrations)






FIG. 2

Basket Alignment for 125 lb. Dryers

**INSTRUCTIONS FOR
ALIGNING BASKETS ON
125 LB. DRYERS**


INSTRUCTIONS

1. Loosen bolts number one (1) through five (5).
2. Place pin “A” in position shown in figures 1 and 2.
3. Check pins “B” at position shown in figures 1 and 2 for equal clearance.
4. If pin “B” clearance is unequal, adjust at nut #6.
5. When clearance at pin “B” is correct, tighten bolts #1 in the following order, as viewed from rear of dryer, top right, bottom left, top left and bottom right.
6. Tighten bolts #5 until flush against back of dryer. Tighten lock nut #4 to secure bolt #5 in position.
7. Tighten bolts #2 and #3.
8. Remove pin “A” and check for proper clearance at points “A” and “B”. If clearance is incorrect, repeat the above steps.

NOTE

Use short sections of round steel rod for pins or drill bits may be used in place of round rod.

Shimming the Basket and Spider Assembly



INSTRUCTIONS FOR SHIMMING THE BASKET AND SPIDER ASSEMBLY

This procedure is normally necessary when replacing either the basket or the spider assembly on any dryer. The alignment of these two parts is crucial in assuring a true running basket.

- A. Align the basket as per instructions on the previous page.
- B. Rotate the basket to determine where the most out-of-round point is (where the basket scrapes or comes closest to scraping the sweep sheet).
- C. Mark this position and the nearest rib to this position. If it is between two ribs, both ribs may need to be shimmed.
- D. Remove the basket from the dryer (do not loosen the alignment bolts).
- E. With the basket on the floor (spider up), loosen the cap screws and tie rod nuts enough to insert one or two shims between the spider leg and the basket at the marked position. With shims in place, tighten the screws and nuts.
- F. Install spider and basket assembly and check again.
- G. If basket is still out-of-round, start at *Step B* and repeat procedure.
- H. When shimming is completed, re-align basket.




FIG. 3

$\frac{3}{4}$ " (20 mm)




FIG. 1




FIG. 2

AIRSWITCH ADJUSTMENT

1. Shut off current; disconnect leads and remove air switch.
2. Lay air switch assembly on flat surface. Adjust air blade at "A" (figure 1) so that air blade lays flat and surface "B" is parallel to the flat surface.
3. Place $\frac{3}{8}$ " x $\frac{5}{8}$ " (10 mm x 16 mm) spacer bar or equivalent "C" (figure 2) under air blade in position shown; hold switch mounting bracket firmly and adjust switch actuator "D" with needle nose pliers at "E" by twisting actuator right or left, whichever is needed, so that switch closes when end of air blade engages bar "C".
4. Maximum opening of air switch must be no greater than $\frac{3}{4}$ " (20 mm) (figure 3). Bend tab "F" in or out to maintain this dimension.
5. Re-install air switch assembly on rear of dryer.
6. Re-check operation of air blade. Switch must close before air blade engages face of opening and re-open before stop "F" engages.

Dryers with Reversing Control Timer

INSTRUCTIONS FOR DRYERS WITH REVERSING CONTROL TIMER

Instructions

In operation, coasting of basket increases, making it necessary to readjust reversing timer.

CAUTION

Failure to do this will cause the thermal overload units for the basket to cut-out unnecessarily and probably damage the gear reducer.

Adjustment of Reversing Timer Dwell Time

CAUTION

Dryer power supply must be shut off before adjusting timer.

The dwell time is the time from when the motor turns “off”, to when it turns “on” again in the opposite direction.

Turning the dwell adjustment knob counter-clockwise increases the dwell time and turning it clockwise decreases the dwell time.


Recommended dwell time for the basket to stop completely is 5 to 7 seconds. Minimum basket stopping time is 4 seconds.

NOTE

Select non-reversing or reversing before starting dryer.

NOTE

Fan rotates counter-clockwise as viewed from back end of motor. See arrow on motor support. to change rotation, reverse power leads L1 and L2.



**INSTRUCTIONS FOR
DRYERS WITHOUT
REVERSING CONTROL
FAN AND BASKET
ROTATION**

Instructions

NOTE

Fan rotates counter-clockwise as viewed from back end of motor. See arrow on motor support.

Basket rotates counter-clockwise as viewed from back end of motor. See arrow on motor support.

Basket rotates clockwise as viewed from front of tumbler.

To change rotation of both fan and basket, reverse power leads L1 and L2.

To change rotation of fan only, reverse motor leads F1 and F2.

To change rotation of basket only, reverse motor leads B1 and B2.

Large Gear Reducer Maintenance

**LARGE GEAR REDUCER
MAINTENANCE**

LARGE GEAR REDUCER MAINTENANCE


Before placing the dryer in operation, check the oil level. If the oil level is correct, it can be checked by removing the fill overflow plug on the right hand side of the gear reducer (facing rear).

If oil must be added, remove the pop-off valve at the top of the gear reducer and add as needed.

CHANGE OIL ONCE EVERY 6 MONTHS.

WARNING:
Oil level shall not exceed 52 oz.
Please drain oil to oil level plug if required.

125 lb. Laundry Dryer (Front Exploded View) (Illustration)




Parts—125 lb. Laundry Dryer (Front Exploded View)

1	TU8013	Cissell Nameplate	34	VSB134	3/8" Lockwasher (Pkg. of 6)
2	TU5739	Support Rod	35	IB140	3/8" Cut Washer
*3	TU14157	Access Panel	36	TU6854	#14 x 3/4" Screw
4	TU5674	Control Box Brace	37	LB74	#14 Speed Nut without Barbs
5	TU7159	Left Control Box		TU7848	#14 Speed Nut with Barbs
6	TU14056	Right Control Box	38	TU3801	Push On Speed Nut
7	TU13803	Jacket Weldment	39	TU2662	1/2" - 20 x 1 1/2" Cap Screw
8	TU5302	Gasket Set	40	TU2664	5/8" - 18 x 1 1/2" Cap Screw
9	TU2486	Thermostat Bracket	41	OP251	1/2" Lockwasher
10	TU2477	Thermostat	42	TU5801	5/8" Lockwasher
11	TU5337	Thermostat Bulb Support	43	F557	#10 - 24 x 3/8" Screw
12	F646	5/16" Clamp	44	FB187	#10 Lockwasher
13	TU5290	Felt Seal	*45	TU7804	Lint Door (with Insulation), Handles, and Hardware
14	K109	Spider "C" and "F"	46	TU9975	Basket Shaft Key
	K348	Spider "K" and "R"	47	TU490	Thermostat Knob (Fahrenheit)
15	TU5397	Outside Rib Plate		TU491	Thermostat Knob (Centigrade)
16	TU6469	Basket "C" and "F"	48	K169	Handle Assembly
	K421	Basket and Spider "C" & "F"	49	TU6025	Cam Stop
17	TU10345	Lint Screen Hood	50	TU3811	Cam
18	TU7473	Door Handle	51	TU6159	Support Clips
19	K368	Lint Screen ONLY	52	TU14025	Reset Button Assembly
	K121	Wire Frame ONLY	53	TU9209	Snap Bushing
*20	TU13807	Front Panel & Door Assy.	54	RC349	1/4" Lockwasher
21	TU6030	Temperature Control	55	TU7719	Conduit Channel Cover
22	TU1979H	Door Switch	56	TU8036	Left Control Box Shield "C"
24	TU1771	#6 Twin Speed Nut (Pkg. of 12)	57	TU6160	Lint Screen Clip
25	TU3219	#6 x 1" Screw	58	TU11568	Door Trim
26	TU2373	Mounting Bracket	59	TU13629	Cable, Hi-Voltage DSI
27	TU7733	#8 x 1/2" Screw (Pkg. of 6)	60	TU13409	Spark Ignition Mount, 3-Trial (Gas only)
28	TU3479	#10 - 32 x 7/16" Truss Screw		TU13627	Spark Ignition Mount, 1-Trial (Gas only)
29	FG343	Screw Fastener			
30	FG345	Retaining Washer			
31	P104	1/4" Cut Washer (Pkg. of 6)			
32	TU2842	#10 - 32 Hex Nut (Pkg. of 6)			
33	TU3246	3/8" - 16 x 1" Hex Head Screw (Pkg. of 6)			

*** Specify Color**

125 lb. Dryer (Double Motor Models) (Illustration)



Parts—125 lb. Laundry Dryer (Double Motor Models)

1	TU4934	1/4" - 20 x 7/16" Hex Nut (Pkg. of 6)	26	500300644	Junction Box
2	FB189	1/4" - 20 x 1" Hex Head Screw	27	TU7517	Basket Shaft Cover
3	TU8206	Air Switch**		TU10732	Prompter Housing Assembly**
4	CFB3000	1/2" Greenfield Cable - 30"	28	TU7131	3/4" Straight Connector
5	TU3806	Gear Sheave	29	SB170	Junction Box Cover
6	TU3807	Sheave Bushing	30	TU13803	Jacket Welded Assembly
7	TU5668	Outside Belt Guard	31	TU14057	Key
8	TU2363	"V" Belt 5L500	32	TU7733	#8 x 1/2" Self Drinning Screw (Pkg. of 6)
9	TU2832	Motor Sheave 60 Cy.	33	RC347	1/2" - 13 x 1 1/4" Hex Head Cap
	TU6081	Motor Sheave 50 Cy.	34	TU2831	1/2" Split Lockwasher (Pkg. of 6)
10	TU2833	Sheave Bushing	35	TU1851	1/2" Flat Washer
11	TU9615	Belt Guard Welded Asm.	36	TU2195	1/2" - 13 x 1 3/4" Hex Head Cap Screw (Pkg. of 6)
12	TU470	Large Hex Nut (2 required)	37	TU455	Cam Adjustment Nut
13	TU6633	2-3/4" O.D. x 1- 13/32" I.D. x 3/4" Thick Washer	38	TU3575	7/8" Internal Tooth Lockwasher
14	TM200	Gear Reducer**	39	TU5312	3/8" - 16 x 3" Square Head Set Screw
15	TU5328	Belt Adjusting Rod	40	TU4787	3/8" - 16 Hex Nut (Pkg. of 6)
16	TU4626	Basket Motor Mount Asm.	41	TU5439	5/16" - 18 x 3/4" Hex Head Cap Screw (Pkg. of 6)
*17	TU5658	Motor and Fan Mount (60 Cycle)	42	TU2814	5/16" Split Lockwasher (Pkg. of 6)
18	TU2473	Self-Sticking Gaskets (2 sets required)	43	C249	5/16" - 18 Hex Nut (Pkg. of 6)
*19	TU403	Fan Wheel (50 Cycle)	44	TU2831	3/8" Split Lockwasher (Pkg. of 6)
19A	TUX220	Fan Wheel (60 Cycle)	45	TU108	Felt Seal
20	TU4791	90 Degree Angle Connector	46	F1116	Serial No. Nameplate
21	TU2372	Snap Bushing	47	CFB0650	1/2" Greenfield Cable (specify 6 1/2")
22	CFB2800	1/2" Greenfield Cable (specify 28")	48	TU2846	1/4" Split Lockwasher (Pkg. of 6)
23	TU6026	Top Motor Conduit	49	TU2847	1/4" Flat Washer (Pkg. of 6)
24	TU6027	Back Motor Conduit	50	TUX415	Air Switch Box
25	TU5507	Blanking Plate "C" Model (Steam Only)	51	TU8206	Air Switch Assembly


* For 50 Cy. Motor Mount Assembly

** See separate page for parts breakdown

CAUTION

Grease to be applied to all bearing shafts, #42-032-6015 grease Lubriplate #310, 1 lb. cans OR 14 1/2 ounce tubes - Lubriplate No. 930-2, multi-purpose grease #10098.

Front Panel and Door Assembly (Illustration)




***TU13807 Front Panel Assembly w/Door**

1	TU7862	Door Glass 20 - 1/4"	16	TU2686	#8 - 32 x 3/8" Phillips Head Screw
2	TU7169	Door Glass Gasket	17	TU2836	5/16" - 32 x 3/8" Hex Head Screw
3	TU5503	Door Latch Spacer	18	TU3212	5/16" I.T. Lockwasher
4	TUA2319H	Door Latch with Keeper	19	TU3209	#14 x 5/8" Pan Head Screw
5	TU14483	Door (specify color)	20	TU4839	#10 - 32 x 3/8" Hex Head Screw
6	TU2236	Hinge Post	21	TU4840	#10 - 32 Crown Nut
7	TU5288	Door Seal	22	RC347	1/4" Lockwasher
8	TU13809	Front Panel		*TU7856	Door w/Plain Glass Assy. (Parts 1-5)
9	TU2641	Thermometer Gasket		*TU9318	Door w/Solid Panel Assy. (Parts 3-5)
10	TU5458	Temperature Label			
11	TU10673	Insulation			
12	TU7858	"Clean Lint Compartment" Nameplate			
13	PIF172	Hinge Post Bearing			
14	TU2687	#8 - 1/2" Phillips Head Screw			
15	TU3785	#8 Cup Lockwasher			

* Specify Color


Thermostat Assembly (Illustration)



TU6030 Front Panel Assembly w/Door


- | | | |
|---|---------|--|
| 1 | TU5530 | Mounting Bracket |
| 2 | TU1980 | Thermostat |
| 3 | TU3593 | Thermometer |
| | TU3816 | Lens Replacement (Texas Gage ONLY) |
| | TU8475 | Lens Replacement (Marshalltown Inst. ONLY) |
| | TU11193 | Lens Replacement (Weiss—consult factory) |
| | TU13213 | Lens Replacement (Weiss—consult factory) |
| 4 | TU490 | Thermostat Knob (Fahrenheit) |
| | TU491 | Thermostat Knob (Cnetigrade) |
| 5 | TU3209 | #14 x 5/8" S.M.S. |
| 6 | TU7848 | #14 Tinnerman Clip |

**AIR SWITCH ASSEMBLY (Gas Only)
TU8206**




- | | | |
|---|--------|------------------------------------|
| 1 | F888 | "E" Ring |
| 2 | TU2463 | Actuator Arm |
| 3 | TU3476 | Air Switch Decal |
| 4 | TU1771 | #6 Tinnerman Nut |
| 5 | TU8155 | Air Switch |
| 6 | TU1770 | Insulator |
| 7 | TU8171 | Air Switch Bracket |
| 8 | TU7733 | #8 - 18 x 1/2" Self Drilling Screw |
| 9 | TU3219 | #6 x 1" Round Head S.M.S. |

Reversing Control Panel Assembly (TU14146)




1	TU12874	Timer, Solid State Reversing
2	TU13480	Transformer 200-240V/24V w/Reset
	TU13514	Transformer, 480/24V w/Reset
3	F540	#6 x 5/8" Phillips Head Screw
4	TU13516	Contactors, 24V
5	TU13526	Contactors Assembly, 24V
6	TU14026	Motor Control Plate
7	WH1797	Wire Harness
8	TU7733	8 - 18 x 1/2" Self-Drill Screw (Pkg 6)

TU13859 - Permanent Press Control Panel Assembly




1	FG147	Toggle Switch	9	TU3805	Hex Nut
2	TU9028	Push Button Switch	10	TU13825	Control Panel
3	TU12933	Timer (0-15 Minutes)	11	TU12932	Timer (0-60 Minutes)
4	TU13620	Control Panel Weldment	12	TU3479	Pan Head Machine Screw
5	TUT316	LED	13	13FB187	#10 Split Lock Washer
6	TU7733	#8 - 18 x 1/2" Self-Drill Scr.	14	P104	1/4" Brass Washer
7	TU2555	Knob Assembly	15	TU2842	#10 - 32 Hex Nut (Pkg 6)
8	ET208	#6 - 32 x 1/4" Binding Head Screw	16	TU13621	Control Box Timer Assy
			17	F325	Terminal Block

Moisture Control Panel Assembly - TU14253



1	C196	#8-32 x 5/16" Socket Set Screw	14	TU13646	24V Coil Relay
2	ET208	6-32 x 1/4" Binding Head Scr.	15	TU14251	Front Panel 125# ICC
3	FG147	Toggle Switch	16	TU2555	Knob
4	FG343	Steel Screw	17	TU2842	10-32 Hex Nut (Pkg. 6)
5	FG345	Steel Washer	18	TU3479	10-32 x 7/16" Machine Screw
6	PT118	M/C Knob	19	TU3805	15/32-32 Hex Lock Nut
7	P104	1/4" Brass Washer (Pkg. 6)	20	TU7733	#8-18 x 1/2 Self-Drill Screw
8	TUT316	24V LED Light	21	FG325	Terminal Block
9	TU12932	Timer (0-60 Min.) Drying	22	TU9347	PC Board Support
10	TU12933	Timer (0-15 Min.) Cooling	23	TU9028	Push Button Switch
11	TU13229	24V Humidity-Based Controller	24	TU3243	3/8" Int. Tooth Lockwasher
12	TU13345	DPDT Switch	25	FB187	#10 Split Lockwasher
13	TU13620	Timer Control Weldment			

Parts—TM200—Large Gear Reducer with Bronze Teeth




1	TM203	Housing	10	VSB134	3/8" Split Lockwasher (Pkg. of 6)
2	K474	Oil Level Plug Kit	11	TU3246	3/8" - 16 x 1" Cap Screw (Pkg. of 6)
3	TM119	1/4" Vent Plug	12	TM217	Large Bearing Cone & Cup
4	TM208	Small Bearing Cone & Cup	13	TM220	Large Klozure
5	TM225	Worm & Worm Gear	14	TM221	1/4" Pipe Plug
6	IB139	3/8" - 16 x 1 1/4" Cap Screw	15	TU5312	3/8" x 3" Set Screw
7	TM205	Small Open End Cap	16	TM211	Large End Cap 10 1/2 Dia.
8	TM204	Small Klozure	17	TM212	Small End Cap 6 3/4 Dia.
9	TM218	Small Closed End Cap			

TM225 Worm and Worm Gear Set (for TM200 ONLY) (only sold as set)


Not Illustrated—TU3465 one pint of Cissell Transmission Oil

Gas Bonnet Assembly




1	TU9614	Gas Manifold	12	TU4606	3/4" x 4" Nipple
2	CB36	1/4" - 20 x 1/2" Hex Head Screw	13	TU4934	1/4" - 20 Hex Nut (Pkg 6)
3	OP267	3/4" x 1/2" Steel Bushing	14	TU13823	3/4" x 36" Nipple
4	PT196	3/4" Strap	15	TU3539	Burner Orifice
5	RC344	1/4" - 20 x 3/4" Hex Head Screw	16	TU4606	1/4" Lock Washer (Pkg 6)
6	TUX387	BSI Asm. Burner	17	TU2224	1/8" Pipe Plug
7	TUX352 TUX435	3/4" Natural Gas Valve 3/4" LP Gas Valve	18	TU13678	Thermostat, Man. Reset 300°
8	TU10946	Pipe Plug	19	TU2226	Manifold Mounting Bracket
9	TU13613	Bonnet Assembly	20	TU7733	#8 - 18 x 1/2" Self-Drill Screw (Pkg. of 6)
10	GA-00764-0	Direct Spark Ignition Electrode	21	TU13695	Bonnet Thermostat Bracket
11	TU4605	3/4" Elbow	22	TU13647	Mounting Bracket

TU14001—Steam Bonnet (14FPI) (Illustration)




1	TU7393	Top Plate	13	TU4608	3/4" x 2" Nipple
2	TU3209	#14 x 5/8" Sheet Metal Screw (Pkg. of 6)	14	TU4610	3/4" x 5" Nipple
3	TU6080	Air Filter (4 required)	15	TU4600	3/4" Union
4	TU13936	Steam Coil (14FPI)	16	TU4620	3/4" x 4 1/2" Nipple
6	LB74	#14 Speed Nut	17	TU4597	3/4" Tee
7	TU8083	Bonnet Weldment	18	TU5914	3/4" x 3 1/2" Nipple
10	TU2846	1/4" Lockwasher (Pkg. of 6)	19	TU13517	Solenoid Valve (24V)
11	TU4934	1/4" - 20 x 7/16" Hex Nut (Pkg. of 6)	20	390401031	3/4" x Close Nipple
12	TU4605	3/4" Elbow	24	FB189	1/4" - 20 x 1" Hex Head Screw
			25	TU5726	Rear Coil Holder

TU13691—24V Steam Bonnet (4 Coil) (Illustration)



1	TU7393	Top Plate	12	TU4605	3/4" Elbow
2	TU3209	#14 x 5/8" Sheet Metal Screw (Pkg. of 6) (4 each)	13	TU4608	3/4" x 2" Nipple
3	TU6458	Air Filter (4 required)	14	TU4610	3/4" x 5" Nipple (3 each)
4	TU1699	Steam Coil (4 Coil) (2 each)	15	TU4600	3/4" Union
5	TU4790	1/2" Angle Connector	16	TU4620	3/4" x 4 1/2" Nipple
6	LB74	#14 Speed Nut (4 each)	17	TU4597	3/4" Tee (2 each)
7	TU8082	Bonnet Weldment	18	TU5914	3/4" x 3 1/2" Nipple
8	CFB7200	Greenfield Cable 72"	19	TU13517	Solenoid Valve 24V
9	TU4790	1/2" Straight Connector	20	TU5431	Bushing
10	TU2846	1/4" Lockwasher (Pkg. of 6) (2 each)	21	FB189	1/4" - 20 x 1" Hex Head Screw (2 each)
11	TU4934	1/4" - 20 x 7/16" Hex Nut (Pkg. of 6) (2 each)	22	TU5726	Rear Coil Holder

TU13692—24V Steam Bonnet (6 Coil) (Illustration)



1	TU7393	Top Plate	12	TU4605	3/4" Elbow
2	TU3209	#14 x 5/8" Sheet Metal Screw (Pkg. of 6) (4 each)	13	TU4608	3/4" x 2" Nipple (3 each)
3	TU6080	Air Filter (4 required)	14	TU4610	3/4" x 5" Nipple
4	TU2808	Steam Coil (6 Coil) (2 each)	15	TU4600	3/4" Union
5	TU4791	1/2" Angle Connector	16	TU4620	3/4" x 4 1/2" Nipple
6	LB74	#14 Speed Nut (4 each)	17	TU4597	3/4" Tee (2 each)
7	TU8083	Bonnet Weldment	18	TU5914	3/4" x 3 1/2" Nipple
8	CFB7200	Greenfield Cable 72"	19	TU13517	Solenoid Valve 24V
9	TU4790	1/2" Straight Connector	20	TU5431	Bushing
10	TU2846	1/4" Lockwasher (Pkg. of 6) (2 each)	21	FB189	1/4" - 20 x 1" Hex Head Screw (2 each)
11	TU4934	1/4" - 20 x 7/16" Hex Nut (Pkg. of 6) (2 each)	22	TU5726	Rear Coil Holder

