

# **Operating and installation manual**

## **Tumble dryer TT200 / TT270**

**El, Steam  
(RMC)**

487 14 49 51

 **Electrolux**

---

**Wascator**

# Tumble Dryer, drum volume 200/270 litres

---

## Contents:

### Instructions for use:

General aspects .....	1
Explanation .....	2
Operation, manual residual moisture control.....	3
Maintenance .....	4

### Installation:

Positioning .....	5
Dimension sketch, electric heating .....	6
Dimension sketch, hot water/steam heating.....	7
Wiring .....	8
Evacuation system .....	9
Examples of evacuation system .....	10
Technical data, electric heating .....	11
Technical data, hot water/steam .....	12
Left-/right-hung door .....	13
Function controls .....	14
PCB (printed circuit board), setting.....	15
Quick-view parameter listing .....	16
Parameter programming, residual moisture control .....	17
Parameter programming, changing parameters.....	18-19
Error codes .....	20

## Safety Instructions

**This machine is intended for drying water-washed garments alone.**

**The machine is not to be used for drying foam rubber or materials similar to rubber.**

**The machine is not to be used by minors.**

**The machine is not to be washed down with water.**

**Mechanical and electrical installation work are only to be performed by authorized personnel.**


**In the case of machine fault, this is to be reported to the person in charge as soon as possible. This is important for your own safety and for the safety of other users.**

**Remember that such textiles as silk and wool  
are not to be dried in the tumbler.**

The manufacturer reserves the right to alter design and material specifications.

## Drying is effected as follows:


- The tumbling drum (1) rotates at constant speed in order to keep the garments in movement all the time.
- An inbuilt fan (2) carries fresh air through the machine.
- The air first passes the heating unit (3), where it is heated.
- The air is then sucked into the drum via the perforation at the back wall. It absorbs the humidity in the garments and leaves the drum via the perforation at the front of the drum.
- Next the air passes a filter (4) which collects lint and dust. The air is conducted out of the room via the fan and the vent pipe system.











## Explanation

### Manual residual moisture control

- A. Program selector
- B. Temperature symbols
- C. Lamp is lit for selected program
- D. Start button
- E. Lamp flashes / ready to start
- F. Drying / lamp is lit
- G. Cooling / lamp is lit
- H. Drying time completed / lamp is lit
- I. Filter / lamp is lit: Clean filter
- J. Display indicates drying time when time controlled is selected.
- K. Timer buttons for desired drying time, one press = one minut
- L. Select residual moisture program by pressing one of the following buttons:
  1. Extra dry
  2. Storage dry
  3. Iron dry for iron
  4. Iron dry for ironing machine



## Manual operation with residual moisture control


<h1>1</h1>	<p>Open filter door. Clean filter. Close filter door ➡.</p> 	<p>Open filling door. Fill garments into drum. Close door ➡.</p> 	
<h1>2</h1>	<p><b>Select drying program.</b> Press program button. Lamp is lit for selected program.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p><b>Airing.</b> without heat.</p> <p><b>Mild wash.</b> Low heat.</p> <p><b>PP / normal wash.</b> Normal heat.</p> <p><b>Residual moisture</b> Extra dry</p> <p>Storage dry</p> <p>Iron dry (iron)</p> <p>Iron dry (machine)</p> </div> </div> <p><b>Select either</b> <b>Time controlled</b> <i>or</i> <b>Residual moisture</b></p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p><b>Time control</b> one press = one minut</p> </div> <div style="text-align: center;">  </div> </div>		
<h1>3</h1>			
<h1>4</h1>	<p><b>Drying program:</b></p> <p>Airing without heat Mild wash, low heat PP / normal wash, normal heat</p>	<p><b>Drying time:</b> Set timer to:</p> <p>c. 10 min. c. 25 min. c. 25 min.</p> <p><b>Residual moisture:</b> Automatic program with the following options: Extra dry Storage dry Iron dry (for iron) Iron dry (for machine)</p>	
<h1>5</h1>	<p><b>Start:</b> Press start button.</p> 	<p><b>Stop:</b> The tumbler can always be stopped by opening the door. <b>Re-start:</b> Close door and press start button.</p>	<p><b>The tumbler stops automatically:</b> <b>Time controlling:</b> - when the drying time has expired <b>Residual moisture:</b> - When the selected has been obtained.</p>
<h1>6</h1>	<p>In order to <b>prevent garments from creasing:</b> Empty tumbler immediately. ➡.</p> 	<p><b>Anti-crease program ➡.</b></p> <p>After the drying time has ended, the drum rotates at short intervals until door is opened. Max. 1 hour.</p>	

## Maintenance

The following work should be carried out at regular intervals at a rate depending on the frequency of use.

### Daily

- Check that the drum stops when the door is opened.
- Check that the lint screen has been cleaned. The lint screen is to not be removed for cleaning; just clean it with a soft brush or your hand.
- Check that the lint screen is unbroken.
- Check that the machine will not start until the start button has been activated.
- Check that the door glass is unbroken.



### Every quarter / half year

- Check that the fresh-air intake at the back of the tumbler is not clogged by lint or in any other way.
- Check that the vent system is tight and not clogged by lint/dust or in any other way.
- On machines with residual moisture automatic, the lifters in the drum should be cleaned with a sponge at least once every three months.

### Annually

- Check that the fresh-air intake to the room and the vent ducts/pipes in and from the room are not clogged by lint/dust or in any other way.  
Clean as required - depending on the frequency of use. Minimum once a year.
- At least once a year the inside parts of the machine should be checked by a competent, skilled person and cleaned for lint.

## Installation

### Unpacking


Unpack the machine from its packaging.  
There are no transport fittings.

### Positioning

Place the tumble dryer in such a manner that the work of both user and service technician becomes as easy as possible. The door is reversible (page 13).

Fig. The distance from the wall or other equipment behind the machine should be at least 500 mm; distance on the sides at least 10 mm. Please note that for the purpose of servicing there should be access to the back of the machine.

①




### Mechanical installation

Fig. Adjust the machine to make it horizontal - and stable on all four feet.

②

The max. height adjustment of the feet is 50 mm.

When adjustment has been completed, lock the feet with the lock nuts.




### Installation onboard ship

Fig. The 4 accompanying fittings can be used to secure the machine.



③

Secure the fittings to the base with four M10 set screws.



Dimension sketch



Electric heating



Drum volumen litres	A mm	B mm	C Exhaust
200	769	614	Ø 160
270	995	769	Ø 200



Dimension sketch  
Hot water/steam heating  
HW/IS



Drum volumen litres	Heating	A mm	B mm	C Exhaust
200	HW/hot water	1050	614	Ø 160
270	IS/steam	1205	769	Ø 200

## Electrical installation

To be carried out by a skilled, competent person.  
The tumble dryer requires its own fuse group.

Fig. For each tumbler, place a multi-pole fixed switch in the fixed installation. Place it in such a way that it is easily accessible but will not be mistaken for the tumbler main switch.

4


The motor has an inbuilt thermo-fuse, which is why motor protection is not required in the installation.

Fig. Remove the top cover from the tumbler in order to connect the cable. Set up the tumbler as a fixed installation. See dimensions in the table below.

5

Before remounting the top cover: Check the direction of rotation. See function checks, page 14. If the drum rotates in the wrong direction, switch 2 phases.

**The tumble dryer must be provided with extra protection in accordance with relevant regulations.**



5

### Cable dimensioning table

Drum volumen	Voltage	Power input	Heating lead	Connecting Dimension	Fuse
200 liter	400-440V 3N/3 50/60 Hz	9.5 kW	EI 9.0 kW	5/4 × 2.5 mm <sup>2</sup>	16A
200 liter	400-440V 3N/3 50/60 Hz	12.5 kW	EI 12.0 kW	5/4 × 4.0 mm <sup>2</sup>	20A
270 liter	400-440V 3N/3 50/60 Hz	14.0 kW	EI 13.5 kW	5/4 × 4.0 mm <sup>2</sup>	25A
200 liter	200-208V 3 50/60 Hz	9.5 kW	EI 9.0 kW	4 × 10.0 mm <sup>2</sup>	35A
200 liter	230-240V 3 50/60 Hz	9.5 kW	EI 9.0 kW	4 × 6.0 mm <sup>2</sup>	25A
200 liter	208-240V 3 50/60 Hz	12.5 kW	EI 12.0 kW	4 × 10.0 mm <sup>2</sup>	35A
270 liter	230-240V 3 50/60 Hz	14.0 kW	EI 13.5 kW	4 × 16.0 mm <sup>2</sup>	63A (50A)
200/270 liter	400-440V 3N/3 50/60 Hz	0.5 kW	Hot water/Steam	5/4 × 1.5 mm <sup>2</sup>	10A
200 liter	230-240V 1N 50 Hz	6.6 kW	EI 6.0 kW	3 × 10.0 mm <sup>2</sup>	35A

Machines marked 230V or 400V (new European voltage as per IEC 38) can be connected to 220V or 380V mains plugs without any problems.

## Evacuation system

### Fresh air intake

Fig. 7 In order for the machine to work optimally, with the shortest possible drying time, it is **important** for the air intake to the room to come from the open air and for the same amount of air as enters the room to be evacuated. In order to avoid draught in the room, it is best to place the air intake behind the machine. See example on Fig. 7. The area of the air intake opening must be 5 times the area of the evacuation pipe. The resistance in the damper / slatted shutter must not exceed 10 Pa (0.1 mbar). The air consumption is shown in the table. (Fig. 9).

### Evacuation pipe / duct

It is recommended to connect each machine to a separate, smooth-faced evacuation pipe with as low air resistance as possible.

The pipe must lead to the outside and be protected against rain and impurities. The length of the evacuation pipe is given in metres.



For each 90° bend - add 2 metres.

For each 45° bend - add 1 metre.

Fig. 8 Set the damper in accordance with the table, ensuring that the optimal efficiency is obtained.

Fig. 9 Lengths and dimensions can be seen from the table.



If in doubt with regard to the design of an evacuation system, please do not hesitate to contact our service organisation / dealer.



9

Hz	Type in litres	Heating	Air consumpt.	Static pressure	Diameter of evacuation pipe	Setting of damper scale to match different pipe lengths			
						0-15 m	15-30 m	30-60 m	60-100 m
50	200	6,0 kW	300 m³/h	190 Pa	160 mm	1	1	1-2	2-3
	200	9,0 kW	360 m³/h	200 Pa	160 mm	1	1	1-2	2-3
	200	12,0 kW	525 m³/h	150 Pa	160 mm	2	3	3-4	5
	270	13,5 kW	620 m³/h	120 Pa	200 mm	3	3-4	4-5	5
60	200	9,0 kW	360 m³/h	400 Pa	160 mm	1	1-2	2-3	3-5
	200	12,0 kW	525 m³/h	250 Pa	160 mm	1	1-2	2-3	4-5
	270	13,5 kW	620 m³/h	200 Pa	200 mm	2	2	2-3	3-5

## Examples of evacuation system



## Technical data

### Electric heating

Drum volume			200 liter	270 liter
Dimensions:	Width		792 mm	792 mm
	Depth		769 mm	995 mm
	Height		1508 mm	1508 mm
Weight:	Net		115 kg	130 kg
Drum:	Diameter		760 mm	760 mm
	Depth		440 mm	595 mm
	Drum rotation		42 rpm	42 rpm
	G-factor		0.75	0.75
Capacity:	Factor 1:25		8.0 kg	10.8 kg
	Factor 1:33		6.0 kg	8.2 kg
Motor:	Power	3 phases	2×0.20 kW	2×0.20 kW
		1 phase	2×0.25 kW	2×0.25 kW
	Rotation	50 Hz	2800 rpm	2800 rpm
		60 Hz	3360 rpm	3360 rpm
Heat generation:			6/9/12 kW	13.5 kW
Air consumption:	6.0 kW		300 m³/h	620 m³/h
	9.0 kW		360 m³/h	
	12.0 kW		525 m³/h	
	13.5 kW			
Pipe connection:	Evacuation	6.0 kW	Ø 160	Ø 200
		9.0 kW	Ø 160	
		12.0 kW	Ø 160	
		13.5 kW		
Pressure drop:	Evacuation 50 Hz	6.0 kW max.	190 Pa	120 Pa
		9.0 kW max.	200 Pa	
		12.0 kW max.	150 Pa	
		13.5 kW max.		
	Evacuation 60 Hz	9.0 kW max.	400 Pa	200 Pa
		12.0 kW max.	250 Pa	
		13.5 kW max.		
Sound pressure level :			< 70 dB (A)	< 70 dB (A)

## Technical data

Hot water/steam heating			Hot water	Steam
Drum volume			200 liter	270 liter
<b>Dimensions:</b>	Width		792 mm	792 mm
	Depth		769 mm	995 mm
	Height		1508 mm	1508 mm
<b>Weight:</b>	Net		133 kg	147 kg
<b>Drum:</b>	Diameter		760 mm	760 mm
	Depth		440 mm	595 mm
	Drum rotation		42 rpm	42 rpm
	G-factor		0.75	0.75
<b>Capacity:</b>	Factor 1:25		8,0 kg	10,8 kg
	Factor 1:33		6,0 kg	8,2 kg
<b>Motor:</b>	Power 3 phases		2×0.20 kW	2×0.20 kW
	1 phase		2×0.25 kW	2×0.25 kW
	Rotation 50 Hz		2800 rpm	2800 rpm
	60 Hz		3360 rpm	3360 rpm
<b>Heat generation:</b>			Variabel	Variabel
<b>Air consumption:</b>			360-525 m³/h	620-720 m³/h
<b>Pipe connection</b> Evacuation			Ø 160	Ø 200
<b>Pressure drop:</b>	Evacuation pipe at 50 Hz	Max.	200-150 Pa	120-25 Pa
	Evacuation pipe at 60 Hz	Max.	400-250 Pa	200-25 Pa
<b>Steam connection:</b>				DN 32 BSP 1/4"
Rec. steam pressure:				300-800
Max. steam pressure:				1000
Min. pipe diameter: 100-1000 kPa				DN 20 BSP 3/4"
-100 kPa				DN 25 BSP 1"
<b>Condensate outlet:</b>				DN 32 BSP 1/4"
<b>Rec. diam. of steam trap:</b>	100-1000 kPa			DN 15 BSP 1/2"
	-100 kPa			DN 20 BSP 3/4"
<b>Hot water connection:</b>			DN 32 BSP 1/4"	
Max. water pressure			1000	
Min. pipe diam.			DN 20 BSP 3/4"	
<b>Sound pressure level :</b>			< 70 dB (A)	< 70 dB (A)

## Left-/right-hung door

### Reverse the door as follows:

1. Disconnect the power to the machine.
- Fig. 2. Remove the top cover.
- 10 3. Remove the operating panel with the PCB by removing the 2 multi-plugs, G1 and G2.
4. Remove the lock system, A.




Fig. Remove the 2 leads on the door switch.

- 11 Remove screws B with gaskets and screws C and E (fig.10).

Remove screws D, taking care because the door is now hanging loosely on the front panel (fig. 10).

Fig. 5. Switch cover plate and dust hood.

- 12 6. Move the leads to the opposite side. Be careful with the leads, so that they will not get caught by the drum or when mounting the front panel.
7. Mount the front panel with door in such a way that the hinges are on the opposite side.
8. Mount the lock system, A (must be reversed).
9. Mount the operating panel and the PCB. Insert multi-plugs G1 and G2.
10. Mount the top cover.
11. Connect the machine to the power source and test the machine.



## Function checks, manual

Must be carried out by a skilled, competent person.  
Check that the drum is empty and the door closed.

### Fig. **Before start-up**

**13** Check the direction of rotation by pressing down switch K3. If the drum rotates the wrong way, switch 2 phases.

Fig.

**14** The direction of rotation can be seen from fig. 14.



### **After start-up**

**Check that the safety lock works. The drum must stop when the front door or filter door is opened.**

Let the machine run a program with heating for 5 minutes. Check the heating by opening the front door and checking that there is heat in the drum.

If the above check-points are found to be in order, the tumbler is ready for use.

If faults or deficiencies are found, please contact your nearest service organisation / dealer.






## PCB (printed circuit board), setting of 200/270 -litre machine

The switch setting (variant setting) for the 200/270-litre model.  
The PCB has been preset at the works to match this model.

Only if the PCB is replaced is it necessary to reset.



## Quick-view parameter listing

The following values have been pre-programmed:

Parameter No.	Value / setting	Parameter
01	3.0	Cooling time
02	50	Program with low temperature: 50°C
03	70	Program with high temperature: 70°C
04	90	Maximum running time
05	1	With reversing
06	2.3	Reversing time
07	3	Reversing, pausing time
16	n6	Program: Extra dry
17	0	Program: Dry
18	13	Program: Iron dry (iron)
19	21	Program: Iron dry (flatbed ironer)

A more detailed explanation of the parameter programming can be found on the following pages.

## Applies only to machines with RMC



At the works, the tumbler has been set at a specific value, such as: length of running time per coin, temperature, cooling, reversing, etc.

These different parameters (number of parameters can vary from type to type) can be changed by turning the key switch at the front of the machine (cannot be engaged when the machine is in operation or the door closed).































When engaging the program, always start with parameter 01.

Press the start button (Enter) repeatedly to reach the parameter number to be changed.

When the parameter programming is engaged, the LEDs indicate the current parameter:



# Parameter programming 200/270 litres











Parameters 1-7	LED: On =  Off = 	Value, factory setting	To change : Press button for:
<b>Cool-down time</b> 	 <b>1</b> 	Value = Min. sec. <b>0,0 - 9,6</b> Factory setting: 3,0	 <ul style="list-style-type: none"> <li>Longer time</li> <li>Shorter time</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Temperature 50° (HP = 45°)</b> 	 <b>2</b> 	Value = Degrees C. $\pm 7^{\circ}\text{C}$ Factory setting: 50°C <b>Special factory setting for machine with heat pump (HP)</b> Value : min. 40°C, max. 50°C Factory setting: 45°C	 <ul style="list-style-type: none"> <li>Higher max. 7°</li> <li>Lower max. 7°</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Temperature 70° (HP = 53°)</b> 	 <b>3</b> 	Value = Degrees C. $\pm 7^{\circ}\text{C}$ Factory setting: 70°C <b>Special factory setting for machine with heat pump (HP)</b> Value : min. 50°C, max. 60°C Factory setting: 53°C	 <ul style="list-style-type: none"> <li>Higher max. 7°</li> <li>Lower max. 7°</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Maximum running time per start</b> 	 <b>4</b> 	Value = Minutes <b>15 - 90</b> Factory setting: 40	 <ul style="list-style-type: none"> <li>Longer time</li> <li>Shorter time</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Reversing</b> 	 <b>5</b> 	Value = <b>1 / 0</b> With/without reversing Factory setting: 1 med	 <ul style="list-style-type: none"> <li>With revers. =1</li> <li>W.out revers.=0</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Reversing time</b> 	 <b>6</b> 	Value = Min. sec. <b>0,2 - 9,6</b> Factory setting: 2,3	 <ul style="list-style-type: none"> <li>Longer time</li> <li>Shorter time</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>
<b>Reversing pause time</b> 	 <b>7</b> 	Value = Sec. <b>3 - 20</b> Factory setting: 3	 <ul style="list-style-type: none"> <li>Longer time</li> <li>Shorter time</li> <li>Factory setting</li> <li>Store value/shift to next</li> </ul>

Concerning machines with **Residual moisture control program**:  
Go to parameter 16 (page 19).

# Parameter programming 200/270 litres

19


## Only on machines with residual moisture control

Parameter 16-19	LED: On =  Off = 	Value, factory setting	To change : Press button for:
<b>Residual moisture control</b>  Extra dry	<b>16</b> → 	Value = Residual moisture <b>n9 - 30%</b> Factory setting: <b>n6</b>  n6 = 0% + 6 minutes' extra drying (n1 - n9 = 1-9 minutes)	
<b>Residual moisture control</b>  Dry	<b>17</b> → 	Value = Humidity <b>0 - 30 %</b> Factory setting: <b>0 %</b>	
<b>Residual moisture control</b>  Iron dry	<b>18</b> → 	Value = Humidity <b>0 - 30 %</b> Factory setting: <b>13 %</b>	
<b>Residual moisture control</b>  Iron dry for ironing machine	<b>19</b> → 	Value = Humidity <b>0 - 30 %</b> Factory setting: <b>21 %</b>	

**Note!** Parameters 8 - 15 are not used (with residual moisture control).

## Error codes

The machine features automatic error reporting, shown in the form of flashing error codes.



Error code	Error	What is wrong/what needs doing?
F1	Brown-out	20% reduction of the voltage from the power station: Can be restarted when current returns to normal.
F3	Heating error	Fault on inlet sensor or heating element. Disconnect current for a moment. If the fault repeats itself, call in service.
F4	Outlet sensor	Outlet sensor faulty. Disconnect voltage for a moment. If the fault repeats itself, call in service.
F5	Wrong variant	Wrong combination of switches on the PCB. All lamps go out. Call in service.
F6	Electronic error	Micro-processor error: Call in service.
F7	Service program	Service program illegally engaged: Must only be used with the door open.
F9	Vacuum switch	Vacuum switch fault: Call in service.

Number of error codes can vary from type to type.