

01102010	0298	0	0
Notice	Date	Page	

IM 6431 LFA GAS HEATING
or
IM 6431 FFL/FFS GAS HEATING
or
IM 6431 A GAS HEATING
or
IM 6431 GAS HEATING

Chapters

Characteristics	1
Installation	2
Putting into service	3
Safety devices	4
Machine malfunctions	5
Maintenance	6
Gas heating generalities	7
Electric diagrams for IM 6431 LFA	1/8
Electric diagrams for IM 6431 FFL/FFS	11/8
Electric diagrams for IM 6431 A	13/8
Electric diagrams for IM 6431	14/8

01102010	0298	2	1
Notice	Date	Page	

**LAYOUT FOR IRONER, FOLDER WITH FRONT OR REAR OUTLET
GAS HEATING
KEY TO DRAWING N° 07100041**


BENCHMARKS

- A/** LENGTH OF REAR DELIVERY TABLE
- B/** DRAIN OF VAPOUR DIRECT TO OUTSIDE
- C/** GAS INLET
- F/** ELECTRIC POWER SUPPLY
- G/** OVERALL LENGTH
- H/** COMPRESSED AIR INLET : PRESSURE 8 BAR (CUSTOMER)
- J/** MAIN SWITCH AND ELECTRIC CONNECTION
(EARTH CONNECTION COMPULSORY)
- R/** FRONT VIEW
- S/** SIDE VIEW
- T/** TOP VIEW

t0387gb

dimensions in mm			Gas heating
A	mm		3180
B	inner diameter		160
C	diameter		20/27
F	Amperes	415 V	12
F	Cable section in mm ²	415 V	4 x 2.5
G	mm		3940
H	diameter		15/21

07100042



01102010	0298	4	1
Notice	Date	Page	

**LAYOUT FOR FEEDER, IRONER, FOLDER WITH SIDE DELIVERY
GAS HEATING
KEY TO DRAWING N° 07100042**


BENCHMARKS

- B/** DRAIN OF VAPOUR DIRECT TO OUTSIDE
- C/** GAS INLET
- F/** ELECTRIC POWER SUPPLY
- G/** OVERALL LENGTH
- H/** COMPRESSED AIR INLET : PRESSURE 8 BAR (CUSTOMER)
- I/** LENGTH OF FEEDING PIT
- J/** MAIN SWITCH AND ELECTRIC CONNECTION
(EARTH CONNECTION COMPULSORY)
- P/** DEPTH OF FEEDING PIT
- R/** FRONT VIEW
- S/** SIDE WIEW
- T/** TOP WIEW

t0388gb

dimensions in mm			Gas heating
B	inner diameter		160
C	diameter		20/27
F	Amperes	400 V 415 V	12
F	Cable section in mm ²	400 V 415 V	4 x 2.5
G	mm		3940
H	diameter		15/21
I	mm		3100

07100051



01102010	0298	6	1
Notice	Date	Page	

**LAYOUT FOR IRONER
GAS HEATING
KEY TO DRAWING N° 07100051**

BENCHMARKS

- B/** DRAIN OF VAPOUR DIRECT TO OUTSIDE
- C/** GAS INLET
- F/** ELECTRIC POWER SUPPLY
- G/** OVERALL LENGTH
- J/** MAIN SWITCH AND ELECTRIC CONNECTION
(EARTH CONNECTION COMPULSORY)
- R/** FRONT VIEW
- S/** SIDE VIEW
- T/** TOP VIEW

t0181gb

dimensions in mm			Gas heating
B	inner diameter		160
C	diameter		20/27
F	Amperes	415 V	12
F	Cable section in mm ²	415 V	4 x 2.5
G	mm		3940

Gas connection



The installation, connection and gas arrival adjustments for the machine must be done by qualified personnel only.


Gas supply DN 20 (3/4" BSP)

The customer must install a filter and a manual stop valve on the supply side of the machine if natural gas is used.

For butane or propane, the customer must install a filter, a manual closing valve and a pressure reducer.

Connect the installation above of the machine.


Gas connection



D0576

A : Gas burner
B : Gas inlet
C : Air filter

I : Injectors
G : Service tank
P : Venturis



D0491

01102010	1000	2	2
Notice	Date	Page	

The machine is adjusted at the plant to be suitable for the kind of gas specified on the order. If you have to supply your machine with gas in a family different from the gas for which your machine was adjusted, proceed as follows:

Check that the diameter of the injectors is adequate for the kind of gas of your installation (see table of injectors). The machine is delivered with extra injectors in a plastic envelope.

Testing pressures


According to the EN 437 standard, the values of the testing pressures mentioned in our various documents are values for static pressures taken at the gas inlet connection of the machine; the heating of the machine being on.

Changing to a gas in the same family (type H or L)

- Change the 3 injectors with joints and if necessary, adjust the air flow (see tables of correspondences).
- Adjust the gas outlet pressure (see correspondence in the tables).

Changing to a gas in a different family (from type H or L to butane or propane)

- Change the 3 injectors with joints (see correspondence in the tables).
- Unscrew the fixing screws (V) and remove the adjusting head (J) as well as its cork (T), keep these parts in case a change would be necessary.
- Replace it by the cork (L) and the plate (P).
- Screw the two screws and block.
- Adjust the air flow (see correspondence in the tables).



D0291

Changing to a gas in a different family (from butane or propane to type H or L)

- Change the 3 injectors with joints (see correspondence on the tables).
- Unscrew the fixing screws (V) and remove the plate (P) as well as the cork (L), keep these parts in case a change would be necessary.
- Set the cork (T) and the adjustment head (J).
- Screw the two screws (V) and block.
- Adjust the air flow (see correspondence in the tables).




IMPORTANT

Adjustments should be made by qualified personnel only.

Adjustment and checking of the outlet pressure

The gas outlet pressure of the solenoid valve is adjusted at the factory. If you have to make another adjustment, proceed as follows.

- A** Inlet
- B** Outlet
- D** Outlet pressure regulator adjustment screw plug
- E** Inlet pressure tapping
- F** Outlet pressure tapping
- T** Head regulation



D0290

1/ Close the gas inlet and remove the binding screw from the pressure tapping (F) and connect the manometer tube.

2/ The electricity supply must be energized otherwise gas will not be supplied to the burner.


3/ Open and check the gas inlet main burner using the manometer on the pressure tapping (F).

4/ Remove pressure regulator cap (D).

5/ Using a screwdriver, slowly turn the adjustment screw until the required pressure (P) is indicated on manometer (see tables on the following pages).

Turn the adjustment screw clockwise to increase and counter-clockwise to decrease gas pressure.

6/ Reset the pressure regulator cap, close off the gas inlet, remove the manometer tube and put the binding screw back in (F).



D0034

t0397gb

TABLE OF CORRESPONDENCES - Ironer 3.1 m

Category index	Type of gas	Working supply pressure in mbar	H i	Ø of injectors in mm	Pressure at injectors (mm H ₂ O)	Heat emission Q _n in kW (H i)	Consumption M _n in kg / h	Consumption V _n in m ³ / h
* 2E, 2H, 2ESI	G 20	20	in MJ/ m ³ 34.02	4.00	114	65	-	6.87
2 L, 2ESI	G 25	25	in MJ/ m ³ 29.25	4.00	160	65	-	7.99
3 +	G 30 G 31	28-30/37	in MJ/ kg 45.65 46.34	2.30	-	65	5.12 5.05	-
3 B / P	G 30 G 31	50	in MJ/ kg 45.65 46.34	2.05	-	65	5.12 5.05	-
3 B / P	G 30 G 31	30	in MJ/ kg 45.65 46.34	2.30	-	65	5.12 5.05	-
3 P	G 31	50	in MJ/ kg 46.34	2.10	-	65	5.05	-

* for Belgium, no work is allowed between G20 and G25.

Note : G20 = natural gas, Lacq type
G30 = butane gas

G25 = natural gas, Groningue type
G31 = propane gas

IMPORTANT

Tightness test after installation



The gas leak test is performed as follows:

1/ Paint pipe joints, pilot gas tubing connections and inspect outlets with rich soap and water solution; do not use an aggressive soap.

2/ Put the machine into service. Bubbles indicate a gas leak.

3/ Eliminate this leak.



Check-out

Before leaving, put the appliance into operation and allow to run a complete cycle. Watch to ensure that all burner system components function correctly.

Connection of the dryer evacuation system

Fresh air inlet

To allow the dryer ironer to work at its best, it is important that the laundry air inlet passes through an opening from the outside.


The fresh air arrival must be equivalent to the volume of evacuated air.

In order to prevent drafts in the room, the best solution is to place the air inlet behind the machine.

In the case of a machine with gas heating, it is essential that the rooms should be ventilated.

The free section of the air inlet must be 5 times greater than the section of the evacuation pipe.

Do not forget to allow for the fact that grills often occupy half the total area of the free air opening.




D0462

Evacuation duct

It is recommended that a separate smooth-walled evacuation duct should be connected to each dryer, providing the least possible resistance to air.

Check that the shaft flow is at least twice the capacity of the ironer exhaust fan.



D0460



It is essential that the diameter of the evacuation pipe should be selected as a function of each installation so that the pressure loss never exceed 200 Pa (value measured at ambient temperature).

These conditions are **ABSOLUTELY ESSENTIAL** for correct working of the ironer.

01102010	0298	6	2
Notice	Date	Page	

Gas heating specifications.



Evacuation of vapour from a dryer ironer with gas heating must never be connected to the evacuation used for a gas heating machine and a dry cleaning machine or other machine of the same type.

Fan maximum flow rate with no pressure : 800 Pa.

Average temperature of exhaust at the machine outlet for gas heating : 95 °C

For gas heating, the required combustion fresh air supply should be not less than 2 m³/h per kW either 130 m³/h.

NOTE : if the flow is insufficient due to an excessive pressure loss, a safety pressure switch will automatically switch the heating off.

Values of the adjustment of safety pressure switch 7 mmH₂O




The machine should be installed in conformity with the regulations and standards enforced and situated in a correctly ventilated room.



If you detect gas smells, turn off the gas, open the windows, do not activate any switch and warn the maintenance service.

The duct must lead to the outside and must be fitted with protection against the weather and foreign bodies.

D0059



IRONER FOLDER WITH FRONT OUTLET OR REAR OUTLET IRONER WITH REAR OUTLET OR IRONER GAS HEATING

A/ GENERAL CONTROL AND MOVEMENT

1. Voltage indicator
2. "OFF" key
3. "ON" indicator
4. "ON" key
5. Ironing speed indicators
6. Ironing speed adjustment button


B/ HEATING CONTROL

7. "HEATING OFF" key
8. "HEATING ON" indicator
9. "HEATING ON" key
10. Ironing temperature indicator
11. Temperature programming key (reduce)
12. Temperature programming key (increase)
13. Storage of temperature or display change key (temperature measured / temperature required)
14. Faulty pipe burner indicator
15. Indicator with not use
18. Yellow push-button for reset the burner (push on the yellow button to reset the burner)

C/ FOLDING CONTROL

16. Select switch for front outlet or rear outlet with folding (machine with rear outlet)
17. Eject / initialize blue push-button (machine with rear outlet)

D0430



When the side casings have been reassembled, please follow the instructions below :

Check that the installation is correct (see chapter Installation).

A/ Turn main section switch to "ON", the LED (1) "voltage" lights.

B/ Turn the potentiometer (6) to the minimum speed : 3.2 m/mn (maximum speed : 10 m/mn).

C/ Press key (4) "ON", the machine sets to the position "without folding" (the evacuation table tilts after about thirty seconds).

LED (3) lights.

The cylinder and the guiding bands rotate.

The fan works and draws the air out of the machine outside the building.



The indicator (5) of ironing speed lights.

The indicator (10) of cylinder temperature lights.

Check that the finger protection is working. The finger protection must stop the machine when it is touched. LED (1) "voltage" is the only one that remains light.

To restart the ironing process, carry out the starting operations again.

The machine will not start if the premises where it is installed have a temperature of less than 10 °C.



01102010	0298	3	3
Notice	Date	Page	

START-UP GAS HEATING

A/ Open the fuel gas valve on the gas supply line.

B/ Press key (13).

C/ Select the regulating temperature with keys (11) and (12).

D/ Put this value in memory with key (13). The temperature measured on the cylinder is displayed. Usual ironing temperature is around 150 to 170 °C.

E/ Press key (9) to activate heating. Indicator (8) lights and blinks. Indicator (14) signal to indicate that the burner is lighting. If indicator (14) blinks for more than 6 seconds, there may be a misfire or an opening omission of the gas valve.
Push on the yellow button to reset the burner.


F/ Check the ironing temperature on indicator (10).

G/ The required temperature is reached when indicator (8) remains lit without signaling.

H/ At any time, by pressing key (13), the measured temperature indicated changes into the temperature required during operation n° 3 and vice versa.

I/ The required temperature is reached when indicator (8) remains lit without signaling.

J/ The temperature stops rising after approximately 15 minutes.



HOW TO STOP THE MACHINE

In order to extend the lifetime of your machine and its components, observe the following instructions to stop the heating.

Shut the steam inlet valve or the fuel gas valve.

Press key (7) "HEATING OFF" and only that one. Keep on feeding linen to lower the cylinder temperature down to approximately 120 °C.

Do not use the folding mode during the cooling process.

The machine will automatically stop when the temperature falls below 70 °C.



To obtain the automatic stop at 70 °C, it is essential not to press key (2) "GENERAL STOP" otherwise, the automatic temperature lowering function would be cancelled.

When the machine is stopped :

Turn the general switch situated on the left casing to O (OFF).

At any time, it is possible to stop the machine by pressing key (2) - GENERAL STOP.

(Careful : a high temperature of the ironing cylinder may damage the ironing strips).



01102010	0298	5	3
Notice	Date	Page	

USE OF THE BLUE PUSH-BUTTON ON THE CASING

An action on the button fitted on the ironer's casing ejects the last sheet during the folding process. The sheet is ejected before the end of the folding process and all sheets on the evacuation table are ejected.

Push the button for 4 sec. to re-initialize the automate after an incident during the folding process or after a forced ejection.

SHEETS FEEDING

The positionning of the sheets on the feeding table has to be done with care.

The sheet has to be positionned in front of the detection cell, in the middle of the feeding table, so as the machine can measure the lenght of the piece to be ironeed.

If you put the sheet on the detection cell, the lenght measured will be unaccurate and the folding will be defective.

01102010	0298	1	4
Notice	Date	Page	

Safety gas-heating device.

The ignition of burners and the control of the flame are ensured by an electronic box that provides a full safety in case of bad draught or gas admission cutoff for instance.

On the control panel, the indicator light up when the safety device is in function.

Heating safety device.

In all cases, a safety thermostat prevents the drum from over-heating (except for a steam-heated machine on which the temperature is given by the steam pressure).

01102010	0298	1	5
Notice	Date	Page	

The heating does not work or does not work properly

Check the temperature preselection.

Check thermostats.

Check the thermostat regulation system sensor.

Check the gas inlet.

Clean pressure reducer filters.

Check electronic ignition.

Check the position of the ignition electrodes and flame control.

Check operation of the gas solenoid valve.

If the ironing temperature drops abnormally

The machine is fitted with two regulation thermostats (1 on the left and 1 on the right of the ironing cylinder).

When ironing on one single side of the cylinder, the regulation thermostat located on the other side cut off the heating at 190 °C.

Stop ironing until the thermostat indicates less than 190 °C, or iron on both sides of the cylinder.

If the flame is yellow

Check that the vapour exhaust fan works and rotates in the right direction

Check that the air admissions are not sealed

Check the vapour extraction chimney

Check the calibration of nozzle


Clean the air admission filter

Compressed air

There is a pressostat in the electric box which stops the machine when the compressed air pressure is not sufficient.

This manometer has a mechanical green signal (A) which is "out" when the pressure is correct.

If a pressure drop occurs, check the compressed air feeding pressure with the manometer and try to find the reason on the machine or on your installation.



01102010	0298	1	6
Notice	Date	Page	

MONTHLY

Clean the gas filters (only for gas heated machines).

ONCE A YEAR

Check the gas inlet.


Clean pressure reducer filters.

Check electronic ignition.

Check the position of the ignition electrodes and flame control.

Check operation of the gas solenoid valve.

GAS TRAIN



- 1 - Shutt-off value 3/4"
- 2 - Pressure control gas min
- 3 - Inlet pressure TAP
- 4 - Gas electrovalve (or Australia gas electrovalves block)
- 5 - Outlet pressure TAP
- 6 - Burner with 39 ceramic plates
- 7 - Fan
- 8 - Depressure control air

List of components

Quantity	Designation	Ref.	Manufacturer
1	Pressure control gas min	GW50 A4	Dungs
1	Gas electrovalve	VR4925	Honeywell
	or electrovalves block	VR4925	Honeywell
1	Electronic flame safeguards	S4560	Honeywell
1	Depressure control air	C6065A/1028	Honeywell
1	Fan	T63B5 0.3 kW	Néri

01102010	0399	2	8
Notice	Date	Page	


CONTROL CIRCUIT
gas heating
(ironer, folder with front or rear outlet)
32006937

T1	Isolating transformer 1000 VA	
T2	Distribution circuit transformer 24 V	same part
A2	Distribution circuit rectifier 24 V DC	
A3	Programmer / block diagram	
A4	Programmable automate	
Q5	Two-pole breaker ph + N 2 A secondary	
Q6	Two-pole breaker 6 A primary	
Q7	Two-pole breaker 2 A (common outputs)	
i2	Rear outlet motor thermal contact	
i3	Thermal contact fan motor	
i8	Air shortage pressostat	
i9	Thermal contact motion motor	
i11	Left rear outlet emergency stop	
i14	Finger protection right flap position switch	
i15	Finger protection left flap position switch	
i16	Right rear outlet emergency stop	
i28	Gas pressure switch (option or Australia machine)	
KM3	Fan contactor	
KM8	Rear outlet motor contactor	
KM9	Motion contactor	
C2	220 V AC longitudinal folding cell supply	

01102010	0298	4	8
Notice	Date	Page	

POWER CIRCUIT
gas heating
(ironer, folder with front or rear outlet)
32006938

X1	General supply terminal
Q3	6 A three-pole breaker
Q4	Two-pole breaker 4 A
Q5	Two-pole breaker ph + N 2 A
Q6	Two-pole breaker 6 A
Q8	General switch
T1	Isolating transformer 1000 VA
A1	Motion frequency converter (ATV16)
A3	Programmer
Citel	Accomodating connection
M2	Rear outlet motor
M3	Fan motor
M9	Motion motor
KM3	Fan motor contactor
KM8	Rear outlet motor contactor
KM9	Motion motor contactor
R1	Rectifier for brake F1
F1	Rear evacuation brake




32006939

01102010	0298	6	8
Notice	Date	Page	

AUTOMATE INPUTS
gas heating
(ironer, folder with front or rear outlet)
32006939

X3	Inputs connection terminal on automate A4
IØ,0	Run / stop
KM3	Fan contactor
IØ,1	With/without folding
i29	With or without folding switch
IØ,4	Rear longitudinal arm
i30	Rear folding position switch
IØ,5	Longitudinal sheet measurement
i32	Longitudinal folding measurement inductive detector
IØ,7	Longitudinal folding safety device
C3	Longitudinal folding safety device photocell
C4	Longitudinal folding safety device photocell
IØ,11	Longitudinal folding
C2	Longitudinal folding photocell
IØ,12	Sheet at feeding
C1	Feeding sheet photocell
IØ,15	Push-button for rear evacuation and initialization
i22	Push-button for rear evacuation and initialization
IØ,25	Longitudinal folding shunted at IØ,5 quick metering input



01102010	0399	8	8
Notice	Date	Page	

AUTOMATE OUTPUTS
gas heating
(ironer, folder with front or rear outlet)
32006940

X4	Outputs on automate A4 connection terminal
Q7	Two-pole breaker 2 A (common outputs)
OØ,Ø	Vat without folding
Y1	Vat without folding pneumatic distributor
A5	Control box for antistatic bar
OØ,4	Front longitudinal folding arm
OØ,5	Rear longitudinal folding arm
i 27	Front folding position switch
i 28	Rear folding position switch
Y14	Longitudinal folding arm clutch (clutch/brake, 2 stops/turn)
OØ,8	Tension lift pneumatic distributor
Y2	Tension lift pneumatic distributor
OØ,9	Rear blow pneumatic distributor
Y3	Rear blow pneumatic distributor
OØ,10	Front blow pneumatic distributor
Y4	Front blow pneumatic distributor
OØ,11	Rear outlet motor contactor
KM8	Rear outlet motor contactor

01102010	0298	10	8
Notice	Date	Page	




INPUTS / OUTPUTS CARD
gas heating
(ironer, folder with front or rear outlet)
32006941

F1	General fuse 2 A
A1	Frequency converter
C1	Feeding connector 230 V
C2	Outputs connector 230 V
C3	Inputs connector
C5	Connector for converter flat cable
i11	Photocell detection speed
S1	Thermic probe PT100
Citel	Accommodating connection
H1	Indicator for faulty pipe burner gas ignitor

Adjustment potentiometers

P1	Adjustments of gain in temperature
P2	Adjustments of temperature zero
P3	Adjustments of minimum ironing speed
P4	Adjustments of maximum ironing speed


These adjustments should only be carried out by a technician.



32007046

POWER CIRCUIT
gas heating
(feeder, ironer, folder with side delivery)
32007046

X1	General supply terminal
Q1	Three-pole motor breaker
Q2	Three-pole motor breaker
Q3	Three-pole motor breaker
Q4	Two-pole breaker 4 A
Q5	Two-pole breaker ph + N 2A
Q6	Two-pole breaker 10 A
Q8	General switch
T1	Isolating transformer 1000 VA
A1	Motion frequency converter (ATV16)
A3	Programmer
Citel	Accommodating connection
F1	Stacker table brake
F3	Rear evacuation brake
M1	Stacker table motor
M2	Pile evacuation motor
M3	Fan motor
M4	Smoothing right motor
M5	Smoothing left motor
M6	Cross-folding motor
M8	Rear evacuation motor
M9	Motion motor
KM1	Stacker table motor contactor
KM2	Pile evacuation motor contactor
KM3	Fan motor contactor
KM4	Smoothing motor contactor
KM5	Cross-folding motor contactor
KM8	Rear evacuation motor contactor
KM9	Motion motor contactor
R1	Rectifier for brake F1
R3	Rectifier for brake F3




01102010	0298	14	8
Notice	Date	Page	

CONTROL CIRCUIT
Gas heating with ceramic burner
(Standard machines)
32007428

A	RV500 ignition meter case
A4	Electronic programmer
E	Ionization/ignition electrode
H	Indicator for faulty pipe burner
i7	Gas inlet pressostat (option)
i8	Air pressure switch
i9	Safety thermostat
i10	Left side thermostat
i11	Right side thermostat
KA4	Time relay
R	Varistor
Y1-Y2	Gas electrovalve

INTERCONNECTION CIRCUIT (ironer) gas heating



INPUTS / OUTPUTS CARD

gas heating

(ironer)


32007080


F1	General fuse 2 A
A1	Frequency converter
C1	Feeding connector 230 V
C2	Outputs connector 230 V
C3	Inputs connector
C5	Connector for converter flat cable
i11	Photocell detection speed
R1	Thermic probe PT100
Citel	Accomodating connection
H1	Indicator for faulty pipe burner gas ignitor

Adjustment potentiometers

P1	Adjustments of gain in temperature
P2	Adjustments of temperature zero
P3	Adjustments of minimum ironing speed
P4	Adjustments of maximum ironing speed

These adjustments should only be carried out by a technician.





01102010	0298	18	8
Notice	Date	Page	

CONTROL CIRCUIT
gas heating
(ironer and ironer with rear outlet))
32007081

A4	Electronic scheduler
i1	Switch of position safety-hand shutter (left)
i2	Switch of position safety-hand shutter (right)
i3	Thermal contact motor fan
i4	Thermal contact motion motor
i5	Air pressure switch
i11	Photocell detection speed
Q2	Contact breaker fan motor
R1	Thermic probe PT100

01102010	1099	20	8
Notice	Date	Page	

CONTROL CIRCUIT
Gas heating with ceramic burner
(Australia machines)
32006967A

i17	Left side control thermostat
i26	Right side control thermostat
i27	Air pressure switch
i29	Over heating thermostat
i29	220 °C Over heating thermostat
A8	Ignition meter case
KA2	Time-relay for air pressure switch gas
KA3	Safety control air relay
H1	Indicator for faulty pipe burner
S1	Push-button reset burner
S2	Programmer output
Y5	Gas electrovalve
E1	Control electrode
E2	Ignition electrode