



PARTS ILLUSTRATION



DETAIL "F"

Set adjusting screws as close to valve stems as possible. Leave approximately .015 clearance to allow for seating of valve. Use caution not to adjust so valves can bottom out.

On earlier machines this valve was a #30876 poppet valve. To replace the #30876 valve, order replacement kit #K-349.