

Washer-Extractor

Cabinet Freestanding
Refer to Page 3 for Model Numbers

— Unique Parts —

Table of Contents

Title	Page
Parts Ordering Information.....	2
Serial Plate Location	2
Model Identification	3
Unique Parts	4
Parts Index.....	5

© Copyright 2013, Alliance Laundry Systems LLC

All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without the expressed written consent of the publisher.

Parts Ordering Information

If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at (920) 748-3950 for the name and address of the nearest authorized parts distributor.

For technical assistance, call either of the numbers listed below:

(920) 748-3121 Ripon, Wisconsin

+32 56 41 20 54 Wevelgem, Belgium

Serial Plate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on serial plate(s).

Model Identification

Information in this manual is applicable to these washer-extractor models:

HX18_B-CONTROL	SX18_B-CONTROL
HX30_B-CONTROL	SX30_B-CONTROL
HX35_B-CONTROL	SX35_B-CONTROL
HXN075B	SXN075B
HXN135B	SXN135B
HXN165B	SXN165B

Unique Parts

PART NO.	DESCRIPTION	COMMENTS
209/00580/02	Printer Timer	
B12359902	Optical Coin Drop Switch	
B12523401	Operation Panel	Models HX18_B-CONTROL, HXN075B, SX18_B-CONTROL and SXN075B; Models with coin meter
B12523801	Operation Panel	All other models; Models with coin meter
B12540601	Operation Panel	Models HX18_B-CONTROL, HXN075B, SX18_B-CONTROL and SXN075B; Models with central payment
B12540701	Operation Panel	All other models; Models with central payment
B12524901	Overlay	
111/01004/00	Front Panel	Gray
111/01003/00	Top Panel	Black
209/00682/00	Transformer	
209/00683/00	Input Block	
209/00438/50	Central Control Board	
254/00077/00	Coin Box	
254/00077/02	Key	
B12530201	Coin Drop Power Harness	
B12531201	Central Payment Key Switch Harness	
B12531301	Direct Fill and Central Payment Harness	
B12531401	Central Payment Harness	
B12392705	Direct Fill Harness	
B12348904	Drive Stop or Bypass Harness	

NOTE: This manual includes unique parts information for the models shown on page 3.

Parts Index

C

Central Control Board	
209/00438/50	4
Central Payment Harness	
B12531401	4
Central Payment Key Switch Harness	
B12531201	4
Coin Box	
254/00077/00	4
Coin Drop Power Harness	
B12530201	4

D

Direct Fill and Central Payment Harness	
B12531301	4
Direct Fill Harness	
B12392705	4
Drive Stop or Bypass Harness	
B12348904	4

F

Front Panel	
111/01004/00	4

I

Input Block	
209/00683/00	4

K

Key	
254/00077/02	4

O

Operation Panel	
B12523401	4
B12523801	4
B12540601	4
B12540701	4
Optical Coin Drop Switch	
B12359902	4
Overlay	
B12524901	4

P

Printer Timer	
209/00580/02	4

T

Top Panel	
111/01003/00	4
Transformer	
209/00682/00	4

N/A items do not appear in index.

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal black lines across its entire width, typical of notebook or legal stationery. The background is a solid off-white color, and there are no margins, text, or other markings present.