Washer-Extractor

Refer to Page 5 for Model Numbers






Table of Contents

Title	Page
Parts Ordering Information	q
Nameplate Location	
Model Identification	
Product Overview - PS40 Control	
Decals - Models through 8/31/09 (Drawing 1 of 2)	
Decals - Models through 8/31/09 (Drawing 1 of 2)	
Decals - Models starting 9/1/09	
Bearing Housing Assembly (Drawing 1 of 6)	
Bearing Housing Assembly (Drawing 2 of 6)	
Bearing Housing Assembly (Drawing 3 of 6)	
Bearing Housing Assembly (Drawing 4 of 6)	
Bearing Housing Assembly (Drawing 5 of 6)	
Bearing Housing Assembly (Drawing 6 of 6)	
Top and Front Panels (Drawing 1 of 2)	
Top and Front Panels (Drawing 2 of 2)	
Rear, Side and Valve Panels (Drawing 1 of 2)	
Rear, Side and Valve Panels (Drawing 2 of 2)	
Control Box Assembly	
Cylinder Assembly	
Single Cup Dispenser Assembly	
5 Cup Dispenser Assembly	
Door Assembly - Models through 2/9/09 (Drawing 1 of 2)	
Door Assembly - Models through 2/9/09 (Drawing 2 of 2)	
Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)	
Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)	
Door Lock Assembly	
Door Lock Assembly with Magnetic Sensor	
5 Cup Hot Plumbing Assembly	
1 Cup Hot Plumbing Assembly	
5 Cup Cold Plumbing Assembly	
1 Cup Cold Plumbing Assembly	
Auxiliary Plumbing Assembly	
Supply Hose and Filter (Optional)	
Steam Heat Assembly	
Steam Option Assembly	68
Shell Assembly (Drawing 1 of 2)	
Shell Assembly (Drawing 2 of 2)	
Electric Heat Shell Assembly (Drawing 1 of 2)	
Electric Heat Shell Assembly (Drawing 2 of 2)	
Drive Box Assembly	
Electric Heat Drive Box Assembly	
© Conveight 2012, Alliance Loundry Cystems LLC	

© Copyright 2013, Alliance Laundry Systems LLC

All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without the expressed written consent of the publisher.

AC Drive and EMI Filter	82
AC Drive and EMI Filter - Electric Heat Models	84
PowerFlex Drive and EMI Filter - Design 1 Models	86
PowerFlex Drive and EMI Filter - Design 2 Models	88
Main Assembly (Drawing 1 of 8)	90
Main Assembly (Drawing 2 of 8)	92
Main Assembly (Drawing 3 of 8)	
Main Assembly (Drawing 4 of 8)	96
Main Assembly (Drawing 5 of 8)	
Main Assembly (Drawing 6 of 8)	100
Main Assembly (Drawing 7 of 8)	102
Main Assembly (Drawing 8 of 8)	104
Parts Index	

Parts Ordering Information


If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at (920) 748-3950 for the name and address of the nearest authorized parts distributor.

For technical assistance, call either of the numbers listed below:

(920) 748-3121 Ripon, Wisconsin +32 56 41 20 54 Wevelgem, Belgium

Nameplate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on nameplate(s) as shown. The nameplate is located inside the door and on the upper rear panel.



Notes


-			
-			
-			
-			
-			


Model Identification

Information in this manual is applicable to these washer-extractor models:

	• •	
CP040PHN1	IP040PHN1	JP040PHN1
CP040PHQ1	IP040PHN2	JP040PHQ1
CP040PHX2	IP040PHQ1	JP060PHN1
CP040PMN1	IP040PHX2	JP060PHN2
CP040PMQ1	IP040PMN1	JP060PHQ1
CP040PMX2	IP040PMQ1	JP060PMQ1
CP060PHN1	IP040PMX2	
CP060PHN2	IP060PHN1	
CP060PHQ1	IP060PHN2	
CP060PHQ2	IP060PHQ1	
CP060PHX1	IP060PHX2	
CP060PHX2	IP060PMN1	
CP060PMN1	IP060PMN2	
CP060PMQ1	IP060PMQ1	
CP060PMX2	IP060PMX2	
CPC40H	IPH40H	
CPC40M	IPH40M	
CPC60H	IPH60H	
CPC60M	IPH60M	
	IPH180	
	IPH270	

Product Overview - PS40 Control






PHM3091P_C002874

Product Overview - PS40 Control

REF	PART NO.	DESCRIPTION	COMMENTS
1		Product Family	СР
			IP
			JP
2		Capacity (Pounds)	040
			060
			080
			100
			125
			140 175
3		Control	P (PS-40 Control)
4		Speed	H (High Speed)
			M (Medium Speed)
5		Voltage	N (380-415/440-480/50/60/3)
			Q (208-220/220-240/50/60/3)
			X (208-220/220-240/50/60/1/3)
6		Design	1
			2
7		Heat	0 (Prep for Steam)
			D (Direct)
			E (Electric)
8		Plumbing	0 (Standard US Thread - 2 valves)
			A (US Thread - 3 valves)
			B (Metric Thread - 2 valves)
			C (Metric Thread - 3 valves)
			D (US Thread - 2 valves, 3 inlets)
			E (No valves)
9		Supply	1 (1 Compartment 6 Signals)
			2 (1 Compartment 12 Signals)
			5 (5 Compartments 6 Signals)
			6 (5 Compartments 12 Signals)
			7 (No Compartment 6 Signals)
			8 (No Compartment 12 Signals)

Decals - Models through 8/31/09 (Drawing 1 of 2)




PHM2767P_C002874

Decals - Models through 8/31/09 (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F200085100	Spin Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
2	F200085000	Hot Surface Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1 and IP060PMQ1
3	F200085300	Hot Water and Chemical Caution Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1 and JP060PHQ1
4	F200318200	Cover Decal	
5	F230734	Water Line Caution Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
6	F231367	Hot Water Valve Decal	
7	F231368	Cold Water Valve Decal	
8	C000508	Bearing Lubrication Decal	
9	C000506	Supply Signal Decal	
10	F230917-1	External Supply Connection Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PHQ1, IP040PMN1, IP040PMQ1, IP040PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IP060PHN1, IP060PHQ1, JP060PHN1, JP060PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1

Decals - Models through 8/31/09 (Drawing 2 of 2)



PHM2767PA_C002874


Decals - Models through 8/31/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F200318200	Cover Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1 and IP060PMQ1
2	502511	Electrical Shock Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
3	500049	Warning Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
4	N/A	Crush Hazard Warning Decal	Models CPC40H, CPC40M, CPC60H, CPC60M, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
	502506	Pinched Fingers Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
5	F200085000	Hot Surface Warning Decal	Models CPC40H, CPC40M, CPC60H, CPC60M, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
	F231380	Hot Surface Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
6	C001038	Logo Decal	Models IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
7	C000694	Door Release Decal	
8	F230303	Push Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1

N/A = Part no longer available

Decals - Models starting 9/1/09

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMQ1, IP060PMX2, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1




PHM3089P_C002874

Decals - Models starting 9/1/09

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000694	Door Release Decal	
2	F230303	Push Decal	
3	F200085100	Spin Warning Decal	All models except JP040PHQ1, JP060PHQ1 and JP060PMQ1
4	F200085000	Hot Surface Warning Decal	
5	F200085300	Hot Water and Chemical Caution Decal	
6	F8211901	Hot Surface Warning Plate	Steam models only
7	F8246401	Mount On Concrete Warning Label	
8	F200061000	Clean Filter Daily Decal	
9	C000508	Bearing Lubrication Decal	
10	F8150201	External Supply Connection Decal	
11	F8233501	Warning Label	
12	F8115501	Electric Shock Danger Label	
13	44127701	Warning Label	

Bearing Housing Assembly (Drawing 1 of 6)

Models CPC40H, CPC60H, IPH40H and IPH60H Models Through 3/23/04




PHM2768P_C002874

Bearing Housing Assembly (Drawing 1 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CPC40H and IPH40H
	C000145	Screw	8 required; Bearing housing to frame; Models CPC60H and IPH60H
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	F200201	Hose Clamp	2 required; Ship inside machine
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
1	C000058P	Bearing Housing Assembly	Includes items 2 and 4-20
2	J1408004	Connector	
3	9002071P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	
6	C000068	Cylinder Shaft	
7	C000151	Carb Bearing	
8	C000064	Grease Shield	
9	C000152	Roller Bearing	
10	C000071	Washer	
11	C000063	Nut	
12	C000158	Seal Plate	
13	C000070	V-Ring Seal	
14	C000057	Bearing Housing	
15	C002959	Triple Lip Seal	
16	C000069	V-Ring Seal	
17	C000065	Seal Plate	
18	C000066	Seal Plate	
19	C001916	Plate	
20	C001704	Gasket	

Bearing Housing Assembly (Drawing 2 of 6) Models CPC40H, CPC60H, IPH40H and IPH60H

Models Starting 3/23/04



PHM2971P_C002874


Bearing Housing Assembly (Drawing 2 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CPC40H and IPH40H
	C000145	Screw	8 required; Bearing housing to frame; Models CPC60H and IPH60H
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000058P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
	C001364P	Bearing Housing Assembly	Includes items 2 and 5; Viton seals
2	J1408004	Connector	
3	9002071P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 3 of 6)

Models CPC40M, CPC60M, IPH40M, IPH60M, IPH180 and IPH270

Models Through 3/23/04



PHM2769P_C002874


Bearing Housing Assembly (Drawing 3 of 6)

C001019 Screw	REF	PART NO.	DESCRIPTION	COMMENTS
PH60M and IPH270		C001019	Screw	
F430929 Screw 12 required; Front and rear seal plates to bearing housing		C001018	Screw	
C000571 Washer		C000147	Washer	16 required; Bearing housing to frame
Nousing		F430929	Screw	• • • • • • • • • • • • • • • • • • • •
C000552		C000571	Washer	
C000628P Tubing		C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
36801 Hose Clamp 1 required; Bearing weep hole "TEE" 1		C000552	Hose	25 inch; Weep hole fitting to drain line fitting
1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector 3 9002071P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C00065 Seal Plate 20 C001916 Plate		C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
2 J1408004 Connector 3 9002071P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 20 C001916 Plate		36801	Hose Clamp	1 required; Bearing weep hole "TEE"
3 9002071P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	1	C000728P	Bearing Housing Assembly	Includes items 2 and 4-21
4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	2		Connector	
5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	3			Optional; Not installed
6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	4	C000372	Mounting Bracket	
7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	5	C001649	Reducing Connector	
8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	6	C000725		
9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	7	C000485	<u> </u>	
10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	8	C000729	Front Grease Shield	
11 C000488 Washer 12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	9	C000730		
12 C000727 Seal Plate 13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	10	C000486	Roller Bearing	
13 C000726 Cylinder Shaft 14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	11		Washer	
14 C000731 V-Ring Seal 15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	12	C000727		
15 C000487 Nut 16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	13	C000726	•	
16 C002959 Triple Lip Seal 17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	14	C000731	V-Ring Seal	
17 C000069 V-Ring Seal 18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	15	C000487	Nut	
18 C000065 Seal Plate 19 C000066 Seal Plate 20 C001916 Plate	16	C002959	Triple Lip Seal	
19 C000066 Seal Plate 20 C001916 Plate	17	C000069	V-Ring Seal	
20 C001916 Plate	18	C000065	Seal Plate	
	19	C000066	Seal Plate	
21 C001704 Gasket	20	C001916	Plate	
	21	C001704	Gasket	

Bearing Housing Assembly (Drawing 4 of 6)

Models CPC40M, CPC60M, IPH40M, IPH60M, IPH180 and IPH270

Models Starting 3/23/04




PHM2972P_C002874

Bearing Housing Assembly (Drawing 4 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001019	Screw	8 required; Bearing housing to frame; Models CPC40M, IPH40M and IPH180
	C001018	Screw	8 required; Bearing housing to frame; Models CPC60M, IPH60M and IPH270
	C000147	Washer	16 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000728P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
2	J1408004	Connector	
3	9002071P	Lubricator	Optional; Not installed
4	C001037	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 5 of 6)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ1, CP060PHX1, CP060PHX2, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IPH270, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM2971P_C002874

Bearing Housing Assembly (Drawing 5 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CP040PHN1, CP040PHQ1, IP040PHN1, IP040PHQ1 and JP040PHN1
	C000145	Screw	8 required; Bearing housing to frame; Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, IP060PHN1, IP060PHN2, IP060PHQ1 and JP060PHQ1
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	F200201	Hose Clamp	2 required; Ship inside machine; Models through 3/23/04
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000058P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
	C001364P	Bearing Housing Assembly	Includes items 2 and 5; Viton seals
2	J1408004	Connector	
3	9002071P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 6 of 6) Models CP040PMN1, CP040PMQ1, CP040PMX2, CP060PMN1, CP060PMQ1,

Models CP040PMN1, CP040PMQ1, CP040PMX2, CP060PMN1, CP060PMQ1, CP060PMX2, IP040PMN1, IP040PMQ1, IP040PMX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH270 and JP060PMQ1




PHM2972P_C002874

Bearing Housing Assembly (Drawing 6 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001019	Screw	8 required; Bearing housing to frame; Models CP040PMN1, CP040PMQ1, IP040PMN1 and IP040PMQ1
	C001018	Screw	8 required; Bearing housing to frame; Models CP060PMN1, CP060PMQ1, IP060PMN1, IP060PMQ1, IPH270 and JP060PMQ1
	C000147	Washer	16 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000728P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
2	J1408004	Connector	
3	9002071P	Lubricator	Optional; Not installed
4	C001037	Mounting Bracket	
5	C001649	Reducing Connector	

Top and Front Panels (Drawing 1 of 2)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM2945P_C002874

Top and Front Panels (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	2 required for top panel to valve panel; 12 required for front panel to side panel; 2 required for lower front panel to frame; 4 or 5 required for front electrical mounting bracket to side panel
	F431024	Nut	4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel
	N/A	Nut	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000571	Washer	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000585	Washer	2 required for lower front panel to frame
	F430910	Screw	6 required for rub rails to lower front panel; Models starting 3/23/04
	C000568	Nut	6 required for rub rails to lower front panel; Models starting 3/23/04
1	C000483	Control Panel Insert	
2	C000513P	Top Panel	
3	C000484	Control Panel Insert	
4	C002967P	Front Panel Assembly	5 compartment
	C002966	Front Panel Assembly	1 compartment
5	C002984	Lower Front Adjustment Bracket Assembly	Models starting 3/23/04
6	C001013	Insert Rail	Models starting 3/23/04
7	C001012	Rub Rail	Vinyl; Models starting 3/23/04
8	N/A	Lower Front Panel	Models through 3/23/04
	C001246	Front Panel	Models starting 3/23/04
9	C000629	Trim Gasket	Black; 10 feet; Models starting 3/23/04
10	1242	Programming Key	
11	C003024P	Keymode Switch Assembly	
12	F200233500	Emergency Stop Pushbutton	
13	F200233700P	Emergency Stop Button Kit	Includes items 12 and 14
14	F200233401	Contact Block Switch	

N/A = Part no longer available

Top and Front Panels (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1




Top and Front Panels (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	2 required for top panel to valve panel; 12 required for front panel to side panel; 2 required for lower front panel to frame; 4 or 5 required for front electrical mounting bracket to side panel
	F431024	Nut	4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel
	N/A	Nut	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000571	Washer	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000585	Washer	2 required for lower front panel to frame
	F430910	Screw	6 required for rub rails to lower front panel
	C000568	Nut	6 required for rub rails to lower front panel
1	C000484	Control Panel Insert	
2	C000050	Top Panel	
3	C000483	Control Panel Insert	
4	C002968	Front Panel Assembly	1 compartment
	C002969	Front Panel Assembly	5 compartment
5	N/A	Lower Front Panel	Models through 3/23/04
	C001248	Front Panel	Models starting 3/23/04
6	C002985	Lower Front Adjustment Bracket Assembly	Models starting 3/23/04
7	C000636	Insert Rail	
8	C000633	Rub Rail	Vinyl
9	1242	Programming Key	
10	C003024P	Keymode Switch Assembly	
11	F200233500	Emergency Stop Pushbutton	
12	C000629	Trim Gasket	Black; 11 feet; Models starting 3/23/04
13	F200233401	Contact Block Switch	

N/A = Part no longer available

Rear, Side and Valve Panels (Drawing 1 of 2)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1



PHM2770PA_C002874


Rear, Side and Valve Panels (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	6 required for valve panel to side panel; 2 required for top panel to valve panel; 12 required for front panel to side panel; 6 required for side panel to frame; 4 required for rear cover to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	F431024	Nut	6 required for valve panel to side panel; 4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	N/A	Nut	2 required for top panel to valve panel; 6 required for side panel to frame; 2 required for rear electrical cover to valve panel
	C000571	Washer	2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel
	C000585	Washer	6 required for side panel to frame
	F430929	Screw	2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel
1	C002696	Side Panel and Stiffener Assembly	
2	C000533	Front Electrical Enclosure Rail	
3	C000539	Grease Connector Box	
4	C000173	Rear Electrical Enclosure Cover	
5	N/A	Inlet Power Cover	Models through 3/23/04
	C001257	Inlet Power Cover	Models starting 3/23/04
6	C002979	Valve Panel Assembly	
7	C000525	Rear Panel	
8	C002695	Side Panel and Stiffener Assembly	
9	N/A	Side Skirt Panel	Models through 3/23/04
10	C000530	Front Skirt Panel	Models through 3/23/04

N/A = Part no longer available

Rear, Side and Valve Panels (Drawing 2 of 2)

Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMX2, IP060PMX2, IP060PMX2, IP060PHX2, IP060PHX2,




PHM2771PA_C002874

Rear, Side and Valve Panels (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	6 required for valve panel to side panel; 2 required for top panel to valve panel; 12 required for front panel to side panel; 6 required for side panel to frame; 4 required for rear cover to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	F431024	Nut	6 required for valve panel to side panel; 4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	N/A	Nut	2 required for top panel to valve panel; 6 required for side panel to frame; 2 required for rear electrical cover to valve panel
	C000571	Washer	2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel
	C000585	Washer	6 required for side panel to frame
	F430929	Screw	2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel
1	C002708	Side Panel and Stiffener Assembly	Right
2	C000218	Front Electrical Enclosure Rail	
3	C000539	Grease Connector Box	
4	C000173	Rear Electrical Enclosure Cover	
5	N/A	Inlet Power Cover	Models through 3/23/04
	C001257	Inlet Power Cover	Models starting 3/23/04
6	C002980	Valve Panel Assembly	
7	C000051	Rear Panel	
8	C002707	Side Panel and Stiffener Assembly	Left
9	N/A	Side Skirt Panel	Models through 3/23/04
10	C000314	Front Skirt Panel	Models through 3/23/04

N/A = Part no longer available

Control Box Assembly




Control Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F431133	Washer	4 required for keypad to keypad mounting plate; Models starting 3/23/04
	F430910	Screw	4 required for keypad to keypad mounting plate
	C000567	Screw	1 required for keypad mounting plate to control panel; 4 required for electrical box to mounting bracket
	F431024	Nut	1 required for keypad mounting plate to control panel
	N/A	Nut	4 required for electrical box to mounting bracket
	C000571	Washer	4 required for electrical box to mounting bracket
	F430909	Screw	2 required for electrical box cover to electrical box; 1 required for ground connection to electrical box for models through 03/23/04; 2 required for ground connection to electrical box for models starting 3/23/04
	C000865	Control Module Harness	
	210/00902/00P	Infrared Cable Kit	
1	C000432	Front Electrical Enclosure Assembly	
2	C000348	Front Electrical Enclosure Cover	
3	C001276	Control Panel Decal	Models IP040PHN1, IP040PHN2, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PMN1, IP060PMN2, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
	C001389	Control Panel Decal	Models CP040PHN1, CP040PHQ1, CP040PHX1, CP040PMN1, CP040PMQ1, CP040PMX1, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX1, CPC40H, CPC40M, CPC60H and CPC60M
	C001069	Control Panel Decal	Models JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1
4	C000282P	Keypad Controller	
5	C000376	Standoff	8 required for keypad to keypad mounting plate
6	C000375	Mounting Bracket	
7	C000281P	Main Board Controller Kit	Includes item 9
8	209/00505/04P	Battery	
9	C002642P	Tilt Switch Assembly	
10	C000371P	Chemical Supply Controller	
11	C000213	Front Electrical Enclosure	
12	C002999	RC Network Assembly	
13	F330217P	RC Network Filter	

N/A = Part no longer available

Cylinder Assembly




Cylinder Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000583	Washer	Models starting 3/23/04
1	N/A	Washer	Models through 3/23/04
	C001239	Washer	Models starting 3/23/04
2	C001238	Cylinder Bolt Shroud	Models starting 3/23/04
3	N/A	Bolt	Models through 3/23/04
	C001093	Screw	Models starting 3/23/04 and continuing through 7/1/06
	C001294	Screw	Models starting 7/1/06
4	C000455P	Cylinder Assembly Kit	Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1
	C000812P	Cylinder Assembly Kit	Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M and IPH180
	C000792P	Cylinder Assembly Kit	Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1; Includes lifter rod
	C000037P	Cylinder Assembly Kit	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1; Includes lifter rod
5	F431011	Nut	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270 and JP060PHQ1 starting 3/23/04
6	F0431159-00	Washer	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M and IPH270 starting 3/23/04
7	C001327	Cylinder Lifter Rod	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270 and JP060PHQ1 starting 3/23/04

N/A = Part no longer available

Single Cup Dispenser Assembly




PHM2773P_C002874

Single Cup Dispenser Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F430920	Screw	4 required for hinges to cover and 4 required for hinges to control panel for models through 3/23/04; 2 required for dispenser cover to handle for models starting 3/23/04
	C001148	Screw	4 required for hinges to cover; 4 required for hinges to control panel; Models starting 3/23/04
	F430909	Screw	2 required for dispenser cover to handle; Models through 3/23/04
	F430925	Screw	2 required for dispenser to control panel
	N/A	Nut	2 required for dispenser to control panel
	F200201	Hose Clamp	2 required for dispenser hose
	C000552	Hose	Flush hose for supply dispenser
1	C000052	Supply Dispenser Cup	23 ounce
2	C001007	Siphon Tube	
3	C001788	Dispenser Door Handle	
4	C000605	Single Front Dispenser Cover	
5	N/A	Lift-Off Hinge	Nylon; Models through 3/23/04
	C001787	Hinge	Nylon; Black; Models starting 3/23/04
6	C001017	Front Supply Dispenser Nozzle	
7	C000220	Single Dispenser Assembly	1 cup

N/A = Part no longer available

5 Cup Dispenser Assembly



PHM2774P_C002874


5 Cup Dispenser Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F430920	Screw	4 required for hinges to cover and 4 required for hinges to control panel for models through 3/23/04; 2 required for dispenser cover to handle for models starting 3/23/04
	C001148	Screw	4 required for hinges to cover; 4 required for hinges to control panel; Models starting 3/23/04
	F430909	Screw	2 required for dispenser cover to handle; Models through 3/23/04
	F430925	Screw	2 required for dispenser to control panel
	N/A	Nut	2 required for dispenser to control panel
	36801	Hose Clamp	12 required for 5 cup supply dispenser for models through 3/23/04; 7 required for 5 cup supply dispenser for models starting 3/23/04
	C001004	Spring Hose Clamp	5 required for 5 cup supply dispenser; Models starting 3/23/04
	F200201	Hose Clamp	2 required for dispenser hose
	C000552	Hose	Flush hose for supply dispenser cups
1	C001007	Siphon Tube	
2	C001788	Dispenser Door Handle	
3	C000606	Front Cover	5 compartment
4	N/A	Lift-Off Hinge	Nylon; Models through 3/23/04
	C001787	Hinge	Nylon; Black; Models starting 3/23/04
5	C001017	Front Supply Dispenser Nozzle	
6	C000053	Supply Dispenser Cup	
7	C000052	Supply Dispenser Cup	
8	C000107	Dispenser Assembly	5 compartment

N/A = Part no longer available

Door Assembly - Models through 2/9/09 (Drawing 1 of 2) Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M,

Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHQ1 and JP060PMQ1




Door Assembly - Models through 2/9/09 (Drawing 1 of 2)

C000559 Bolt	REF	PART NO.	DESCRIPTION	COMMENTS
803017		C000559	Bolt	8 required for door hinge block to shell front
C000561 Bolt		C000574	Nut	8 required for door hinge block to shell front
handle hinge to door for models through 3/23/04; 3 required for door handle hinge to door for models starting 3/23/04		803017	Nut	2 required for door hinge block to hinge
Handle hinge to door		C000561	Bolt	handle hinge to door for models through 3/23/04; 3 required for door handle hinge to door for models starting
C000601 Stud 8 required for door glass retainer to door F431024 Nut 1 required for door handle to door handle hinge C001236 Nut 1 required for door handle to door handle bushing C001546 Door Bumper 2 required; Models starting 3/23/04 C001032 Screw 2 required for door bumper; Models starting 3/23/04 1 C003285 Door Gasket 2 F200001600P Shell Band Gasket 3 C001784 Bolt 4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000180 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 <		C000560	Nut	
F431024 Nut 1 required for door handle to door handle hinge C001236 Nut 1 required for door handle to door handle bushing C001546 Door Bumper 2 required; Models starting 3/23/04 C001032 Screw 2 required for door bumper; Models starting 3/23/04 1 C003285 Door Gasket 2 F200001600P Shell Band Gasket 3 C001784 Bolt 4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Spring Bushing 15 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt <th></th> <th>F431026</th> <th>Nut</th> <th>8 required for door glass retainer to door</th>		F431026	Nut	8 required for door glass retainer to door
C001236 Nut		C000601	Stud	8 required for door glass retainer to door
C001546 Door Bumper 2 required; Models starting 3/23/04		F431024	Nut	1 required for door handle to door handle hinge
C001032 Screw 2 required for door bumper; Models starting 3/23/04 1		C001236	Nut	1 required for door handle to door handle bushing
1 C003285 Door Gasket 2 F200001600P Shell Band Gasket 3 C001784 Bolt 4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt		C001546	Door Bumper	2 required; Models starting 3/23/04
2 F200001600P Shell Band Gasket 3 C001784 Bolt 4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt		C001032	Screw	2 required for door bumper; Models starting 3/23/04
3 C001784 Bolt 4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	1	C003285	Door Gasket	
4 C000176 Door Hinge Bushing 5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	2		Shell Band Gasket	
5 C000175 Hinge Block 6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	3	C001784	Bolt	
6 C000177 Washer 7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	4		9	
7 C000604 Door Hinge 8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	5	C000175	•	
8 C000190 Door Glass Gasket 9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	6	C000177	Washer	
9 C000603 Door Glass Retainer 10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	7	C000604	Door Hinge	
10 C000191 Door Glass 11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	8	C000190	Door Glass Gasket	
11 C001679P Door Handle 12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	9			
12 C002726 Door Assembly 13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	10			
13 C000181 Door Handle Bushing 14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	11			
14 C000192 Door Handle Spring Bushing 15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	12	C002726	-	
15 C001786 Door Handle Torsion Spring 16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	13			
16 C001785 Bolt 17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt	14	C000192		
17 C000470 Door Handle Hinge Weldment 18 C000180 Bolt				
18 C000180 Bolt	16			
	17	C000470	Door Handle Hinge Weldment	
19 C000077 Door Assembly Includes items 1-18				
	19	C000077	Door Assembly	Includes items 1-18

Door Assembly - Models through 2/9/09 (Drawing 2 of 2)

Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CPC40H, CPC40M, IP040PHN1, IP040PHQ1, IP040PHN1, IP040PHQ1, IP040PHQ1, IP040PHQ1, IP040PHQ1




PHM2775P_C002874

Door Assembly - Models through 2/9/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 4 required for door handle hinge to door for models through 3/23/04; 3 required for door handle hinge to door for models starting 3/23/04
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F431026	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C000177	Washer	
2	C000176	Door Hinge Bushing	
3	C000175	Hinge Block	
4	C001784	Bolt	
5	C000521P	Door Gasket	
6	C000522	Door Glass Gasket	
7	C000520P	Door Glass	
8	C000523	Door	
9	C000519	Door Glass Retainer	
10	C000681	Door Hinge	
11	C000181	Door Handle Bushing	
12	C000180	Bolt	
13	C001679P	Door Handle	
14	C000470	Door Handle Hinge Weldment	
15	C001786	Door Handle Torsion Spring	
16	C001785	Bolt	
17	C000192	Door Handle Spring Bushing	
18	C000524	Door Assembly	Models starting 3/23/04; Includes items 1-17

Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)

Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMX2, IP060PMX2, IP060PMX2, IP060PHX2, IP060PHX2,




Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 3 required for door handle hinge to door
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F431026	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C003285	Door Gasket	
2	F200001600P	Shell Band Gasket	
3	C001784	Bolt	
4	C000176	Door Hinge Bushing	
5	C000175	Hinge Block	
6	C000177	Washer	
7	C000604	Door Hinge	
8	C000190	Door Glass Gasket	
9	C000603	Door Glass Retainer	
10	C000191	Door Glass	
11	C001679P	Door Handle	
12	C002726	Door Assembly	
13	C000181	Door Handle Bushing	
14	C000192	Door Handle Spring Bushing	
15	C001786	Door Handle Torsion Spring	
16	C001785	Bolt	
17	C000470	Door Handle Hinge Weldment	
18	F431223	Pop Rivet	
19	F8390801	Magnet	
20	C002994	Door Magnet Mounting Bracket	
21	C000180	Bolt	
22	C000077	Door Assembly	Includes items 1-21

Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM3092P_C002874

Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 3 required for door handle hinge to door
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F431026	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C000177	Washer	
2	C000176	Door Hinge Bushing	
3	C000175	Hinge Block	
4	C001784	Bolt	
5	C000521P	Door Gasket	
6	C000522	Door Glass Gasket	
7	C000520P	Door Glass	
8	C000523	Door	
9	C000519	Door Glass Retainer	
10	C000681	Door Hinge	
11	C000181	Door Handle Bushing	
12	C000180	Bolt	
13	C001679P	Door Handle	
14	C000470	Door Handle Hinge Weldment	
15	C001786	Door Handle Torsion Spring	
16	C000192	Door Handle Spring Bushing	
17	C001785	Bolt	
18	F431223	Pop Rivet	
19	F8390801	Magnet	
20	C002994	Door Magnet Mounting Bracket	
21	C000524	Door Assembly	Includes items 1-20

Door Lock AssemblyModels Through Serial No. 0902007001




Door Lock Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	81398	Screw	4 required for door lock cover to solenoid bracket; Models starting 3/23/04
	C000613	Screw	2 required for door solenoid bracket to door lock plate; Models through 3/23/04
	C000614	Screw	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000578	Nut	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000561	Bolt	4 required for door lock to shell front
	C000574	Nut	4 required for door lock to shell front
	C000567	Screw	2 required for door latch to door lock plate
	C000571	Washer	2 required for door latch to door lock plate; Models starting 3/23/04
	C000572	Screw	2 required for door lock solenoid to bracket
	C000612	Screw	3 required for door lock catch to door lock plate
	C000430	Bolt	4 required for door solenoid bracket to door lock plate for models starting 3/23/04; 4 required for door lock cover to door lock plate for models through 3/23/04
	C000576	Nut	2 required for door lock cover to door lock plate
	C000867P	Door Lock Harness	
	C003291	Jump Wire	
1	C000688	Door Lock Cover	
2	C000431	Spring	
3	C000430	Bolt	
4	C000278	Door Lock Microswitch	
5	C000684	Door Lock Plate	
6	C000184P	Door Lock Solenoid	
7	C000185	Door Lock Catch	
8	C000276	Door Lock Slide Spring	
9	C000271	Door Lock Switch Slide	
10	N/A	Door Latch	Models through 3/23/04
	C001244	Door Latch	Models starting 3/23/04
11	C000687	Door Lock Spring Cover	
12	C003022	Door Lock Solenoid Bracket	
13	C002996M	Door Lock Kit	
	N/A	Door Lock Assembly	Includes items 1-12; Models through 7/14/11 with C001036P Door Lock Assembly MUST order C002996M Door Lock Kit

N/A = Part no longer available

Door Lock Assembly with Magnetic Sensor Models Starting Serial No. 0902007002




PHM3149P_C002874

Door Lock Assembly with Magnetic Sensor


REF	PART NO.	DESCRIPTION	COMMENTS
	81398	Screw	4 required for door lock cover to solenoid bracket; Models starting 3/23/04
	C000613	Screw	2 required for door solenoid bracket to door lock plate; Models through 3/23/04
	C000614	Screw	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracke
	C000578	Nut	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracke
	C000561	Bolt	4 required for door lock to shell front
	C000574	Nut	4 required for door lock to shell front
	C000567	Screw	2 required for door latch to door lock plate
	C000571	Washer	2 required for door latch to door lock plate; Models starting 3/23/04
	C000572	Screw	2 required for door lock solenoid to bracket
	C000612	Screw	3 required for door lock catch to door lock plate
	C000430	Bolt	4 required for door solenoid bracket to door lock plate for models starting 3/23/04; 4 required for door lock cover to door lock plate for models through 3/23/04
	C000576	Nut	2 required for door lock cover to door lock plate
	C000867P	Door Lock Harness	
	C003291	Jump Wire	
1	C000688	Door Lock Cover	
2	C000431	Spring	
3	C000278	Door Lock Microswitch	
4	C000430	Bolt	
5	C002995	Magnetic Door Switch Bracket	
6	C003000	Reed Switch Assembly	
7	C000684	Door Lock Plate	
8	J1111905	Blind Rivet	
9	C000184P	Door Lock Solenoid	
10	C000271	Door Lock Switch Slide	
11	C000276	Door Lock Slide Spring	
12	C000185	Door Lock Catch	
13	N/A	Door Latch	Models through 3/23/04
	C001244	Door Latch	Models starting 3/23/04
14	C000687	Door Lock Spring Cover	
15	C003022	Door Lock Solenoid Bracket	
16	B12351001	Door Lock Spring	Models starting 12/13/10 through 5/12/11
17	F431215	Pop Rivet	Models starting 12/13/10 through 5/12/11
18	C002996M	Door Lock Kit	Includes items 1-17

N/A = Part no longer available




PHM2736P_C002874

REF	PART NO.	DESCRIPTION	COMMENTS
	C002610P	Inlet Valve Harness	
	C000567	Screw	2 required for hot manifold to valve panel; 4 required for vacuum breaker to valve panel
	F431024	Nut	2 required for drain valve to drain valve mounting bracket; 2 required for hot manifold to valve panel
	C000610	Screw	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Hot water valve to vacuum breaker
	F8514701	Coil	Use with F8322904 Steam Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322904 Steam Valve
	F8379502	Valve Rebuild Kit	Use with F8322904 Steam Valve
1	C001366	Flange and Nipple Assembly	
2	F420403	Tee	
3	F420502	Street Elbow	
4	F420107	Nipple	
5	F381700P	Valve	Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit
	F380991P	Water Valve Repair Kit	3/4 inch; Use with F381700P Valve
	F8322904	Steam Valve	Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit
	F8521901	DIN Valve Kit	Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil
6	F380986P	DIN Coil	120 Volt
	F380987P	DIN Coil	240 Volt
7	F421951	Hose Barb	Brass
8	C000436P	Water Valve	
	G582P3	Diaphragm and Guide Kit	
9	C000424	Adapter	
10	C000420	Coupling	
11	C000426	Hot Plumbing Assembly	5 cup; Includes items 1-9




PHM2737P_C002874

C002608P	REF	PART NO.	DESCRIPTION	COMMENTS
Vacuum breaker to valve panel		C002608P	Inlet Valve Harness	
C000610 Screw 2 required for drain valve mounting bracket		C000567	Screw	
C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04		F431024	Nut	
Models through 3/23/04		C000610	Screw	2 required for drain valve to drain valve mounting bracket
Models starting 3/23/04		C000585	Washer	
F8514701 Coil Use with F8322904 Steam Valve		C000571	Washer	
F8382301 DIN Valve Adapter Kit Use with F8322904 Steam Valve F8379502 Valve Rebuild Kit Use with F8322904 Steam Valve 1		F200128P	Water Hose	Hot water valve to vacuum breaker
F8379502		F8514701	Coil	Use with F8322904 Steam Valve
1 C001664 Hot Plumbing Assembly Includes items 2-10 2 C001366 Flange and Nipple Assembly 3 F420502 Street Elbow 4 F420107 Nipple 5 F381700P Valve Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve F8322904 Steam Valve Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000420 Coupling		F8382301	DIN Valve Adapter Kit	Use with F8322904 Steam Valve
2 C001366 Flange and Nipple Assembly 3 F420502 Street Elbow 4 F420107 Nipple 5 F381700P Valve Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling		F8379502	Valve Rebuild Kit	Use with F8322904 Steam Valve
3 F420502 Street Elbow 4 F420107 Nipple Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit 5 F381700P Valve Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit F830991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve F8322904 Steam Valve Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	1	C001664	Hot Plumbing Assembly	Includes items 2-10
4 F420107 Nipple 5 F381700P Valve Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve F8322904 Steam Valve Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	2	C001366	Flange and Nipple Assembly	
5 F381700P Valve Replaced by F8322904 Steam Valve after being upgraded with F8521901 DIN Valve Kit F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve F8322904 Steam Valve Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	3	F420502	Street Elbow	
Upgraded with F8521901 DIN Valve Kit	4	F420107	Nipple	
F8322904 Steam Valve Replaces F381700P Valve; Includes F8514701 Coil; For models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	5	F381700P	Valve	
models that have been upgraded with F8521901 DIN Valve Kit F8521901 DIN Valve Kit Replaces F381700P Valve; Includes F8322904 Steam Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling		F380991P	Water Valve Repair Kit	3/4 inch; Use with F381700P Valve
Valve and F8514701 Coil 6 F380986P DIN Coil 120 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling		F8322904	Steam Valve	models that have been upgraded with F8521901 DIN
F380987P DIN Coil 240 Volt 7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling		F8521901	DIN Valve Kit	
7 F421951 Hose Barb Brass 8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	6	F380986P	DIN Coil	120 Volt
8 C000716P Valve 2-way G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling		F380987P	DIN Coil	240 Volt
G582P3 Diaphragm and Guide Kit 9 C000424 Adapter 10 C000420 Coupling	7	F421951	Hose Barb	Brass
9 C000424 Adapter 10 C000420 Coupling	8	C000716P	Valve	2-way
10 C000420 Coupling		G582P3	Diaphragm and Guide Kit	
1 3	9	C000424	Adapter	
11 F420403 Tee	10	C000420	Coupling	
	11	F420403	Tee	



PHM2738P_C002874


REF	PART NO.	DESCRIPTION	COMMENTS
	C002611P	Inlet Valve Harness	
	C000567	Screw	2 required for cold manifold to valve panel; 4 required for vacuum breaker to valve panel
	F431024	Nut	2 required for drain valve to drain valve mounting bracket; 2 required for cold manifold to valve panel
	C000610	Screw	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Cold water valve to vacuum breaker
1	C000425	Cold Plumbing Assembly	Includes items 2-9
2	C001366	Flange and Nipple Assembly	
3	F420107	Nipple	Galvanized
4	F420502	Street Elbow	Galvanized
5	F381700P	Valve	
	F380991P	Water Valve Repair Kit	3/4 inch
6	F380986P	DIN Coil	120 Volt
	F380987P	DIN Coil	240 Volt
7	F421951	Hose Barb	Brass
8	C000436P	Water Valve	3-way
	G582P3	Diaphragm and Guide Kit	
9	C000424	Adapter	
10	F420403	Tee	Galvanized



PHM2739P_C002874

REF	PART NO.	DESCRIPTION	COMMENTS
	C002608P	Inlet Valve Harness	
	C000567	Screw	2 required for cold manifold to valve panel; 4 required for vacuum breaker to valve panel
	F431024	Nut	2 required for drain valve to drain valve mounting bracket; 2 required for cold manifold to valve panel
	C000610	Screw	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Cold water valve to vacuum breaker
1	C001106	Cold Plumbing Assembly	Includes items 2-5
2	C001366	Flange and Nipple Assembly	
3	F381700P	Valve	
	F380991P	Water Valve Repair Kit	3/4 inch
4	F380986P	DIN Coil	120 Volt
	F380987P	DIN Coil	240 Volt
5	F421951	Hose Barb	
6	F420502	Street Elbow	Galvanized

Auxiliary Plumbing Assembly





PHM2740P_C002874

Auxiliary Plumbing Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	4 required for vacuum breaker to valve panel
	C000610	Screw	2 required for drain valve to drain valve mounting bracket
	F431024	Nut	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Auxiliary fill water valve to vacuum breaker
1	C001187	Auxiliary Plumbing Assembly	Includes items 2-4
2	C001366	Flange and Nipple Assembly	
3	F381700P	Valve	
	F380991P	Water Valve Repair Kit	3/4 inch
4	F421951	Hose Barb	

Supply Hose and Filter (Optional)






B091P_C002874

Supply Hose and Filter (Optional)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F270306P	Filter	Standard thread
	F270305	Filter	Metric thread
2	803615	Washer	Filter
3	F270406	Replacement Filter	.11 mm
	F270405	Replacement Filter	.25 mm
4	F270407	Filter Housing Cap Gasket	
5	803615	Washer	Filter
6	F200116	Water Hose	3/8 inch; Standard thread
	F200164	Water Hose	3/4 inch; Standard thread
	F200165	Water Hose	3/8 inch; Metric thread
	F200166	Water Hose	3/4 inch; Metric thread

Steam Heat Assembly

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




Steam Heat Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F8514701	Coil	Use with F8322802 Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322802 Valve
	F8379501	Valve Kit	Use with F8322802 Valve
1	C000775	Steam Hose	
2	C001003	Steam Hose Insulation	
3	C002748P	Steam Cord Assembly	
4	F380786P	Steam Valve	Brass; Replaced by F8322802 Valve after being upgraded with F8521601 DIN Valve Kit
	F8322802	Valve	Replaces F380786P Steam Valve; Includes F8514701 Coil; For models that have been upgraded with F8521601 DIN Valve Kit
	F8521601	DIN Valve Kit	Replaces F380786P Steam Valve; Includes F8322802 Valve and F8514701 Coil
5	C000981	Steam Valve Mounting Bracket	
6	C000999	Nipple	
7	C000733	Steam Valve Mounting Flange	
8	F603131	Steam Injector Tube Assembly	
9	F421703	Street Elbow	
10	C001009	Steam Option Assembly	Includes items 1-8

Steam Option Assembly


Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMX2, IP060PMX2, IP060PMX2, IP060PHX2, IP060PHX2,



Steam Option Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F8514701	Coil	Use with F8322802 Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322802 Valve
	F8379501	Valve Kit	Use with F8322802 Valve
1	C001002	Steam Option Assembly	Includes items 2-9
2	F421703	Street Elbow	
3	F603131	Steam Injector Tube Assembly	
4	C000736	Steam Hose	
5	C001003	Steam Hose Insulation	
6	C002748P	Steam Cord Assembly	
7	F380786P	Steam Valve	Brass; Replaced by F8322802 Valve after being upgraded with F8521601 DIN Valve Kit
	F8322802	Valve	Replaces F380786P Steam Valve; Includes F8514701 Coil; For models that have been upgraded with F8521601 DIN Valve Kit
	F8521601	DIN Valve Kit	Replaces F380786P Steam Valve; Includes F8322802 Valve and F8514701 Coil
8	C000981	Steam Valve Mounting Bracket	
9	C000999	Nipple	
10	C000733	Steam Valve Mounting Flange	

Shell Assembly (Drawing 1 of 2)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM2785P_C002874

Shell Assembly (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 1/10/10
	70391101	Screw	8 required for shell back to frame; Models starting 1/11/10
	C000599	Vacuum Breaker Hose	Air trap to water level switch; Models starting 3/23/04
1	C002975	Shell Front Assembly	
2	C001735	Shell Band and Clamp Weldment	
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001762	Shell Front Gasket	Models starting 3/23/04
4	C000518	Shell Assembly	

N/A = Part no longer available

Shell Assembly (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1



PHM2786P_C002874


Shell Assembly (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
	C000599	Vacuum Breaker Hose	Air trap to water level switch; Models starting 3/23/04
1	C002976P	Shell Front Assembly	
2	N/A	Shell Band Assembly	Models through 3/23/04
	F601216	Shell Gasket Shield	Models through 3/23/04
	C000659	Shell Band and Clamp Weldment	Models starting 3/23/04
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001763	Shell Front Gasket	Models starting 3/23/04
4	C000093	Shell Support	

N/A = Part no longer available

Electric Heat Shell Assembly (Drawing 1 of 2) Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H,

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




Electric Heat Shell Assembly (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
	C002755	Electric Heat Harness	
	C002756	Electric Heat Harness	
	C002724	Electric Heat Harness	Option 1
	C002830	Electric Heat Harness	Option 2
	C002758	Electric Heat Harness	200-240 Volt
1	C002975	Shell Front Assembly	
2	C001735	Shell Band and Clamp Weldment	
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001762	Shell Front Gasket	Models starting 3/23/04
4	C000949	Electric Heat Shell Assembly	
5	C000989	Heating Element	

N/A = Part no longer available

Electric Heat Shell Assembly (Drawing 2 of 2)


Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1



Electric Heat Shell Assembly (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001232	Air Trap Tube	Models through 3/23/04
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
1	C002976P	Shell Front Assembly	
2	N/A	Shell Band Assembly	Models through 3/23/04
	F601216	Shell Gasket Shield	Models through 3/23/04
	C000659	Shell Band and Clamp Weldment	Models starting 3/23/04
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001763	Shell Front Gasket	Models starting 3/23/04
4	C000950	Electric Heat Shell Assembly	
5	C000989	Heating Element	

Drive Box Assembly




PHM2747P_C002874

Drive Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000866	Rear Enclosure Harness	
	C000567	Screw	4 required for drive box to valve panel
	C000571	Washer	4 required for drive box to valve panel
	F430909	Screw	2 required for exhaust bracket to box; 4 required for chemical terminal mounting bracket to box for models through 3/23/04; 3 required for chemical terminal mounting bracket to box for models starting 3/23/04; 4 required for AC drive to box; 4 required for EMI filter to box; 4 required for transformer to box; 2 required for ground lug to box
	F431133	Washer	4 required for AC drive to box
	C000575	Screw	2 required for input power block to box
	F430938	Screw	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C000568	Nut	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C002779	Chemical Supply Harness	PT1
	C002780	Chemical Supply Harness	PT2
	C002781	Chemical Supply Harness	PT3
	C003020	Electric Heat Control Harness	
	F140602	Tie Wrap Mounting Clamp	
1	N/A	Circuit Breaker	Design 1 models; 1 Amp; 380-480 Volt; Order C0977P3 Circuit Breaker Kit
	N/A	Circuit Breaker	Design 1 models; 2 Amp; 200-240 Volt; Order C0978P3 Circuit Breaker Kit
	C0977P3	Circuit Breaker Kit	380-480 Volt; Includes F350217 Circuit Breaker
	C0978P3	Circuit Breaker Kit	200-240 Volt; Includes C003135 Circuit Breaker
	F350217	Circuit Breaker	Design 2 models or models that have been retrofitted with C0977P3 Circuit Breaker Kit; .5 Amp; 380-480 Volt
	C003135P	Circuit Breaker	Design 2 models or models that have been retrofitted with C0978P3 Circuit Breaker Kit; 1 Amp; 200-240 Volt
2	C000370	Power Block Terminal	12 pole; Chemical supply
3	C000373	Mounting Bracket	
4	C000203	Transformer	150VA
5	C000318	Thermostat	
6	C000323	Exhaust Bracket	
7	C001050	Drive Box Assembly	
8	C000290	Power Block Terminal	Non-electric heat models only
9	N/A	Ground Terminal	

N/A = Part no longer available

Electric Heat Drive Box Assembly




PHM2748P_C002874

Electric Heat Drive Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	4 required for drive box to valve panel
	C000571	Washer	4 required for drive box to valve panel
	F430909	Screw	2 required for exhaust bracket to box; 4 required for chemical terminal mounting bracket to box for models through 3/23/04; 3 required for chemical terminal mounting bracket to box for models starting 3/23/04; 4 required for AC drive to box; 4 required for EMI filter to box; 4 required for transformer to box; 2 required for ground lug to box
	F431133	Washer	4 required for AC drive to box
	C000575	Screw	2 required for input power block to box
	F430938	Screw	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C000568	Nut	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
1	C000308P	Contactor	400 Volt; 50 Amp
	C000309P	Contactor	200 Volt; 85 Amp
2	N/A	Circuit Breaker	Design 1 models; 1 Amp; 380-480 Volt; Order C0977P3 Circuit Breaker Kit
	N/A	Circuit Breaker	Design 1 models; 2 Amp; 200-240 Volt; Order C0978P3 Circuit Breaker Kit
	C0977P3	Circuit Breaker Kit	380-480 Volt; Includes F350217 Circuit Breaker
	C0978P3	Circuit Breaker Kit	200-240 Volt; Includes C003135 Circuit Breaker
	F350217	Circuit Breaker	Design 2 models or models that have been retrofitted with C0977P3 Circuit Breaker Kit
	C003135P	Circuit Breaker	Design 2 models or models that have been retrofitted with C0978P3 Circuit Breaker Kit
3	C000370	Power Block Terminal	Chemical supply
4	C000373	Mounting Bracket	
5	C000203	Transformer	
6	C000318	Thermostat	
7	C000323	Exhaust Bracket	
8	C001050	Drive Box Assembly	
9	M413865	Terminal Block	
10	N/A	Ground Lug Terminal	
11	C001194	Fuse	15 Amp; Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH60H, IPH60M and IPH270
	C001196	Fuse	10 Amp; All other models
12	C001197	Fuse Holder	

AC Drive and EMI Filter




PHM2747PA_C002874

AC Drive and EMI Filter

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000287	Inverter	200-240 Volt; 2 hp; Models CP040PHQ1, CP040PMQ1, CP060PMQ1, CPC40H, CPC40M, CPC60M, IP040PHQ1, IP040PMQ1, IP060PMQ1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	N/A	Inverter	200-240 Volt; 3 hp; Models CP060PHQ1, CPC60H, IP060PHQ1, IPH60H and JP060PHQ1; Order C003043 160-series to PowerFlex 40 Drive Kit
	C000288	Inverter	380-480 Volt; 2 hp; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180, IPH270 and JP040PHN1
	N/A	Inverter	380-480 Volt; 3 hp; Models CP060PHN1, CPC60H, IP060PHN1 and IPH60H; Order C003045 160-series to PowerFlex 40 Drive Kit
2	F330281	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F330280P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

AC Drive and EMI Filter - Electric Heat Models




PHM2748PA_C002874

AC Drive and EMI Filter - Electric Heat Models

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000287	Inverter	200-240 Volt; 2 hp; Models CP040PHQ1, CP040PMQ1, CP060PMQ1, CPC40H, CPC40M, CPC60M, IP040PHQ1, IP040PMQ1, IP060PMQ1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	N/A	Inverter	200-240 Volt; 3 hp; Models CP060PHQ1, CPC60H, IP060PHQ1, IPH60H and JP060PHQ1; Order C003043 160-series to PowerFlex 40 Drive Kit
	C000288	Inverter	380-480 Volt; 2 hp; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	N/A	Inverter	380-480 Volt; 3 hp; Models CP060PHN1, CPC60H, IP060PHN1 and IPH60H; Order C003045 160-series to PowerFlex 40 Drive Kit
2	F330281	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F330280P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

PowerFlex Drive and EMI Filter - Design 1 Models




PHM3028P_C002874

PowerFlex Drive and EMI Filter - Design 1 Models

REF	PART NO.	DESCRIPTION	COMMENTS
	C003028	Harness	
1	C003031	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP040, CPC40, IP040 and IPH40 M-series models; Models with LM26252 Lincoln Motor; Includes F8168603 AC Drive
	C003039	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 M-series models; Includes F8168603 AC Drive
	C003033	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP040, CPC40, IP040 and IPH40 M-series models; Models with LM26252 Lincoln Motor; Includes F8168604 AC Drive
	C003041	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 M-series models; Includes F8168604 AC Drive
	C003035	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP040, CPC40, IP040, IPH40 and JP040 H-series models; Includes F8168603 AC Drive
	C003043	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models; Includes F8168603 AC Drive
	C003046	PowerFlex 40 Drive	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models that have been retrofitted with C003045 160-series to PowerFlex 40 Drive Kit; Includes F8168604 AC Drive
	C003044	PowerFlex 40 Drive	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models that have been retrofitted with C003043 160-series to PowerFlex 40 Drive Kit; Includes F8168603 AC Drive
	C003037	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP040, CPC40, IP040, IPH40 and JP040 H-series models; Includes F8168604 AC Drive
	C003045	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models; Includes F8168604 AC Drive
2	F8053902	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F8053901P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

PowerFlex Drive and EMI Filter - Design 2 Models




PHM3028P_C002874

PowerFlex Drive and EMI Filter - Design 2 Models

REF	PART NO.	DESCRIPTION	COMMENTS
1	C003044	PowerFlex 40 Drive	200-240 Volt; Models CP060PHQ2, CP060PHX2, IP060PHN2, IP060PHX2 and JP060PHN2; Includes F8168603 AC Drive
	C003046	PowerFlex 40 Drive	380-480 Volt; Models CP060PHN2, IP060PHN2 and JP060PHN2; Includes F8168604 AC Drive
	C003032	PowerFlex 40 Drive	200-240 Volt; Models CP040PMX2 and IP040PMX2; Includes F8168603 AC Drive
	C003034	PowerFlex 40 Drive	380-480 Volt; Models CP040PMX2 and IP040PMX2; Includes F8168604 AC Drive
	C003036	PowerFlex 40 Drive	200-240 Volt; Models CP040PHX2 and IP040PHX2; Includes F8168603 AC Drive
	C003038	PowerFlex 40 Drive	380-480 Volt; Models CP040PHX2, IP040PHN2 and IP040PHX2; Includes F8168604 AC Drive
	C003040	PowerFlex 40 Drive	200-240 Volt; Models CP060PMX2, IP060PMN2 and IP060PMX2; Includes F8168603 AC Drive
	C003042	PowerFlex 40 Drive	380-480 Volt; Models CP060PMX2, IP060PMN2 and IP060PMX2; Includes F8168604 AC Drive
2	F8053902	EMI Filter	Models CP040PHX2, CP040PMX2, IP040PHX2 and IP040PMX2
	F8053901P	EMI Filter	Models CP060PHN2, CP060PHQ2, CP060PHX2, IP060PHN2 and JP060PHN2

Main Assembly (Drawing 1 of 8)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM2796P_C002874

Main Assembly (Drawing 1 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000680	Adapter	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000583	Washer	4 required for shell support bracket to shell
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker
	F200201	Hose Clamp	2 required for fill inlet hose
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04
	C000273	Bolt	2 required for shell support bracket to shell
	C000611	Nut	2 required for shell support bracket to shell
	C000567	Screw	4 required for vacuum breaker to valve panel
	F431024	Nut	4 required for vacuum breaker to valve panel; Models through 3/23/04
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04
1	C000379	Supply Dispenser Hose	
2	C002054	Shell Support Brace	Models starting 3/23/04
3	C000079	Lower Shell Support Bracket	
4	C000510	Temperature Probe Grommet	
5	C002636	Temperature Probe Assembly	
6	N/A	Frame Weldment	
7	C000378	Water Inlet Hose	
8	C000210	Fan Filter Guard Assembly	
9	C000390	Vacuum Breaker Assembly	
10	N/A	Grease Fitting	2 required; Models through 3/23/04
	C000549	Grease Fitting	2 required; Models starting 3/23/04
11	N/A	Grease Coupling	2 required; Models through 3/23/04
	C001789	Connector	2 required; Models starting 3/23/04
12	C000211	Fan	
13	C000317	Circuit Breaker	2 Amp

N/A = Part no longer available

Main Assembly (Drawing 2 of 8)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM2796PA_C002874

Main Assembly (Drawing 2 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000971	Overflow T-Drain Assembly	
	C002422	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	C002858	Dual Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	F200201	Hose Clamp	2 required for drain hose
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003316	Alignment Tool	
1	C000223P	Cylinder Bushing	
2	C002637P	Proximity Switch Assembly	
3	C000222	Cylinder Pulley	
4	C000599	Vacuum Breaker Hose	
5	C000662	Air Trap Tube	Brass
6	C000654	Air Trap Tube Elbow	Rubber
7	C000224	Motor Pulley	
8	C001053	Belt	
9	F280233P	Bushing	
10	C000130	Motor Bracket	
11	C000205	Motor	
12	N/A	Belt Tension Spring	Models through 3/23/04
	C001800	Belt Tension Spring	Models starting 3/23/04
13	C000412	Water Reuse Hose	
14	C001793	Сар	Models starting 3/23/04
15	C000347	Drain Valve	2 required
16	C001649	Reducing Connector	2 required; Models starting 3/23/04 through 3/6/13
17	C000377	Overflow Hose	
18	C000411	Drain Hose	

Main Assembly (Drawing 3 of 8)
Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1




PHM2797P_C002874

Main Assembly (Drawing 3 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS		
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C000680 Adapter		6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C001772	Vacuum Breaker Cover	Models starting 3/23/04		
	C000583	Washer	4 required for shell support bracket to shell		
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker		
	F200201	Hose Clamp	2 required for fill inlet hose		
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04		
	C000273	Bolt	2 required for shell support bracket to shell		
	C000611	Nut	2 required for shell support bracket to shell		
	C000567	Screw	4 required for vacuum breaker to valve panel		
	C002617P	Single Fan Harness			
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04		
	F431024	Nut	4 required for vacuum breaker to valve panel; Models through 3/23/04		
1	C000390	Vacuum Breaker Assembly			
2	N/A	Grease Fitting	2 required; Models through 3/23/04		
	C000549	Grease Fitting	2 required; Models starting 3/23/04		
3	N/A	Grease Coupling	2 required; Models through 3/23/04		
	C001789	Connector	2 required; Models starting 3/23/04		
4	C000211	Fan			
5	C000317	Circuit Breaker	2 Amp		
6	C000210	Fan Filter Guard Assembly			
7	C000379	Supply Dispenser Hose			
8	C000079	Lower Shell Support Bracket			
9	C002636	Temperature Probe Assembly			
10	C000510	Temperature Probe Grommet			
11	C002054	Shell Support Brace	Models starting 3/23/04		
12	C000780	Frame Assembly			
13	C000378	Water Inlet Hose			
		· · · · · · · · · · · · · · · · · · ·			

Main Assembly (Drawing 4 of 8)
Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1




PHM2797PA_C002874

Main Assembly (Drawing 4 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C002422	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	C002858	Dual Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	F200201	Hose Clamp	2 required for drain hose
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003315	Alignment Tool	
1	C000662	Air Trap Tube	Brass
2	C000654	Air Trap Tube Elbow	Rubber
3	C000791P	Motor Pulley	
4	C000130	Motor Bracket	
5	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
6	C000204	Motor	
7	F280233P	Bushing	
8	C000411	Drain Hose	
9	N/A	Belt	Models through 3/23/04
	C001264	Belt	Models starting 3/23/04
10	C000347	Drain Valve	
11	C001649	Reducing Connector	2 required; Models starting 3/23/04 through 3/6/13
12	C000377	Overflow Hose	
13	C000222	Cylinder Pulley	
14	C000599	Vacuum Breaker Hose	
15	C000746	Cylinder Bushing	
16	C002637P	Proximity Switch Assembly	

Main Assembly (Drawing 5 of 8)
Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M, IPH180 and JP060PMQ1




PHM2795P_C002874

Main Assembly (Drawing 5 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS		
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C000680 Adapter		6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C000583	Washer	4 required for shell support bracket to shell		
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker		
	F200201	Hose Clamp	2 required for fill inlet hose		
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04		
	C000273	Bolt	2 required for shell support bracket to shell		
	C000611	Nut	2 required for shell support bracket to shell		
	C000567	Screw	4 required for vacuum breaker to valve panel		
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04		
1	C000379	Supply Dispenser Hose			
2	C000516	Lower Shell Support Bracket			
3	C000510	Temperature Probe Grommet			
4	C002636	Temperature Probe Assembly			
5	C002055	Shell Support Brace			
6	C000813	Frame Assembly			
7	C000677	Water Inlet Hose			
8	C000210	Fan Filter Guard Assembly			
9	N/A	Grease Fitting	2 required; Models through 3/23/04		
	C000549	Grease Fitting	2 required; Models starting 3/23/04		
10	N/A	Grease Coupling	2 required; Models through 3/23/04		
	C001789	Connector	2 required; Models starting 3/23/04		
11	C001772	Vacuum Breaker Cover			
12	C000390	Vacuum Breaker Assembly			
13	C000317	Circuit Breaker	2 Amp		
14	C000211	Fan			

Main Assembly (Drawing 6 of 8)
Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M, IPH180 and JP060PMQ1




PHM2948P_C002874

Main Assembly (Drawing 6 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000662	Air Trap Tube	Brass
	C002421	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	F200201	Hose Clamp	2 required for drain hose
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003313	Alignment Tool	
1	C000746	Cylinder Bushing	
2	C000599	Vacuum Breaker Hose	
3	C000654	Air Trap Tube Elbow	Rubber
4	C001053	Belt	
5	C001051P	Motor Pulley	
6	C000689	Motor Bracket	
7	C000994	Spring Clip	
8	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
9	C000204	Motor	
10	F280233P	Bushing	
11	C000411	Drain Hose	
12	C000222	Cylinder Pulley	
13	F200165100	Drain Hose	No. 56
14	F200201	Hose Clamp	No. 56
15	C000347	Drain Valve	
16	C000676	Overflow Hose	
17	C001649	Reducing Connector	2 required; Models through 3/6/13

N/A = Part no longer available

Main Assembly (Drawing 7 of 8)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1




PHM2794P_C002874

Main Assembly (Drawing 7 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS		
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C000680 Adapter		6 required; Models through 3/23/04; Use with old style vacuum breaker		
	C000583	Washer	4 required for shell support bracket to shell		
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker		
	F200201	Hose Clamp	2 required for fill inlet hose		
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04		
	C000273	Bolt	2 required for shell support bracket to shell		
	C000611	Nut	2 required for shell support bracket to shell		
	C000567	Screw	4 required for vacuum breaker to valve panel		
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04		
	C002617P	Single Fan Harness			
1	C001772	Vacuum Breaker Cover	Models starting 3/23/04		
2	C000390	Vacuum Breaker Assembly			
3	N/A	Grease Fitting	2 required; Models through 3/23/04		
	C000549	Grease Fitting	2 required; Models starting 3/23/04		
4	N/A	Grease Coupling	2 required; Models through 3/23/04		
	C001789	Connector	2 required; Models starting 3/23/04		
5	C000211	Fan			
6	C000317	Circuit Breaker	2 Amp		
7	C000210	Fan Filter Guard Assembly			
8	C000677	Water Inlet Hose			
9	C000379	Supply Dispenser Hose			
10	C002636	Temperature Probe Assembly			
11	C000516	Lower Shell Support Bracket	Models starting 3/23/04		
	C000988	Lower Shell Support Bracket	Electric heat models starting 3/23/04		
12	C000510	Temperature Probe Grommet			
13	C002055	Shell Support Brace	Models starting 3/23/04		
14	C000445	Frame Assembly			

Main Assembly (Drawing 8 of 8)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1



PHM2947P_C002874

Main Assembly (Drawing 8 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C002421	Motor Cable	
	C000304	Motor Cable	
	C000994	Spring Clip	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	F200201	Hose Clamp	2 required for drain hose
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003314	Alignment Tool	
1	20391	Hose Clamp	
2	C001053	Belt	
3	C000204	Motor	
4	C000689	Motor Bracket	
5	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
6	C000690P	Motor Pulley	
7	C000691P	Motor Bushing	
8	C000411	Drain Hose	
9	C000347	Drain Valve	
10	C001649	Reducing Connector	Models starting 3/23/04 through 3/6/13
11	C000676	Overflow Hose	
12	C000552	Hose	
13	C000223P	Cylinder Bushing	
14	C000222	Cylinder Pulley	
15	C000662	Air Trap Tube	Brass
16	C000654	Air Trap Tube Elbow	Rubber

Notes

Parts Index

A
Adapter C000424 55, 57, 59 C000680 91, 95, 99, 103
Air Trap Tube C000662
Air Trap Tube Elbow C000654 93, 97, 101, 105
Alignment Tool C003313
Č001187 63
В
Battery 209/00505/04P35
Bearing Housing C000057
Bearing Housing Assembly C000058P
Bearing Housing Puller Kit 1390P
Bearing Lubrication Decal C000508
Belt C001053
Belt Tension Spring C001790
Blind Rivet53
Bolt C000180
Bushing F280233P 93, 97, 101
<u>с</u>
Сар
C00179393

Carb Bearing
C00015115 C00048519
Chemical Supply Controller C000371P35
Chemical Supply Harness
C00277979
C00278079
C00278179
Circuit Breaker C00031791, 95, 99, 103
C000317
F35021779, 81
Circuit Breaker Kit
C0977P3
C0978P379, 81
Clean Filter Daily Decal F20006100013
Coil
F851470155, 57, 67, 69
Cold Plumbing Assembly
C000425
Cold Water Valve Decal
F231368
Connector
C00178991, 95, 99, 103 J140800415, 17, 19, 21, 23, 25
Contact Block Switch
F20023340127, 29
Contactor C000308P81
C000309P81
Control Module Harness
C00086535
Control Panel Decal
C001069
C001276
Control Panel Insert
C00048327, 29
C00048427, 29
Coupling C00042055, 57
Cover Decal
F2003182009, 11
Cylinder Assembly Kit
C000037P
C000455P
C000792P
Cylinder Bolt Shroud
C00123837
Cylinder Bushing
C000223P93, 105
C000223P
C000223P93, 105

Cylinder Shaft C000068	Door Lock Kit C002996M51, 53
C000726	Door Lock Microswitch
	C00027851, 53 Door Lock Plate
D	C00068451, 53
Diaphragm and Guide Kit	Door Lock Slide Spring C00027651, 53
G582P3	Door Lock Solenoid C000184P51, 53
F380986P 55, 57, 59, 61	Door Lock Solenoid Bracket
F380987P 55, 57, 59, 61 DIN Valve Adapter Kit	C00302251, 53 Door Lock Spring
F8382301 55, 57, 67, 69	B1235100153
DIN Valve Kit F852160167, 69	Door Lock Spring Cover C00068751, 53
F8521901	Door Lock Switch Slide C00027151, 53
Dispenser Assembly C000107	Door Magnet Mounting Bracket
Dispenser Door Handle C001788	C00299447, 49
Door	Door Release Decal C00069411, 13
C000523	Drain Harness
Door Assembly C000077	C00261393, 97, 101, 105 C002614P93, 97, 101, 105
C000524	Drain Hose
Door Bumper 43, 47	C00041193, 97, 101, 105 F200165100101
C001546 43, 45, 47, 49	Drain T
Door Gasket C000521P	C00329593, 97, 101, 105
C00328543, 47	Drain Valve C00034793, 97, 101, 105
Door Glass C00019143, 47	Drive Box Assembly C00105079, 81
C000520P45, 49	Drive Kit, 160-Series to PowerFlex 40
Door Glass Gasket C000190	C003031
C00052245, 49	C003035
Door Glass Retainer C000519	C00303787 C00303987
C000603	C003039
Door Handle	C00304387
C001679P	C00304587
Door Handle Bushing C000181	Dual Drain Harness C00285893, 97
Door Handle Hinge Weldment C00047043, 45, 47, 49	
Door Handle Spring Bushing	E
C000192	Electric Heat Control Harness
C001786 43, 45, 47, 49	C00302079
Door Hinge C00060443, 47	Electric Heat Harness C00272475
C00068145, 49	C00275575
Door Hinge Bushing C000176	C00275675 C00275875
Door Latch	C002830
C001244 51, 53 Door Lock Catch	Electric Heat Shell Assembly C00094975
C00018551, 53	C000950
Door Lock Cover C00068851, 53	Electric Shock Danger Label F811550113
Door Lock Harness	Electrical Shock Label 50251111
C000867P 51, 53	JUZJ11 []

N/A items do not appear in index.

Emergency Stop Button Kit F200233700P	27		
Emergency Stop Pushbutton		G	
F200233500	27, 29	Gasket	
EMI Filter		C001704	15, 19
F330280P	,	Grease Connector Box	
F330281		C000539	31, 33
F8053901P		Grease Fitting	
F8053902	87, 89	C000549	91, 95, 99, 103
Exhaust Bracket C000323	79, 81	Grease Shield C000064	15
External Supply Connection Decal		000000	
F230917-1			
F8150201	13	Н	
F		Hardware Kit C002023	17, 21, 23, 25
		Harness	
Fan C0002119	1 95 99 103	C003028	87
Fan Filter Guard Assembly	1, 00, 00, 100	Heating Element	
C0002109	1, 95, 99, 103	C000989	75, 77
Filter		Hinge C001787	20 /1
F270305			
F270306P	65	Hinge Block C000175	43. 45. 47. 49
Filter Housing Cap Gasket F270407	05	Hose	
	65	C00055215, 17,	19, 21, 23, 25, 39,
Flange and Nipple Assembly C00136655,	57 59 61 63	41, 91	, 95, 99, 103, 105
Frame Assembly	07, 00, 01, 00	Hose Barb	FF F7 F0 01 00
C000445	103	F421951	55, 57, 59, 61, 63
C000780		Hose Clamp F20020115, 23, 3	20 41 01 02 05
C000813	99		99, 41, 91, 93, 95, 99, 101, 103, 105
Front Cover		F200213	
C000606	41	F200222	
Front Electrical Enclosure C000213	25	20391	
Front Electrical Enclosure Assembly	35	36801	
C000432	35	Hot Plumbing Assembly	
Front Electrical Enclosure Cover		C000426	55
C000348	35	C001664	57
Front Electrical Enclosure Rail		Hot Surface Warning Decal	
C000218		F200085000	
C000533	31	F231380	11
Front Grease Shield C000729	19	Hot Surface Warning Plate F8211901	13
Front Panel		Hot Water and Chemical Caution Decal	
C001246	27	F200085300	9, 13
C001248	29	Hot Water Valve Decal	
Front Panel Assembly		F231367	9
C002966			
C002967P			
C002968 C002969	_	1	
Front Skirt Panel			
C000314	33	Infrared Cable Kit 210/00902/00P	0.5
C000530			35
Front Supply Dispenser Nozzle		Inlet Power Cover C001257	31 33
C001017	39, 41	Inlet Valve Harness	
Fuse	04	C002608P	57, 61
C001194 C001196	_	C002610P	
Fuse Holder		C002611P	59
. 000 1 101001	04		

C000636	Insert Rail	Mounting Bracket
CO01013		C00037215, 17, 19, 23
Inverter	C001013 27	
## Agnet Common Switch Bracket Assembly Common Switch Bracket Assembly Common Switch Assem	Inverter	C00037535
No.		C00103721, 25
Jump Wire	,	
Jump Wire		
Jump Wire		N
F420107	U	Nipple
K Nut C000063 15 K C000487 19 C000560 43, 45, 47, 49, 51, 53 C000024P 27, 29 C000568 27, 29, 79, 81 Keypad Controller C000574 43, 45, 47, 49, 51, 53 51, 53 50, 53 C000282P 35 C000576 51, 53 50, 53 51, 53 50, 50 51, 53 50, 59, 61, 63, 71, 73, 75, 77, 91, 95, 99, 103 50, 53 51, 53 50, 50 71, 73, 75, 77, 91, 95, 99, 103 50, 59, 91, 63, 71, 73, 75, 77, 91, 95 99, 103 57, 59, 91, 63, 71, 73, 75, 77, 91, 95 99, 103 64, 34, 45, 47, 49, 58, 57, 79, 91, 95 74, 31024 27, 29, 31, 33, 34, 34, 47, 49, 34, 47, 49, 34, 47, 49, 37, 77, 71, 91, 95 74, 31024 27, 29, 31, 33, 34, 34, 47, 49, 34	Jump Wire	
K C000063 15 K C000447 19 C000560 43, 45, 47, 49 27, 29, 79, 81 C000568 2.27, 29, 79, 81 C00024P 27, 29 C000574 43, 45, 47, 49, 51, 53 C00028P 35 C000578 51, 53 C00028P 35 C000611 71, 73, 77, 79, 195, 99, 103 C001038 11 C001036 43, 45, 47, 49, 55, 55 F431024 27, 29, 31, 33, 35, 43, 45, 47, 49, 55, 57, 56, 16, 87, 77, 77, 77, 195, 59, 103, 37, 77, 77, 195, 59, 103, 37, 77, 77, 195, 59, 61, 63, 77, 77, 77, 77, 77, 77, 77, 77, 77, 7	C003291 51, 53	F42010755, 57, 59
K Keymode Switch Assembly C000024P		
Keymode Switch Assembly C003024P		
Keymode Switch Assembly C000024P 27, 29 C000574 43, 45, 47, 49, 51, 53 C000576 51, 53 C000576 51, 53 C000578 51	V	
Compage Comp	Λ	
C003024P 27,29 C000576 51,53 C000578	Keymode Switch Assembly	
Keypad Controller C000578 51,53 C000282P 35 C000611 71,73,75,77,91,99,9103 C001236 43,45,47,49 51,53 C0001236 43,45,47,49 57,59,61,63,71,73,75,77,91,55 57,93,45,47,49,33,45,47,49,49,33,47,49,49,33,47,49,49,33,47,49,49,33,47,49,49,33,47,49,49,49,34,47,49,33,47,49,49,33,47,49,49,33,47,49,49,49,34,47,49,33		
C000282P	Keynad Controller	
L Logo Decal C001038		
L Logo Decal C001038		
L Logo Decal C001038		
Logo Decal CO01038		
Logo Decal C001038	L	
Logo Decal		
Cover Front Adjustment Bracket Assembly		80301743, 45, 47, 49, 93, 97, 101, 105
C002984 27 C002985 29 Lower Shell Support Bracket		
C002985 29 Lower Shell Support Bracket		
Cower Shell Support Bracket		
C00079 91, 95 C000516 99, 103 C000988 103 C000676 101, 105 C000988 103 C000676 101, 105 C000971 9002071P 15, 17, 19, 21, 23, 25 M Magnet F8390801 47, 49 Magnetic Door Switch Bracket C002995 53 Main Board Controller Kit C000281P 35 Motor G000204 97, 101, 105 C000205 93 Motor Bracket C000191 105 C000689 101, 105 C000689 101, 105 C000242 93, 97 C000691P 105 C000242 93, 97 C000690P 105 C000690P 105 C000690P 105 C000691P 97 C000069P 105 C000690P 105 C000690P 105 C000690P 105 C000690P 105 C000691P 97 C0000690P 105 C000691P 97 C0000690P 105 C000691P 97 C0000691P 97 C0000690P 105 C000791P 97 C0000691P 97 C0000690P 105 C000791P 97 C0000691P 105 C000690P 105 C000691P		O
C000516 99, 103 C000377 93, 97 C000988 103 C000376 101, 105 C000666 101, 101, 105 C000271P 15, 17, 19, 21, 23, 25 Magnet F8390801 47, 49 Magnetic Door Switch Bracket C002995 53 Main Board Controller Kit C000281P 35 Motor C000204 97, 101, 105 C000205 93 Motor Bracket C000130 93, 97 C000689 101, 105 C000689 101, 105 C000689 101, 105 C000204 93, 97, 101, 105 C0002042 93, 97 C0000690P 105 C000090P 105 C0002037P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal	Lower Shell Support Bracket	Overflow Head
C000988		
Cooperation	,	
Magnet		•
MM P Magnet F8390801 47, 49 Pinched Fingers Label 502506 11 Magnetic Door Switch Bracket C002995 53 C001916 15, 19 Main Board Controller Kit C000281P 35 F431215 53 C000204 97, 101, 105 C000205 93 F431223 47, 49 Motor Bracket C000130 93, 97 C000689 101, 105 C003030 Power Block Terminal C000290 79 C000303 93, 97 C000689 PowerFlex 40 Drive C003032 89 C000304 93, 97, 101, 105 C003034 C003036 89 C003038 89 C0002421 101, 105 C002421 C003044 89 C000242 93, 97 C003044 87, 89 Motor Pulley C000690P C000791P C001051P 105 C003044 7000044 87, 89 Programming Key C002637P 15, 17, 19, 21, 23, 25, 93, 97 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label 11, 105 C003020 11, 105 C002020 15, 17, 19, 21, 23, 25, 93, 97	Lubricator	C000971 93
Magnet F8390801	9002071P15, 17, 19, 21, 23, 25	
Magnet F8390801	·	
F8390801	M	P
F8390801	Magnet	Pinched Fingers Label
Main Board Controller Kit	F839080147, 49	50250611
C002995 53 C001916 15, 19 Main Board Controller Kit C000281P 35 F431215 53 F431223 47, 49 Motor C000204 97, 101, 105 Power Block Terminal C000290 79 C000370 79, 81 Motor Bracket C000130 93, 97 C000370 79, 81 PowerFlex 40 Drive C003032 89 C000689 101, 105 C003034 89 C003034 89 Motor Bushing C000691P 105 C003036 89 C0003034 89 C003040 89 C0002421 101, 105 C003042 89 C0002422 93, 97 C003044 87, 89 Motor Pulley C000224 93 Programming Key 1242 27, 29 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal Push Decal Push Decal Mount On Concrete Warning Label Push Decal Push Decal Push Decal	Magnetic Door Switch Bracket	
Motor C000204	C002995 53	C00191615, 19
C000281P 35 F431215 53 Motor F431223 47, 49 C000204 97, 101, 105 Power Block Terminal C000290 79 C000130 93, 97 C000370 79, 81 Motor Bushing C000689 101, 105 C03032 89 C000691P 105 C03034 89 Motor Cable C003034 89 C000304 93, 97, 101, 105 C03040 89 C002421 101, 105 C03042 89 C002422 93, 97 C03044 87, 89 Motor Pulley 93 C03046 87, 89 C000224 93 C03046 87, 89 C000791P 97 C030690P 105 C000791P 97 C001051P 101 Mount On Concrete Warning Label Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal F230202 11, 12 F230202 11, 12	Main Board Controller Kit	
Motor C000204 97, 101, 105 Power Block Terminal C000290 79 Motor Bracket C000130 93, 97 PowerFlex 40 Drive C003032 89 Motor Bushing C000691P 105 C003034 89 Motor Cable C00304 93, 97, 101, 105 C003038 89 Motor Cable C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley C000224 93 C003044 87, 89 C000791P 97 C0000791P 97 C001051P 101 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal F320202 11, 12	C000281P	
C000204 97, 101, 105 Power Block Terminal 79 C000295 93 C000290 79 Motor Bracket 000130 93, 97 PowerFlex 40 Drive C000689 101, 105 C003032 89 Motor Bushing C003034 89 C000691P 105 C003036 89 C000304 93, 97, 101, 105 C003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley Programming Key C003046 87, 89 C000690P 105 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal Engage 11, 12	Motor	F43122347, 49
C000205 93 C000290 79 Motor Bracket 000130 93, 97 C000370 79, 81 C000689 101, 105 C003032 89 Motor Bushing C000691P 105 C003034 89 Motor Cable C000304 93, 97, 101, 105 C003038 89 C002421 101, 105 C003040 89 C002422 93, 97 C003044 87, 89 C0002244 93 C003046 87, 89 Motor Pulley C000224 93 C003046 87, 89 C000690P S000791P C000151P 97 Programming Key 1242 27, 29 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decaded Push Decaded 15, 17, 19, 21, 23, 25, 93, 97 Push Decaded Push Decaded 15, 17, 19, 21, 23, 25, 93, 97		
Motor Bracket 93, 97 PowerFlex 40 Drive C000130 93, 97 C003032 89 Motor Bushing C003034 89 C000691P 105 C003036 89 Motor Cable C00304 89 C000304 93, 97, 101, 105 C003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 C000242 93 C003046 87, 89 Motor Pulley Programming Key 1242 27, 29 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal F320232 11, 12	·	
C000130 93, 97 PowerFlex 40 Drive C000689 101, 105 C003032 89 Motor Bushing C000691P 105 C003034 89 Motor Cable C000304 93, 97, 101, 105 C003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley C000224 93 C003044 87, 89 C0000690P C000051P 105 C003044 87, 89 Mount On Concrete Warning Label Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal Push Decal F3202023 11, 12	Motor Bracket	C00037079, 81
C000689 101, 105 C003032 89 Motor Bushing C000691P 105 C003036 89 Motor Cable C000304 93, 97, 101, 105 C003038 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 C0002424 93, 97 C003044 87, 89 C0000690P C000690P C001051P 105 Programming Key 1242 27, 29 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal		PowerFlex 40 Drive
Motor Bushing C000691P 105 C003034 89 Motor Cable C000304 93, 97, 101, 105 C003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley C000224 93, 97 C003044 87, 89 C0000690P C000791P C001051P 105 Programming Key 1242 27, 29 Mount On Concrete Warning Label Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal F202023 11, 13		
C000691P 105 C003038 89 Motor Cable C0003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley Programming Key 1242 27, 29 C000791P 97 105 C001051P 101 Proximity Switch Assembly Mount On Concrete Warning Label Push Decal	·	
Motor Cable C003038 89 C000304 93, 97, 101, 105 C003040 89 C002421 101, 105 C003042 89 C002422 93, 97 C003044 87, 89 Motor Pulley 93, 97 C003046 87, 89 C000224 93 C003046 87, 89 C000690P 105 1242 27, 29 C001051P 97 C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal Mount Decal Fasanger 11, 13		
C000304 93, 97, 101, 105 C003042 89 C002421 101, 105 C003044 87, 89 C002422 93, 97 C003046 87, 89 Motor Pulley 93 C0000224 93 1242 27, 29 C000791P 97 7001051P 97 C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal		
C002421 101, 105 C003044 87, 89 C002422 93, 97 C003046 87, 89 Motor Pulley 93 C000690P 105 C000791P 97 97 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Mount On Concrete Warning Label Push Decal		
C002422 93, 97 C003046 87, 89 Motor Pulley Programming Key 1242 27, 29 C000690P 105 C000791P 97 C001051P 101 Mount On Concrete Warning Label Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal		
Motor Pulley C000224 93 C000690P 105 C000791P 97 C001051P 101 Mount On Concrete Warning Label Programming Key 1242 27, 29 Proximity Switch Assembly C002637P 15, 17, 19, 21, 23, 25, 93, 97 Push Decal		,
C000224	,	,
C000690P		
C000791P		,
C001051P		Proximity Switch Assembly
Mount On Concrete Warning Label Push Decal		
F8246401	Mount On Concrete Warning Label	
	F8246401	F23030311, 13

N/A items do not appear in index.

	Shell Assembly
R	C000518
	Shell Band and Clamp Weldment C00065973, 77
RC Network Assembly	C00173571, 75
C002999	
RC Network Filter	Shell Band Gasket F200001600P43, 47
F330217P	
Rear Electrical Enclosure Cover	Shell Front Assembly C00297571, 75
C000173 31, 33	C002976P73, 77
Rear Enclosure Harness	•
C00086679	Shell Front Gasket C00176271, 75
Rear Grease Shield	C00176271, 78
C000730 19	•
Rear Panel	Shell Gasket Shield F60121673, 77
C000051 33	
C000525 31	Shell Support
Reducing Connector	C00009373
CŎ01649 15, 17, 19, 21, 23, 25, 93, 97, 101, 105	Shell Support Brace
Reed Switch Assembly	C00205491, 95
C00300053	C00205599, 103
Replacement Filter	Side Panel and Stiffener Assembly
F27040565	C00269531
F270406	C00269631
	C00270733
Roller Bearing C000152	C00270833
C000486	Single Dispenser Assembly
	C00022039
Rub Rail C00063329	Single Fan Harness
C001012	C002617P95, 103
000101227	Single Front Dispenser Cover
_	C00060539
C	Siphon Tube
S	C00100739, 41
Screw	Spin Warning Decal
C000145 15, 17, 23	F2000851009, 13
C000567 27, 29, 31, 33, 35, 51, 53, 55, 57, 59,	Spring _
61, 63, 79, 81, 91, 95, 99, 103	C00043151, 53
C000572 51, 53	Spring Clip
C000575 79, 81	C000994101, 105
C000610 55, 57, 59, 61, 63	Spring Hose Clamp
C000612 51, 53, 93, 97, 101, 105	C0010044
C000613 51, 53	Standoff
C000614 51, 53	C00037635
C001018 15, 17, 19, 21, 23, 25	Steam Cord Assembly
C001019 19, 21, 25	C002748P67, 69
C001032 43, 45, 47, 49, 73, 75, 77	Steam Hose
C001093	C00073669
C001148 39, 41	C000775
C001294	
C001856	Steam Hose Insulation C00100367, 69
F43012493, 97, 101, 105 F43014493, 97, 101, 105	,
F43090935, 39, 41, 79, 81	Steam Injector Tube Assembly F60313167, 69
F43091027, 29, 35	
F430920	Steam Option Assembly
F430925	C00100269
F430929	C00100967
F430938	Steam Valve
7039110171	F380786P67, 69
81398 51, 53	F832290455, 57
Seal Plate	Steam Valve Mounting Bracket
C000065 15, 19	C00098167, 69
C000066	Steam Valve Mounting Flange
C000158 15	C00073367, 69
C000727 19	

Street Elbow	V-Ring Seal
F42050255, 57, 59, 61	C00006915, 19
F42170367, 69	C00007015
Stud	C00073119
C000601 43, 45, 47, 49	
Supply Dispenser Cup	
C00005239, 41	W
C000053 41	**
Supply Dispenser Hose	Warning Label
C00037991, 95, 99, 103	F823350113
Supply Signal Decal	44127701
C000506 9	50004911
	Washer
	C000071
T	C00017743, 45, 47, 49, 93, 97, 101, 105
	C00048819
Tee 57.50	C00055693, 97, 101, 105
F420403 55, 57, 59	C00057115, 17, 19, 21, 23, 25, 27, 29, 31, 33,
Temperature Probe Assembly C00263691, 95, 99, 103	35, 51, 53, 55, 57, 59, 61, 63, 79, 81
	C00058337, 71, 73, 75, 77, 91, 93,
Temperature Probe Grommet C00051091, 95, 99, 103	95, 97, 99, 101, 103, 105 C00058527, 29, 31, 33, 55, 57, 59, 61, 63
	C00058527, 29, 31, 33, 55, 57, 59, 61, 63
Terminal Block M41386581	C00123937
	F0431159-0037
Thermostat C00031879, 81	F43113335, 79, 81
Tie Wrap Mounting Clamp	80361565
F14060279	Water Hose
Tilt Switch Assembly	F20011665
C002642P	F200128P55, 57, 59, 61, 63
Top Panel	F200164
C00005029	F200166
C000513P27	Water Inlet Hose
Transformer	C00037891, 95
C00020379, 81	C000677
Trim Gasket	Water Line Caution Decal
C00062927, 29	F2307349
Triple Lip Seal	Water Reuse Hose
. C002959 15, 17, 19, 21, 23, 25	C00041293
Tubing	Water Valve
C000628P 15, 17, 19, 21, 23, 25	C000436P55, 59
	Water Valve Repair Kit
	F380991P55, 57, 59, 61, 63
V	
Vacuum Breaker Assembly	
C000390 91, 95, 99, 103	
Vacuum Breaker Cover C00177295, 99, 103	
• •	
Vacuum Breaker Hose C00059971, 73, 93, 97, 101	
Vacuum Breaker Plug C00067991, 95, 99, 103	
Valve C000716P 57	
F381700P 55, 57, 59, 61, 63	
F832280267, 69	
Valve Kit	
F837950167, 69	
Valve Panel Assembly	
C00297931	
C002980 33	
Valve Rebuild Kit	
F837950255, 57	
N/A items do not appear in index	

N/A items do not appear in index.