


PARTS ILLUSTRATION

IDLE/DRIVE BEARING ASSEMBLY

REF. No.	PART No.	DESCRIPTION	No. REQD.
1	A-8023	IDLE WHEEL ASSEMBLY	1
2	35024-1	BUSHING	1
3	35027-1	VFT-16 FLANGE BEARING	2
4	35117	IDLE SHAFT	1
5	16372-48	3/8"-24x1 1/4" BOLT	4
6	18445-4	3/8"-24 NUT	4
7	35103	NAME BACKING PLATE	1
8	16103-3	SNAP RING	1
9	35001	NAME PLATE	1
10	35000	BEARING PLATE	2

Idle Bearing Assembly



REF. No.	PART No.	DESCRIPTION	No. REQD.
1	A-8022	DRIVE WHEEL PLATE	1
2	35025-2	P-1 BUSHING	1
3	35027-2	VFT-19 FLANGE BEARING	2
4	35116	DRIVE SHAFT KEY	1
5	27101-7	1/4"x2 7/8" KEY	1
6	27101-3	1/4"x1 3/8" KEY	1
7	35041-7	50B-42 SPROCKET	1
8	16103-3	SNAP RING	1
9	16372-48	3/8"-24x1 1/4" BOLT	4
10	18445-4	3/8"-24 NUT	4
11	35000	DRIVE BEARING PLATE	2

Drive Bearing Assembly

