

PARTS ILLUSTRATION

COLLAR CLAMP

REF. No.	PART No.	DESCRIPTION	No. REQD.
1	34579	BASE	1
2	34576	COLLAR CLAMP BRACKET	1
3	16387-80	ROUND HEAD SCREW	2
4	34594	AIR CYLINDER	1
5	34425	10-32 ROD CLEVIS	1
6	A-3712	ARM	1
7	34304-2	BUSHING	1
8	34581	COLLAR CLAMP PIVOT PIN	1
9	34304-3	BUSHING	1
10	34580	GASKET	1
11	34774	COLLAR CLAMP SPOON	1
12	16388-22	FLAT WASHER	4
13	17776-22	ROLL PIN	1

REF. No.	PART No.	DESCRIPTION	No. REQD.
14	30889-19	BANJO FITTING	1
15	16387-4	ROUND HEAD SCREW	2
16	34472	COLLAR CLAMP PAD	1
17	16388-10	FLAT WASHER	2
18	25703-37	CLEVIS PIN	1
19	16654-15	COTTER PIN	1
20	A-3713	SNORKEL TUBE WELDMENT	1
21	34298-1	ROUND HEAD SCREW	4
22	16388-19	FLAT WASHER	2
23	16389-19	LOCKWASHER	2
24	34582	SPACER	2
25	16372-22	HEX HEAD CAP SCREW	2

COMPLETE COLLAR CLAMP
#A-3710

