




## **COMMERCIAL GAS DRYER**

### **MODELS:**

MDG20CSAWW0 (White)


# TOP AND CONSOLE PARTS



# TOP AND CONSOLE PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                               |
|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|--------------------------------|-----------------------------|-----------------|--------------------------------------------------|
| 1                           |                 | Literature Parts          | 12                          | W10662107       | Lamp, Indicator                | 23                          | W10386302       | Screw                                            |
|                             | W10868655       | Installation Instructions | 13                          | W10327105       | Switch, Cycle Selection        | 24                          | W10133509       | Funnel, Coin                                     |
|                             | W10167622       | Wiring Diagram            | 14                          | W10424310       | Switch, Push to Start          | 25                          | 3349065         | Bolt                                             |
| 2                           | W10139100       | Screw                     | 15                          | 8533971         | Screw                          | 26                          | W10510149       | Bezel - PTS                                      |
| 3                           | W10461070       | Bracket Control           | 16                          | W10863354       | Panel, Rear (Console)          | 27                          | 3954812         | Cushion, Meter Case                              |
| 4                           | W10461094       | Console                   | 17                          | 3390647         | Screw                          | 28                          | 3351136         | Assembly, Service Door                           |
| 5                           | 8317339         | Cover, Terminal Block     | 18                          | W10153108       | Harness, Main                  | 29                          | W10529172       | Meter Case                                       |
| 6                           | W10133502       | Indicator Lights Assembly | 19                          | 98139           | Screw                          | 30                          | W10156125       | Cam, Commercial Lock                             |
| 7                           | W10133507       | Knob                      | 20                          | W10135260       | Timer & Harness Assembly       | 31                          | W10153513       | Extension                                        |
| 8                           |                 | Top                       | 21                          | W10177793       | Harness, Timer                 | 32                          | 96435           | Screw                                            |
|                             | W10136707       | White                     | 22                          | 3387974         | Timing Cam, 3-Pin (60 Minutes) |                             |                 | ESD 270 New Jersey Dr. Fort Washington, PA 19034 |
| 9                           | 3347825         | Plate, Mounting           |                             | 343777          | Timing Cam, 6-Pin (30 Minutes) |                             |                 | 1-800-523-1510                                   |
| 10                          | 98445           | Screw                     |                             |                 |                                |                             |                 | info@esdcoin.com                                 |
| 11                          | W10845278       | Fascia                    |                             |                 |                                |                             |                 |                                                  |


# CABINET PARTS



# CABINET PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                                        |
|-----------------------------|-----------------|--------------------------------------------------------------|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|---------------------------------------------------------------------------|
| 1                           | 3391943         | Boot, Foot                                                   | 21                          |                 | Assembly, Hinge & Pin | 45                          | 342055          | Screw                                                                     |
| 2                           | 356674          | Cone, Wedge                                                  |                             | W10279703       | Silver                | 46                          | 3388229         | Retainer                                                                  |
| 3                           |                 | Plug, Hinge                                                  | 22                          | 8529757         | Bracket, Burner       | 47                          | W10323061       | Door, Rear                                                                |
|                             | W10191265       | White                                                        | 23                          | 3400077         | Screw                 | 48                          | W10836094       | Motor, Sound Pad                                                          |
| 4                           | 3391846         | Clip, Front Panel                                            | 24                          | 345670          | Lock Top              | 49                          | 3401797         | Burner Assembly (60 Hz)                                                   |
| 5                           | 3394881         | Switch - Belt                                                | 25                          | 3392186         | Washer                |                             |                 |                                                                           |
| 6                           | 697773          | Screw                                                        | 26                          | W10131123       | Nut, "U"              | 50                          | 8281911         | Valve, Gas (Complete) 60 Hz                                               |
| 7                           |                 | Cabinet                                                      | 27                          | W10396031       | Motor                 | 51                          | 343641          | Screw                                                                     |
|                             | W10547697       | White                                                        | 28                          | W10116360       | Handle, Door          | 52                          | 3389889         | Bracket, Support                                                          |
| 8                           | 3392100         | Foot, Dryer                                                  | 29                          | 3394341         | Pulley, Motor         | 53                          | 3390647         | Screw                                                                     |
|                             | 279810          | Foot, Optional (Extended Length Package Of 2) (Not Included) | 30                          | W10131172       | Belt, Drive           | 54                          |                 | Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting) |
| 9                           | 660658          | Clamp, Motor                                                 | 31                          | W10773242       | Screw                 |                             |                 |                                                                           |
| 10                          | W10446781       | Spring, Idler                                                | 32                          | 3387118         | Bracket, Motor        |                             |                 |                                                                           |
| 11                          | 3389420         | Screw                                                        | 33                          | 696144          | Strike, Door          |                             |                 |                                                                           |
| 12                          | 3398948         | Wire, Jumper (Broken Belt Switch)                            | 34                          |                 | Panel, Front          |                             | 279818          | Kit, Exhaust Vent                                                         |
|                             |                 |                                                              |                             | W10192882       | White                 | 55                          |                 | Multivent Plug                                                            |
| 13                          | W10344193       | Pulley-Idler Assembly                                        | 35                          |                 | Panel, Toe            |                             | 697750          | White                                                                     |
| 14                          | 3391915         | Screw                                                        |                             | 697215          | White                 | 56                          | 49026           | Elbow                                                                     |
| 15                          | 8066120         | Lever Switch                                                 | 36                          | 3401401         | Cord, Power           | 57                          | 488729          | Screw                                                                     |
| 16                          | W10167612       | Wire, Belt Switch                                            | 37                          | 3387561         | Clamp, Pipe           | 58                          | 3394331         | Plate, Cover                                                              |
| 17                          | 693152          | Bumper                                                       | 38                          | W10322546       | Door, Front           | 59                          | 8563747         | Pipe, Exhaust (Medium)                                                    |
| 18                          | 8066134         | Switch Assembly                                              | 39                          | 3392538         | Assembly, Door Catch  | 60                          | 8563750         | Pipe, Exhaust (Short)                                                     |
| 19                          | W10291934       | Clip                                                         | 40                          | 359625          | Screw                 | 61                          | 8563749         | Pipe, Exhaust (Long)                                                      |
| 20                          | 3393657         | Restrainer, Belt                                             | 41                          | 3406109         | Switch, Door          |                             |                 |                                                                           |
|                             |                 |                                                              | 42                          | 98129           | Screw                 |                             |                 |                                                                           |
|                             |                 |                                                              | 43                          | 3390735         | Seal, Door            |                             |                 |                                                                           |
|                             |                 |                                                              | 44                          | 3387242         | Seal, Front Panel     |                             |                 |                                                                           |

# BULKHEAD PARTS




# BULKHEAD PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                       | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|-------------------------------------------|-----------------------------|-----------------|------------------------------------------|-----------------------------|-----------------|----------------------|
| 1                           | W10359271       | Shaft, Drum Roller -<br>Right Hand Thread | 15                          | 697770          | Seal, Plate Cover                        | 29                          | 697693          | Baffle, Drum         |
| 2                           |                 | Lint Screen                               | 16                          | W10001120       | Nut, Hex (Left Hand<br>Thread)           | 30                          | W10685668       | Door, Lint Screen    |
|                             | W10596627       | White                                     | 17                          | 3387809         | Bulkhead, Rear                           | 31                          | 489463          | Screw                |
| 3                           | 8533971         | Screw                                     | 18                          | 3387459         | Washer                                   | 32                          | 3357011         | Screw                |
| 4                           | 90767           | Screw                                     | 19                          | W10359272       | Shaft, Drum Roller -<br>Left Hand Thread | 33                          | 3391912         | Thermostat, Hi Limit |
| 5                           | 3394346         | Assembly, Air Duct                        | 20                          | W10512946       | Washer, Tri Ring                         | 34                          | 338906          | Sensor, Radiant      |
| 6                           | 8066086         | Plug, Drum Hole                           | 21                          | W10314171       | Roller, Support                          | 35                          | 8573824         | Funnel, Burner       |
| 7                           | 697814          | Seal, Drum Front                          | 22                          | 3392519         | Fuse, Thermal (91C)                      | 36                          | 8066168         | Assembly, Lint Duct  |
| 8                           | 3934666         | Nut, Hex                                  | 23                          | W10685669       | Assembly, Outlet<br>Housing              | 37                          | W10349492       | Wheel, Blower        |
| 9                           | 8066224         | Pipe, Exhaust                             | 24                          | W10692558       | Grill, Outlet                            | 38                          | W10178810       | Thermostat           |
| 10                          | 8572105         | Clip, Exhaust                             | 25                          | W10545923       | Assembly, Drum                           | 39                          | W10135254       | Housing, Blower      |
| 11                          | 3387230         | Screw                                     | 26                          | W10219342       | Screw                                    | 40                          | 695240          | Screw                |
| 12                          | 3394986         | Spring, Lint Screen<br>Door               | 27                          | W10521118       | Seal, Drum                               | 41                          | 8573713         | Cut-Off, Thermal     |
| 13                          | 3390647         | Screw                                     | 28                          | 697557          | Bulkhead, Front                          | 42                          | 693995          | Screw                |
| 14                          | W10345456       | Clip, Spring                              |                             |                 |                                          | 43                          | W10131836       | Thermostat           |
|                             |                 |                                           |                             |                 |                                          | 44                          | 3401707         | Jumper, Wire         |

# BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL  
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES





# BURNER ASSEMBLY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                               |
|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|---------------------------------------------------|-----------------------------|-----------------|--------------------------------------------------|
| 1                           | 3401797         | Burner Assembly (60 Hz)     | 11                          | 694421          | Screw, Coil                                       | 20                          | 697441          | Valve, Gas                                       |
|                             |                 |                             | 12                          | 694538          | Bracket, Coil                                     | 21                          | 233076          | Nut, Compression                                 |
| 2                           | 688617          | Tube, Burner                | 13                          | 694540          | Coil, 60 Hz. (2 Terminal) (Main)                  | 22                          | 3393767         | Pipe, Tail                                       |
| 3                           | 694298          | Bracket, Ignitor            |                             |                 |                                                   |                             |                 | Following Parts Not Illustrated                  |
| 4                           | 686590          | Ignitor                     | 14                          | 694539          | Coil, 60 Hz (Split) (3 Terminal) (Pilot Position) |                             | 694572          | Conversion Kit (Type 1 and 2) to Type (4) L.P.G. |
| 5                           | 3393909         | Screw                       |                             |                 |                                                   |                             |                 |                                                  |
| 6                           | 343641          | Screw                       |                             |                 |                                                   |                             |                 |                                                  |
| 7                           | 3389871         | Base, Burner                | 15                          | 694424          | Leak, Limiter                                     |                             |                 |                                                  |
| 8                           | 3387057         | Screw                       | 16                          | 694423          | Screw, Regulator Adjustment                       |                             |                 |                                                  |
| 9                           |                 | Orifice, Burner             |                             |                 |                                                   |                             |                 |                                                  |
|                             | 3397656         | Type 1 (Natural Gas)        | 17                          | 694422          | Spring, Regulator                                 |                             |                 |                                                  |
|                             |                 |                             | 18                          | 239822          | Plug, Pipe                                        |                             |                 |                                                  |
| 10                          | 8281911         | Valve, Gas (Complete) 60 Hz | 19                          | W10110395       | Pipe, Gas Supply                                  |                             |                 |                                                  |

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 4392067         | Kit, Dryer Repair  |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 72017           | White              |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 350938          | Gray Primer        |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |