




COMMERCIAL ELECTRIC DRYER

MODELS:

MDG20MNAWW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Top	18	W10153155	Harness, Main
	W10868655	Installation Instructions		W10136704	White	19	98139	Screw
	W10167625	Wiring Diagram	9	W10386302	Screw	20	W10157942	Timer, Dryer
2	W10139100	Screw	10	W10510149	Bezel - PTS	21	W10133506	Skirt, Dial
3	W10461071	Back Bracket, Non-Coin	11	W10845280	Fascia	22	W10906058	Knob
4	W10461095	Console	12	W10662107	Lamp, Indicator	23	W10155650	Nut, Hex
5	8317339	Cover, Terminal Block	13	W10327105	Switch, Cycle Selection	24	W10133501	Cap, Knob
6	W10133502	Indicator Lights Assembly	14	W10424310	Switch, Push to Start			
7	W10133507	Knob	15	8533971	Screw			
			16	W10863352	Panel, Rear (Console)			
			17	3390647	Screw			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3391943	Boot, Foot	21	W10279703	Silver	46	3388229	Retainer
2	W10836094	Motor, Sound Pad	22	8529757	Bracket, Burner	47	W10323061	Door, Rear
3		Plug, Hinge	23	3400077	Screw	48	3401797	Burner Assembly (60 Hz)
	W10191265	White	24	345670	Lock Top	49	8281911	Valve, Gas (Complete) 60 Hz
4	3391846	Clip, Front Panel	25	3392186	Washer	50	343641	Screw
5	3394881	Switch - Belt	26	W10131123	Nut, "U"	51	3389889	Bracket, Support
6	697773	Screw	27	W10396031	Motor	52	3390647	Screw
7		Cabinet	28	W10116360	Handle, Door	53		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
	W10547697	White	29	3394341	Pulley, Motor		279818	Kit, Exhaust Vent
8	3392100	Foot, Dryer	30	W10131172	Belt, Drive	54		Multivent Plug
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	31	W10773242	Screw		697750	White
9	660658	Clamp, Motor	32	3387118	Bracket, Motor	55	49026	Elbow
10	W10446781	Spring, Idler	33	696144	Strike, Door	56	488729	Screw
11	3389420	Screw	34		Panel, Front	57	3394331	Plate, Cover
12	3398948	Wire, Jumper (Broken Belt Switch)		W10192882	White	58	8563747	Pipe, Exhaust (Medium)
13	W10344193	Pulley-Idler Assembly	35		Panel, Toe	59	8563750	Pipe, Exhaust (Short)
14	3391915	Screw		697215	White	60	8563749	Pipe, Exhaust (Long)
15	8066120	Lever Switch	36	3401401	Cord, Power			
16	W10167612	Wire, Belt Switch	37	3387561	Clamp, Pipe			
17	693152	Bumper	38	W10322546	Door, Front			
18	8066134	Switch Assembly	39	3392538	Assembly, Door Catch			
19	W10291934	Clip	40	359625	Screw			
20	3393657	Restrainer, Belt	41	3406109	Switch, Door			
			42	98129	Screw			
			43	3390735	Seal, Door			
			44	3387242	Seal, Front Panel			
			45	342055	Screw			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	15	697770	Seal, Plate Cover	29	697693	Baffle, Drum
2		Lint Screen	16	W10001120	Nut, Hex (Left Hand Thread)	30	W10685668	Door, Lint Screen
	W10596627	White	17	3387809	Bulkhead, Rear	31	489463	Screw
3	8533971	Screw	18	3387459	Washer	32	3357011	Screw
4	90767	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	33	3391912	Thermostat, Hi Limit
5	3394346	Assembly, Air Duct	20	W10512946	Washer, Tri Ring	34	338906	Sensor, Radiant
6	697557	Bulkhead, Front	21	W10314171	Roller, Support	35	8573824	Funnel, Burner
7	697814	Seal, Drum Front	22	3392519	Fuse, Thermal (91C)	36	8066168	Assembly, Lint Duct
8	3934666	Nut, Hex	23	W10685669	Assembly, Outlet Housing	37	W10349492	Wheel, Blower
9	8066224	Pipe, Exhaust	24	W10692558	Grill, Outlet	38	W10178810	Thermostat
10	8572105	Clip, Exhaust	25	W10545923	Assembly, Drum	39	W10135254	Housing, Blower
11	3387230	Screw	26	W10219342	Screw	40	695240	Screw
12	3394986	Spring, Lint Screen Door	27	W10521118	Seal, Drum	41	8573713	Cut-Off, Thermal
13	3390647	Screw	28	8066086	Plug, Drum Hole	42	693995	Screw
14	W10345456	Clip, Spring				43	W10131836	Thermostat
						44	3401707	Jumper, Wire

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3401797	Burner Assembly (60 Hz)	11	694421	Screw, Coil	20	697441	Valve, Gas
2	688617	Tube, Burner	12	694538	Bracket, Coil	21	233076	Nut, Compression
3	694298	Bracket, Ignitor	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	22	3393767	Pipe, Tail
4	686590	Ignitor	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)	Following Parts Not Illustrated		
5	3393909	Screw						
6	343641	Screw				694572		Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
7	3389871	Base, Burner	15	694424	Leak, Limiter			
8	3387057	Screw	16	694423	Screw, Regulator Adjustment			
9		Orifice, Burner						
	3397656	Type 1 (Natural Gas)	17	694422	Spring, Regulator			
10	8281911	Valve, Gas (Complete) 60 Hz	18	239822	Plug, Pipe			
			19	W10110395	Pipe, Gas Supply			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)