




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE26PDBYW1 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807485	Harness, Collar	18	W10133264	Assembly, Lock Access Door	33	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
2	W10139762	Nut, Hex	19	3397659	Block, Terminal	34	W10140858	Key, Access Door
3	W10155270	Cable Tie	20	3400408	Screw	35	279393	Screw Kit, Terminal Block
4	8533974	Screw	21	W10160652	Bracket-Switch	36	W10133266	Cam, Locking
5	W10140652	Screw	22	W10137319	Bolt, Hex Bar	37	W10133514	Standoff, Circuit Board
6	W10133285	Transformer 120Vac To 22.5Vac	23	W10862445	Collar	38	W10001120	Nut, Hex (Left Hand Thread)
7	8533971	Screw	24	W10850065	Cover, Terminal Block	39	3400000	Screw
8	W10177242	Nut, Hex	25	W10133258	Assembly, Vault Body	40	W10807493	Jumper, Lower to Collar
9	W10139046	Nut	26	W10133248	Box, Coin			Coin Mech. Parts May Be Ordered From Whpl or Vendor Below
10	W10386302	Screw	27	W10678217	Control Board			ESD 270 New Jersey
11	W10657185	Plate, Control Mounting	28	W10169579	Kit-Coin Box, Security (To be serviced as a kit)			Dr. Fort Washington, PA
12	W10111027	Jumper, Transformer	29		Coin Optic Sensor Assembly			19034 1-800-523-1510
13	W10684165	Facia Console		W10247389	White			info@esdcoin.com
14	W10133242	Assembly, Single Coin Drop	30	W10142655	Screw			
15	W10133268	Cover, Display	31	W10827406	Relay, Motor			
16	W10447152	Switch, Service Access	32	W10131838	Switch, Vault Service Door			
17	W10159907	Assembly, Mounting Strap Weld						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	19	W10291934	Clip	39	3392538	Assembly, Door Catch
	W10761033	Installation Instructions	20	W10807486	Harness, Upper/Lower	40		Panel, Toe
	W10135168	Tech Sheet	21		Hinge & Pin Assembly		697215	White
	W10738550	Wiring Diagram		W10279703	Silver	41	3406109	Switch, Door
2	3391915	Screw	22	8066134	Switch Assembly	42	W10322546	Door, Front
3	3390663	Screw	23	3394881	Switch - Belt	43	W10323061	Door, Rear
4	3391846	Clip, Front Panel	24	8066120	Lever Switch	44	3387242	Seal, Front Panel
5	3393657	Restrainer, Belt	25	98129	Screw	45	342055	Screw
6	697773	Screw	26	W10167612	Wire, Belt Switch	46	3388229	Retainer
7		Cabinet	27	3398948	Wire, Jumper (Broken Belt Switch)	47	W10576519	Seal, Deflector
	W10547697	White	28	W10396031	Motor	48		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
8	3392100	Foot, Dryer	29	3394341	Pulley, Motor		279818	White
9	660658	Clamp, Motor	30	3387610	Belt, Drive	49		Multivent Plug
10	W10446781	Spring, Idler	31	3390647	Screw		697750	White
11	3389420	Screw	32	3387118	Bracket, Motor	50	49026	Elbow
12	W10116360	Handle, Door	33	3392186	Washer	51	488729	Screw
13	W10344193	Pulley-Idler Assembly	34	693152	Bumper	52	3394331	Plate, Cover
14	3400077	Screw	35		Plug, Hinge			
15	3391943	Boot, Foot		W10191265	White			
16	W10212660	Motor, Sound Pad	36	696144	Strike, Door			
17	98997	Clip	37		Panel, Front			
18	3390735	Seal, Door		W10192882	White			
			38	8283298	Jumper, Door Switch			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	21	8066134	Switch Assembly	44	3387242	Seal, Front Panel
2	3391915	Screw	22	3394881	Switch - Belt	45	342055	Screw
3	3393657	Restrainer, Belt	23	8066120	Lever Switch	46	3388229	Retainer
4	3400077	Screw	24	98129	Screw	47		Plug, Hinge
5	689172	Foot, Dryer Plastic	25	W10167612	Wire, Belt Switch		W10191265	White
6	697773	Screw	26	3398948	Wire, Jumper (Broken Belt Switch)	48	W10323061	Door, Rear
7		Cabinet	27	W10396031	Motor	49	W10322546	Door, Front
	W10547697	White	28	3979115	Bracket, Angle	50	W10576519	Seal, Deflector
8	W10212660	Motor, Sound Pad	29	3394341	Pulley, Motor	51		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
9	660658	Clamp, Motor	30	3387610	Belt, Drive		279818	White
10	W10446781	Spring, Idler	31	3390735	Seal, Door			Multivent Plug
11	3389420	Screw	32	3387118	Bracket, Motor	52		697750 White
12		Top	33	693152	Bumper			49026 Elbow
	3389351	White	34	W10807486	Harness, Upper/Lower	53		488729 Screw
13	W10344193	Pulley-Idler Assembly	35	3390647	Screw	54		3394331 Plate, Cover
14		Panel, Toe	36	3392186	Washer			
	697215	White	37	3400523	Bolt, Security			
15	W10116360	Handle, Door	38	8283298	Jumper, Door Switch			
16	98997	Clip	39	696144	Strike, Door			
17	3391846	Clip, Front Panel	40	W10117347	Cotter Pin			
18	3392538	Assembly, Door Catch	41	3406109	Switch, Door			
19	W10291934	Clip	42		Panel, Front			
20		Hinge & Pin Assembly		W10192882	White			
	W10279703	Silver	43	3389233	Bushing			

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	17	8520836	Bulkhead, Rear	30		Screen, Lint
2	8066086	Plug, Drum Hole	18	3387459	Washer		W10596627	White
3	8533971	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	31	W10608837	Assembly, Weld Heater Box
4	90767	Screw	20	W10512946	Washer, Tri Ring	32	W10349492	Wheel, Blower
5	697354	Assembly, Air Duct	21	W10314171	Roller, Support	33	697557	Bulkhead, Front
6	W10181929	Assembly, Outlet Grill Housing (Complete)	22	3391914	Thermostat HL-295/215	34	W10131836	Thermostat
7	697814	Seal, Drum Front	23	697770	Seal, Plate Cover	35	3387230	Screw
8	3934666	Nut, Hex	24	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	36	W10135254	Housing, Blower
9	8066224	Pipe, Exhaust	25	W10545923	Assembly, Drum	37	8066168	Assembly, Lint Duct
10	8572105	Clip, Exhaust	26	W10219342	Screw	38	W10832958	Element, Heater
11	3357011	Screw	27	W10521118	Seal, Drum	39	8066099	Bracket, Heater Box
12	W10345456	Clip, Spring	28	3392519	Fuse, Thermal (91C)	40	W10193019	Thermostat, Electronic (155F)
13	3390647	Screw	29	8318314	Kit, Thermal Cut-Off (Includes High Limit Thermostat)	41	697693	Baffle, Drum
14	3402841	Lens, Drum Light						
15	8578825	Bracket, Drum Light						
16	W10001120	Nut, Hex (Left Hand Thread)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing