




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE26PDBYW2 (White)


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	16	W11378153	Cover, Terminal	35		Plug, Hinge
			17	98997	Clip		W10191265	White
	W10761033	Installation Instructions	18	3390735	Seal, Door	36	696144	Strike, Door
	W10866494	Tech Sheet	19	W10291934	Clip	37		Panel, Front
	W10738550	Wiring Diagram	20	W10807486	Harness, Upper/Lower		W10192882	White
2	3391915	Screw	21		Hinge & Pin Assembly	38	8283298	Jumper, Door Switch
3	3390663	Screw		W10279703	Silver	39	3392538	Assembly, Door Catch
4	3391846	Clip, Front Panel	22	8066134	Switch Assembly	40		Panel, Toe
5	3393657	Restrainer, Belt	23	3394881	Switch, Belt		697215	White
6	697773	Screw	24	8066120	Lever, Belt Switch	41	W10237959	Switch, Door
7		Cabinet	25	98129	Screw	42	W10322546	Door, Front
	W11161907	White	26	W10167612	Wire, Belt Switch	43	W10323061	Door, Rear
8	3392100	Foot, Dryer	27	3398948	Wire, Jumper (Broken Belt Switch)	44	3387242	Seal, Front Panel
9	660658	Clamp, Motor	28	W10396031	Motor	45	342055	Screw
10	W10446781	Spring, Idler	29	3394341	Pulley, Motor	46	3388229	Retainer
11	3389420	Screw	30	W10131172	Belt, Drive	47	W10576519	Seal, Deflector
12	W10116360	Handle, Door	31	3390647	Screw			DRYER EXHAUST KIT NOT INCLUDED
13	W10344193	Pulley-Idler Assembly	32	3387118	Bracket, Motor		W10323246	Kit, 4-Way Vent
14	W10879744	Screw	33	98139	Screw			
15	3391943	Boot, Foot	34	693152	Bumper			


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807485	Harness, Collar (Includes Motor Relay)	18	W10899602	Assembly, Lock Access Door	30	W10142655	Screw
2	3396795	Cover, Terminal Block	19	3397659	Block, Terminal	31	W10827406	Relay, Motor
3	W10155270	Cable Tie	20	3400408	Screw	32	W10131838	Switch, Vault Service Door
4	W10773242	Screw	21	W10160652	Bracket-Switch	33	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
5	W10140652	Screw	22	W10137319	Bolt, Hex Bar	34	98139	Screw
6	W10133285	Transformer 120Vac To 22.5Vac	23	W10862445	Collar	35	279393	Screw Kit, Terminal Block
7	8533971	Screw		337686	Screw	36	W10913660	Cam, Locking
8	3390814	Screw			Collar to Cabinet Flange	37	W10133514	Standoff, Circuit Board
9	W10139046	Nut		3400500	Bolt	38	W10001120	Nut, Hex (Left Hand Thread)
10	W10386302	Screw			Collar to Lower Cabinet	39	3400000	Screw
11	W10657185	Plate, Control Mounting	24	W10850065	Cover, Terminal Block	40	W10807493	Jumper, Lower to Collar
12	W10111027	Jumper, Transformer	25	W11109083	Assembly, Vault Body			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
13	W10684165	Facia Console	26	W11109086	Box, Coin			ESD 270 New Jersey Dr. Fort Washington, PA 19034 1-800-523-1510 info@esdcoin.com
14	W10133242	Assembly, Single Coin Drop	27	W11393069	Control Board			
15	W10133268	Cover, Display	28	W10169579	Kit-Coin Box, Security (To be serviced as a kit)			
16	W10447152	Switch, Service Access			Coin Optic Sensor Assembly			
17	W10159907	Assembly, Mounting Strap Weld	29					
				W10247389	White			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	19	W10291934	Clip	37	3400523	Bolt, Security
2	3391915	Screw	20		Hinge & Pin Assembly	38	8283298	Jumper, Door Switch
3	3393657	Restrainer, Belt		W10279703	Silver	39	696144	Strike, Door
4	W10879744	Screw	21	8066134	Switch Assembly	40	W10117347	Cotter Pin
5	345670	Lock Top	22	3394881	Switch, Belt	41	W10237959	Switch, Door
6	697773	Screw	23	8066120	Lever, Belt Switch	42		Panel, Front
7		Cabinet					W10192882	White
	W11161907	White	24	98129	Screw	43	3389233	Bushing
8	W11378153	Cover, Terminal	25	W10167612	Wire, Belt Switch	44	3387242	Seal, Front Panel
9	660658	Clamp, Motor	26	3398948	Wire, Jumper (Broken Belt Switch)	45	342055	Screw
10	W10446781	Spring, Idler				46	3388229	Retainer
11	3389420	Screw	27	W10396031	Motor	47		Plug, Hinge
12		Top	28	3979115	Bracket, Angle		W10191265	White
	3389351	White	29	3394341	Pulley, Motor	48	W10323061	Door, Rear
13	W10344193	Pulley-Idler Assembly	30	W10131172	Belt, Drive	49	W10322546	Door, Front
14		Panel, Toe	31	3390735	Seal, Door	50	W10576519	Seal, Deflector
	697215	White	32	3387118	Bracket, Motor			DRYER EXHAUST KIT NOT INCLUDED
15	W10116360	Handle, Door	33	693152	Bumper			
16	98997	Clip	34	W10807486	Harness, Upper/Lower		W10323246	Kit, 4-Way Vent
17	3391846	Clip, Front Panel	35	3390647	Screw			
18	3392538	Assembly, Door Catch	36	98139	Screw			

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	17	W11162455	Bulkhead, Rear	31	W10891205	Assembly, Weld Heater Box
2	8066086	Plug, Drum Hole	18	3387459	Washer	32	W10349492	Wheel, Blower
3	693995	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	33	697557	Bulkhead, Front
4	90767	Screw	20	W10512946	Washer, Tri Ring	34	W10131836	Thermostat
5	W11104018	Assembly, Air Duct	21	W10314171	Roller, Support	35	3387230	Screw
6	W10685669	Assembly, Outlet Housing	22	3391914	Thermostat HL-295/215	36	W10135254	Housing, Blower
7	W10692558	Grill, Outlet	23	697770	Seal, Plate Cover	37	8066168	Assembly, Lint Duct
8	3934666	Nut, Hex	24	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	38	W10832958	Element, Heater
9	8066224	Pipe, Exhaust				39	8066099	Bracket, Heater Box
10	8572105	Clip, Exhaust	25	W10545923	Assembly, Drum	40	W10193019	Thermostat, Electronic (155F)
11	3357011	Screw	26	W10219342	Screw	41	697693	Baffle, Drum
12	W10345456	Clip, Spring	27	W10521118	Seal, Drum	42	695240	Screw
13	3390647	Screw	28	3392519	Fuse, Thermal (91C)	43	8533971	Screw
14	3402841	Lens, Drum Light	29	8318314	Thermal Cut-Off	44	489463	Screw
15	8578825	Bracket, Drum Light	30	W10049370	Screen, Lint	45	697814	Seal, Drum Front
16	W10001120	Nut, Hex (Left Hand Thread)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing