




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE26PRBYW2 (White)


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	16	W10212660	Motor, Sound Pad	35		Plug, Hinge
	W10761033	Installation Instructions	17	98997	Clip		W10191265	White
	W10866494	Tech Sheet	18	3390735	Seal, Door	36	696144	Strike, Door
	W10738550	Wiring Diagram	19	W10291934	Clip	37		Panel, Front
2	3391915	Screw	20	W10807486	Harness, Upper/Lower		W10192882	White
3	3390663	Screw	21		Hinge & Pin Assembly	38	8283298	Jumper, Door Switch
4	3391846	Clip, Front Panel		W10279703	Silver	39	3392538	Assembly, Door Catch
5	3393657	Restrainer, Belt	22	8066134	Switch Assembly	40		Panel, Toe
6	697773	Screw	23	3394881	Switch, Belt		697215	White
7		Cabinet	24	8066120	Lever, Belt Switch	41	3406109	Switch, Door
	W11161907	White	25	98129	Screw	42	W10322546	Door, Front
8	3392100	Foot, Dryer	26	W10167612	Wire, Belt Switch	43	W10323061	Door, Rear
9	660658	Clamp, Motor	27	3398948	Wire, Jumper (Broken Belt Switch)	44	3387242	Seal, Front Panel
10	W10446781	Spring, Idler	28	W10396031	Motor	45	342055	Screw
11	3389420	Screw	29	3394341	Pulley, Motor	46	3388229	Retainer
12	W10116360	Handle, Door	30	W10131172	Belt, Drive	47	W10576519	Seal, Deflector
13	W10344193	Pulley-Idler Assembly	31	3390647	Screw			DRYER EXHAUST KIT NOT INCLUDED
14	3400077	Screw	32	3387118	Bracket, Motor		W10470674	Kit, 4-Way Venting
15	W11325273	Boot, Foot	33	3392186	Washer			
			34	693152	Bumper			


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807485	Harness, Collar (Includes Motor Relay)	15	W10133268	Cover, Display	30	W10163036	Bezel
2	W10133514	Standoff, Circuit Board	16	W10447152	Switch, Service Access	31	W10143462	Screw
3	W10155270	Cable Tie	17	W10145157	Retainer, Facia Cover	32	W10827406	Relay, Motor
4	W10773242	Screw	18	W10899602	Assembly, Lock Access Door	33	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
5	W10140652	Screw	19	3397659	Block, Terminal	34	3390814	Screw
6	W10133285	Transformer 120Vac To 22.5Vac	20	3400408	Screw	35	279393	Screw Kit, Terminal Block
7	8533971	Screw	21	W10160652	Bracket-Switch	36	W10913660	Cam, Locking
8	W10807493	Jumper, Lower to Collar	22	3400618	Screw			
9	W10139046	Nut	23	W10862446	Collar			
10	W10386302	Screw	24	W10850065	Cover, Terminal Block			
11	W10657185	Plate, Control Mounting	25	W10769481	Jumper, Coin Box			
12	W10111027	Jumper, Transformer	26	W11393069	Control Board			
13	W10678216	Facia Console	27	3400000	Screw			
14	W10137769	Cover, Card Reader	28	W10135263	Card Reader Conversion Kit			
			29	W10239515	Harness, Card Reader			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	19	W10291934	Clip	37	3400523	Bolt, Security
2	3391915	Screw	20		Hinge & Pin Assembly	38	8283298	Jumper, Door Switch
3	3393657	Restrainer, Belt		W10279703	Silver	39	696144	Strike, Door
4	3400077	Screw	21	8066134	Switch Assembly	40	W10117347	Cotter Pin
5	W11325273	Boot, Foot	22	3394881	Switch, Belt	41	3406109	Switch, Door
6	697773	Screw	23	8066120	Lever, Belt Switch	42		Panel, Front
7		Cabinet					W10192882	White
	W11161907	White	24	98129	Screw	43	3389233	Bushing
8	W10212660	Motor, Sound Pad	25	W10167612	Wire, Belt Switch	44	3387242	Seal, Front Panel
9	660658	Clamp, Motor	26	3398948	Wire, Jumper (Broken Belt Switch)	45	342055	Screw
10	W10446781	Spring, Idler				46	3388229	Retainer
11	3389420	Screw	27	W10396031	Motor	47		Plug, Hinge
12		Top	28	3979115	Bracket, Angle	48	W10323061	Door, Rear
	3389351	White	29	3394341	Pulley, Motor	49	W10322546	Door, Front
13	W10344193	Pulley-Idler Assembly	30	W10131172	Belt, Drive		W10191265	White
14		Panel, Toe	31	3390735	Seal, Door	50	W10576519	Seal, Deflector
	697215	White	32	3387118	Bracket, Motor			DRYER EXHAUST KIT NOT INCLUDED
15	W10116360	Handle, Door	33	693152	Bumper			
16	98997	Clip	34	W10807486	Harness, Upper/Lower		W10470674	Kit, 4-Way Venting
17	3391846	Clip, Front Panel	35	3390647	Screw			
18	3392538	Assembly, Door Catch	36	3392186	Washer			

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	18	3387459	Washer	34	W10131836	Thermostat
2	8066086	Plug, Drum Hole	19	W10359272	Shaft, Drum Roller - Left Hand Thread	35	3387230	Screw
3	8533971	Screw	20	W10512946	Washer, Tri Ring	36	W10135254	Housing, Blower
4	90767	Screw	21	W10314171	Roller, Support	37	8066168	Assembly, Lint Duct
5	W11104018	Assembly, Air Duct	22	3391914	Thermostat HL-295/215	38	W10832958	Element, Heater
6	697770	Seal, Plate Cover	23	W10685669	Assembly, Outlet Housing	39	8066099	Bracket, Heater Box
7	697814	Seal, Drum Front	24	W10692558	Grill, Outlet	40	W10193019	Thermostat, Electronic (155F)
8	3934666	Nut, Hex	25	W10545923	Assembly, Drum	41	697693	Baffle, Drum
9	8066224	Pipe, Exhaust	26	W10219342	Screw	42	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
10	8572105	Clip, Exhaust	27	W10521118	Seal, Drum	43	695240	Screw
11	3357011	Screw	28	3392519	Fuse, Thermal (91C)	44	693995	Screw
12	W10345456	Clip, Spring	29	8318314	Thermal Cut-Off			
13	3390647	Screw	30	W10049370	Screen, Lint			
14	3402841	Lens, Drum Light	31	W10891205	Assembly, Weld Heater Box			
15	8578825	Bracket, Drum Light	32	W10349492	Wheel, Blower			
16	W10001120	Nut, Hex (Left Hand Thread)	33	697557	Bulkhead, Front			
17	W11162455	Bulkhead, Rear						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing