




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE26PRFYW0 (White)

LOWER CABINET AND FRONT PANEL PARTS




Literature Parts

LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	15	3391943	Boot, Foot	35		Plug, Hinge
	W11647897	Installation Instructions	16	W10836097	Panel, Dampening		W10191265	White
	W11651037	Tech Sheet	17	98997	Clip	36	696144	Strike, Door
	W11463414	Installation Instructions, Card Reader	18	3390735	Seal, Door	37		Panel, Front
2	3391915	Screw	19	W10291934	Clip		W10192882	White
3	3390663	Screw	20	W10807486	Harness, Upper/Lower	38	8283298	Jumper, Door Switch
4	3391846	Clip, Front Panel	21		Hinge & Pin Assembly	39	3392538	Assembly, Door Catch
5	3393657	Restrainer, Belt		W10279703	Silver	40		Panel, Toe
6	697773	Screw	22	8066134	Switch Assembly		697215	White
7		Cabinet	23	3394881	Switch, Belt	41	W10237959	Switch, Door
	W11161907	White	24	8066120	Lever, Belt Switch	42	W10322546	Door, Front
8	3392100	Foot, Dryer	25	98129	Screw	43	W10323061	Door, Rear
9	660658	Clamp, Motor	26	W10167612	Wire, Belt Switch	44	3387242	Seal, Front Panel
10	W10446781	Spring, Idler	27	3398948	Wire, Jumper (Broken Belt Switch)	45	342055	Screw
11	3389420	Screw	28	W10396031	Motor	46	3388229	Retainer
12	W10116360	Handle, Door	29	3394341	Pulley, Motor	47	345670	Lock Top
13	W10344193	Pulley-Idler Assembly	30	W10131172	Belt, Drive			DRYER EXHAUST KIT NOT INCLUDED
14	W10879744	Screw	31	3390647	Screw		W10470674	Kit, 4-Way Venting
			32	3387118	Bracket, Motor			
			33	W10576519	Seal, Deflector			
			34	693152	Bumper			


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651083	Facia	17	W10913660	Cam, Locking	32	W10188051	Jumper, Line Filter
2	W10386302	Screw	18	W10160652	Bracket-Switch	33	W10769481	Jumper, Coin Box
3	W10137769	Cover, Card Reader	19	W10447152	Switch, Service Access	34	W10111027	Jumper, Transformer
4	W10145157	Retainer, Facia Cover	20	3400408	Screw	35	W10807493	Jumper, Lower to Collar
5	3400618	Screw	21	W11378153	Cover, Terminal	36	W10155270	Cable Tie
6	W10133268	Cover, Display	22	W10850065	Cover, Terminal Block	37	3400500	Bolt
7	W10657185	Plate, Control Mounting	23	3390814	Screw			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
8	W10140652	Screw	24	W11332324	Power Cord			Greenwald Industries 212 Middlesex Ave Chester, CT 06412 1-800-221-0982 sales@greenwaldindustries.com
9	W11582595	Control Board	25	W10773242	Screw			
10	W11455510	Collar	26	694415	Clip, Strain Relief			
11	W10133514	Standoff, Circuit Board	27	W11498818	Instructions, Installation (Card Reader)			
12	W10139046	Nut	28	W10239515	Harness, Card Reader			
13	W10133285	Transformer 120Vac To 22.5Vac	29	W10143462	Screw			
14	W10827406	Relay, Motor	30	W10163036	Bezel			
15	8533971	Screw	31	W10807485	Harness, Collar (Includes Motor Relay)			
16	W10899602	Assembly, Lock Access Door						


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	17	3391846	Clip, Front Panel	34	W10807486	Harness, Upper/Lower
2	3391915	Screw	18	3392538	Assembly, Door Catch	35	3390647	Screw
3	3393657	Restrainer, Belt	19	W10291934	Clip	36	W10576519	Seal, Deflector
4	W10879744	Screw	20		Hinge & Pin Assembly	37	3400523	Bolt, Security
5	W10322546	Door, Front		W10279703	Silver	38	8283298	Jumper, Door Switch
	W10191265	White	21	8066134	Switch Assembly	39	696144	Strike, Door
6	697773	Screw	22	3394881	Switch, Belt	40	W10117347	Cotter Pin
7		Cabinet	23	8066120	Lever, Belt Switch	41	W10237959	Switch, Door
	W11161907	White	24	98129	Screw	42		Panel, Front
8	W10836097	Panel, Dampening	25	W10167612	Wire, Belt Switch		W10192882	White
9	660658	Clamp, Motor	26	3398948	Wire, Jumper (Broken Belt Switch)	43	3389233	Bushing
10	W10446781	Spring, Idler	27	W10396031	Motor	44	3387242	Seal, Front Panel
11	3389420	Screw	28	3979115	Bracket, Angle	45	342055	Screw
12		Top	29	3394341	Pulley, Motor	46	3388229	Retainer
	3389351	White	30	W10131172	Belt, Drive	47		Plug, Hinge
13	W10344193	Pulley-Idler Assembly	31	3390735	Seal, Door	48	W10323061	Door, Rear
14		Panel, Toe	32	3387118	Bracket, Motor	49	345670	Lock Top
	697215	White	33	693152	Bumper			DRYER EXHAUST KIT NOT INCLUDED
15	W10116360	Handle, Door						
16	98997	Clip					W10470674	Kit, 4-Way Venting

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359272	Shaft, Drum Roller - Left Hand Thread	17	W11162455	Bulkhead, Rear	31	W10891205	Assembly, Weld Heater Box
2	8066086	Plug, Drum Hole	18	3387459	Washer	32	W10349492	Wheel, Blower
3	8533971	Screw	19	W10359271	Shaft, Drum Roller - Right Hand Thread	33	697693	Baffle, Drum
4	90767	Screw	20	W10512946	Washer, Tri Ring	34	W10131836	Thermostat
5	W11104018	Assembly, Air Duct	21	W10314171	Roller, Support	35	3387230	Screw
6	695240	Screw	22	3391914	Thermostat HL-295/215	36	W10135254	Housing, Blower
7	697814	Seal, Drum Front	23	3392519	Fuse, Thermal (91C)	37	8066168	Assembly, Lint Duct
8	3934666	Nut, Hex	24	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	38	W10832958	Element, Heater
9	8066224	Pipe, Exhaust	25	W10545923	Assembly, Drum	39	8066099	Bracket, Heater Box
10	8572105	Clip, Exhaust	26	W10219342	Screw	40	W10193019	Thermostat, Electronic (155F)
11	3357011	Screw	27	W10521118	Seal, Drum	41	W10685669	Assembly, Outlet Housing
12	697770	Seal, Plate Cover	28	697557	Bulkhead, Front	42	W10692558	Grill, Outlet
13	3390647	Screw	29	8318314	Thermal Cut-Off	43	693995	Screw
14	3402841	Lens, Drum Light	30	W10049370	Screen, Lint	44	489463	Screw
15	8578825	Bracket, Drum Light						
16	W10001120	Nut, Hex (Left Hand Thread)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	Paint, Touch-up (White 1/2 oz)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	Paint, Spray (White 12 oz)
	350938	Paint, Spray (12 oz Gray Primer)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	Paint, Bulk (White Uncut 1 qt)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing