




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE26PRKYW0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807485	Harness, Collar	17	W10145157	Retainer, Facia Cover	32	W10827406	Relay, Motor
2	W10139762	Nut, Hex	18	W10133264	Assembly, Lock Access Door	33	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
3	W10155270	Cable Tie	19	3397659	Block, Terminal	34	W10140858	Key, Access Door
4	W10773242	Screw	20	3400408	Screw	35	279393	Screw Kit, Terminal Block
5	W10140652	Screw	21	W10160652	Bracket-Switch	36	W10133266	Cam, Locking
6	W10133285	Transformer 120Vac To 22.5Vac	22	3400618	Screw	37	W10133514	Standoff, Circuit Board
7	8533971	Screw	23	W10862446	Collar	38	W10807493	Jumper, Lower to Collar
8	W10177242	Nut, Hex	24	W10850065	Cover, Terminal Block	39	3400000	Screw
9	W10139046	Nut	25	W10769481	Jumper, Coin Box			
10	W10386302	Screw	26	W10678217	Control Board			
11	W10657185	Plate, Control Mounting	27	W10169579	Kit-Coin Box, Security (To be serviced as a kit)			
12	W10111027	Jumper, Transformer	28	W10135263	Card Reader Conversion Kit			
13	W10678216	Facia Console	29	W10239515	Harness, Card Reader			
14	W10137769	Cover, Card Reader	30	W10163036	Bezel			
15	W10133268	Cover, Display	31	W10143462	Screw			
16	W10447152	Switch, Service Access						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	15	3391943	Boot, Foot	33	3392186	Washer
	W10761033	Installation Instructions	16	W10212660	Motor, Sound Pad	34	693152	Bumper
	W10135168	Tech Sheet	17	98997	Clip	35	8283298	Jumper, Door Switch
	W10738550	Wiring Diagram	18	3387242	Seal, Front Panel	36	3403431	Strike, Door
2	3391915	Screw	19	W10291934	Clip	37	W10694688	Panel, Front
3	3390663	Screw	20	W10807486	Harness, Upper/Lower	38		Cover, Strike
4	3391846	Clip, Front Panel	21	3406109	Switch, Door		W10521429	White
5	3393657	Restrainer, Belt	22	8066134	Switch Assembly	39	W10576519	Seal, Deflector
6	697773	Screw	23	3394881	Switch - Belt	40		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
7		Cabinet	24	8066120	Lever Switch		279818	White
	W10547697	White	25	98129	Screw	41		Multivent Plug
8	3392100	Foot, Dryer	26	W10167612	Wire, Belt Switch	42	697750	White
9	660658	Clamp, Motor	27	3398948	Wire, Jumper (Broken Belt Switch)	43	49026	Elbow
10	W10446781	Spring, Idler	28	W10396031	Motor	44	488729	Screw
11	3389420	Screw	29	3394341	Pulley, Motor	45	3394331	Plate, Cover
12	3388229	Retainer	30	3387610	Belt, Drive			
13	W10344193	Pulley-Idler Assembly	31		Panel, Toe			
14	3400077	Screw		697215	White			
			32	3387118	Bracket, Motor			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	17	3391846	Clip, Front Panel	36	3392186	Washer
2	3391915	Screw	18	3387242	Seal, Front Panel	37	3400523	Bolt, Security
3	3393657	Restrainer, Belt	19	W10291934	Clip	38	8283298	Jumper, Door Switch
4	3400077	Screw	20	3389233	Bushing	39	3403431	Strike, Door
5	689172	Foot, Dryer Plastic	21	8066134	Switch Assembly	40	W10117347	Cotter Pin
6	697773	Screw	22	3394881	Switch - Belt	41	3406109	Switch, Door
7		Cabinet	23	8066120	Lever Switch	42		Cover, Strike
	W10547697	White	24	98129	Screw		W10521429	White
8	W10212660	Motor, Sound Pad	25	W10167612	Wire, Belt Switch	43	W10576519	Seal, Deflector
9	660658	Clamp, Motor	26	3398948	Wire, Jumper (Broken Belt Switch)	44		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
10	W10446781	Spring, Idler	27	W10396031	Motor		279818	White
11	3389420	Screw	28	3979115	Bracket, Angle			Multivent Plug
12		Top	29	3394341	Pulley, Motor	45		
	3389351	White	30	3387610	Belt, Drive		697750	White
13	W10344193	Pulley-Idler Assembly	31	W10694688	Panel, Front	46	49026	Elbow
14		Panel, Toe	32	3387118	Bracket, Motor	47	488729	Screw
	697215	White	33	693152	Bumper	48	3394331	Plate, Cover
15	3388229	Retainer	34	W10807486	Harness, Upper/Lower			
	W10191265	White	35	3390647	Screw			
16	98997	Clip						

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10513690	Assembly, Inner Door
2	8519354	Retainer, Window
3		Hinge & Pin Assembly
	W10279703	Silver
4	342055	Screw
5	W10354795	Seal, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	3393258	Screw
7	W10192860	Screw
8	W10284122	Seal, Window
9	690081	Assembly, Door Catch
10	W10470571	Door, Inner
11	W10284121	Glass, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Door, Outer Assembly
	W10284127	White
13		Plug-Hinge Screw
	W10191265	White

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	17	8520836	Bulkhead, Rear	30		Screen, Lint
2	8066086	Plug, Drum Hole	18	3387459	Washer		W10596627	White
3	8533971	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	31	W10608837	Assembly, Weld Heater Box
4	90767	Screw	20	W10512946	Washer, Tri Ring	32	W10349492	Wheel, Blower
5	697354	Assembly, Air Duct	21	W10314171	Roller, Support	33	697557	Bulkhead, Front
6	W10181929	Assembly, Outlet Grill Housing (Complete)	22	3391914	Thermostat HL-295/215	34	W10131836	Thermostat
7	697814	Seal, Drum Front	23	697770	Seal, Plate Cover	35	3387230	Screw
8	3934666	Nut, Hex	24	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	36	W10135254	Housing, Blower
9	8066224	Pipe, Exhaust	25	W10545923	Assembly, Drum	37	8066168	Assembly, Lint Duct
10	8572105	Clip, Exhaust	26	W10219342	Screw	38	W10832958	Element, Heater
11	3357011	Screw	27	W10521118	Seal, Drum	39	8066099	Bracket, Heater Box
12	W10345456	Clip, Spring	28	3392519	Fuse, Thermal (91C)	40	W10193019	Thermostat, Electronic (155F)
13	3390647	Screw	29	8318314	Kit, Thermal Cut-Off (Includes High Limit Thermostat)	41	697693	Baffle, Drum
14	3402841	Lens, Drum Light						
15	8578825	Bracket, Drum Light						
16	W10001120	Nut, Hex (Left Hand Thread)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing