




COMMERCIAL ELECTRIC DRYER

MODELS:

MLE27PDBYW1 (White)

CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807485	Harness, Collar	18	W10133264	Assembly, Lock Access Door	33	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
2	W10139762	Nut, Hex	19	3397659	Block, Terminal			
3	W10155270	Cable Tie	20	3400408	Screw	34	W10140858	Key, Access Door
4	W10773242	Screw	21	W10160652	Bracket-Switch	35	279393	Screw Kit, Terminal Block
5	W10140652	Screw	22	W10137319	Bolt, Hex Bar	36	W10133266	Cam, Locking
6	W10133285	Transformer 120Vac To 22.5Vac	23	W10862445	Collar	37	W10133514	Standoff, Circuit Board
7	8533971	Screw	24	W10850065	Cover, Terminal Block	38	W10001120	Nut, Hex (Left Hand Thread)
8	W10177242	Nut, Hex	25	W10133258	Assembly, Vault Body	39	3400000	Screw
9	W10139046	Nut	26	W10133248	Box, Coin	40	W10807493	Jumper, Lower to Collar
10	W10386302	Screw	27	W10678217	Control Board			Coin Mech. Parts May Be Ordered From Whpl or Vendor Below
11	W10657185	Plate, Control Mounting	28	W10169579	Kit-Coin Box, Security (To be serviced as a kit)			ESD 270 New Jersey
12	W10111027	Jumper, Transformer	29		Coin Optic Sensor Assembly			Dr. Fort Washington, PA
13	W10684165	Facia Console		W10247389	White			19034 1-800-523-1510
14	W10133242	Assembly, Single Coin Drop	30	W10142655	Screw			info@esdcoin.com
15	W10133268	Cover, Display	31	W10827406	Relay, Motor			
16	W10447152	Switch, Service Access	32	W10131838	Switch, Vault Service Door			
17	W10159907	Assembly, Mounting Strap Weld						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	16	W10694688	Panel, Front	36	3388229	Retainer
	W10761035	Installation Instructions	17	98997	Clip	37	3387242	Seal, Front Panel
	W10135168	Tech Sheet	18	3405160	Belt, Drive (Blower Wheel)	38	8283298	Jumper, Door Switch
2	3391915	Screw	19	W10291934	Clip	39	98129	Screw
3	8564011	Bracket, Switch	20	W10212660	Motor, Sound Pad	40		Panel, Toe
4	3391846	Clip, Front Panel	21	3394341	Pulley, Motor		697215	White
5	8564010	Assembly, Switch and Actuator	22	8318396	Seal, Foam	41	W10167613	Wire, Belt Switch
6	697773	Screw	23	W10807486	Harness, Upper/Lower	42	8539892	Wire, Motor To Belt Switch
7		Cabinet	24	3392519	Fuse, Thermal (91C)	43		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
	W10547697	White	25	3403431	Strike, Door		279818	White
8	3392100	Foot, Dryer	26	3390647	Screw	44		Plug, Multivent
9	660658	Clamp, Motor	27	W10396034	Assembly, Motor 60 HZ.		49252	White
10	W10446781	Spring, Idler	28	W10155571	Switch, Assembly	45	49026	Elbow
11	3389420	Screw	29	3393657	Restrainer, Belt	46	488729	Screw
12	W10576519	Seal, Deflector	30	W10131172	Belt, Drive	47	3394331	Plate, Cover
13	W10344192	Assembly, Idler	31	3406109	Switch, Door			
14	3400077	Screw	32	W10135695	Bracket, Motor			
15		Cover, Strike	33	3392186	Washer			
	W10521429	White	34	693152	Bumper			
			35	3391943	Boot, Foot			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390647	Screw	19	W10291934	Clip	38	8283298	Jumper, Door Switch
2	3391915	Screw	20	3394341	Pulley, Motor	39	3389233	Bushing
3	8564011	Bracket, Switch	21	8318396	Seal, Foam	40	W10117347	Cotter Pin
4	3400077	Screw	22		Top	41	3406109	Switch, Door
5	689172	Foot, Dryer Plastic		3389351	White	42	98129	Screw
6	697773	Screw	23	3979115	Bracket, Angle	43	3403431	Strike, Door
7		Cabinet	24		Panel, Toe	44	W10167613	Wire, Belt Switch
	W10547697	White		697215	White	45	8539892	Wire, Motor To Belt
8	3400523	Bolt, Security	25	W10807486	Harness, Upper/Lower			Switch
9	660658	Clamp, Motor	26	3392519	Fuse, Thermal (91C)	46		Optional Parts Not
10	W10446781	Spring, Idler	27	W10396034	Assembly, Motor 60 HZ.			Included Dryer Exhaust
11	3389420	Screw	28	W10155571	Switch, Assembly			Kit (For Side & Bottom
12	W10576519	Seal, Deflector	29	3393657	Restrainer, Belt		279818	Venting)
13	W10344192	Assembly, Idler	30	W10131172	Belt, Drive	47		White
14	3405160	Belt, Drive (Blower	31	98997	Clip		49252	White
		Wheel)	32	W10135695	Bracket, Motor	48	49026	Elbow
15		Cover, Strike	33	693152	Bumper	49	488729	Screw
	W10521429	White	34	W10694688	Panel, Front	50	3394331	Plate, Cover
16	8564010	Assembly, Switch and	35	3388229	Retainer			
		Actuator	36	3392186	Washer			
17	3391846	Clip, Front Panel	37	3387242	Seal, Front Panel			
18	W10212660	Motor, Sound Pad						

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10513690	Assembly, Inner Door
2	8519354	Retainer, Window
3		Hinge & Pin Assembly
	W10279703	Silver
4	342055	Screw
5	W10354795	Seal, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	3393258	Screw
7	W10192860	Screw
8	W10284122	Seal, Window
9	690081	Assembly, Door Catch
10	W10470571	Door, Inner
11	W10284121	Glass, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Door, Outer Assembly
	W10284127	White
13		Plug-Hinge Screw
	W10191265	White

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	17	8520836	Bulkhead, Rear	30		Screen, Lint
2	8066086	Plug, Drum Hole	18	3387459	Washer		W10596627	White
3	8533971	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	31	W10608837	Assembly, Weld Heater Box
4	90767	Screw	20	W10512946	Washer, Tri Ring	32	W10349492	Wheel, Blower
5	697354	Assembly, Air Duct	21	W10314171	Roller, Support	33	697557	Bulkhead, Front
6	W10181929	Assembly, Outlet Grill Housing (Complete)	22	3391914	Thermostat HL-295/215	34	W10131836	Thermostat
7	697814	Seal, Drum Front	23	697770	Seal, Plate Cover	35	3387230	Screw
8	3934666	Nut, Hex	24	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	36	W10135254	Housing, Blower
9	8066224	Pipe, Exhaust	25	W10545923	Assembly, Drum	37	8066168	Assembly, Lint Duct
10	8572105	Clip, Exhaust	26	W10219342	Screw	38	W10832958	Element, Heater
11	3357011	Screw	27	W10521118	Seal, Drum	39	8066099	Bracket, Heater Box
12	W10345456	Clip, Spring	28	3392519	Fuse, Thermal (91C)	40	W10193019	Thermostat, Electronic (155F)
13	3390647	Screw	29	8318314	Kit, Thermal Cut-Off (Includes High Limit Thermostat)	41	697693	Baffle, Drum
14	3402841	Lens, Drum Light						
15	8578825	Bracket, Drum Light						
16	W10001120	Nut, Hex (Left Hand Thread)						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security