




## **COMMERCIAL GAS DRYER**

### **MODELS:**

MLG26PRBWW0 (White)


## CONTROL PANEL AND SEPARATOR PARTS



# CONTROL PANEL AND SEPARATOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|----------------------------|-----------------------------|-----------------|-------------------------|
| 1                           | W10702047       | Harness, Collar               | 16                          | W10447152       | Switch, Service Access     | 30                          | W10163036       | Bezel                   |
| 2                           | W10160652       | Bracket-Switch                | 17                          | W10145157       | Retainer, Facia Cover      | 31                          | W10143462       | Screw                   |
| 3                           | W10155270       | Cable Tie                     | 18                          | W10133264       | Assembly, Lock Access Door | 32                          | W10306592       | Filter, RFI             |
| 4                           | W10773242       | Screw                         | 19                          | W10140858       | Key, Access Door           | 33                          | 3401850         | Harness, Gas            |
| 5                           | W10140652       | Screw                         | 20                          | W10139762       | Nut, Hex                   | 34                          | 694415          | Clip, Strain Relief     |
| 6                           | W10133285       | Transformer 120Vac To 22.5Vac | 21                          | W10177242       | Nut, Hex                   | 35                          | W10188051       | Jumper, Line Filter     |
| 7                           | 8533971         | Screw                         | 22                          | 3400618         | Screw                      | 36                          | W10913660       | Cam, Locking            |
| 8                           | 3400408         | Screw                         | 23                          | W10678213       | Collar                     | 37                          | W10133514       | Standoff, Circuit Board |
| 9                           | W10139046       | Nut                           | 24                          | 3396795         | Cover, Terminal Block      | 38                          | W10702055       | Jumper, Lower to Collar |
| 10                          | W10386302       | Screw                         | 25                          | W10769481       | Jumper, Coin Box           | 39                          | 3400000         | Screw                   |
| 11                          | W10657185       | Plate, Control Mounting       | 26                          | W10678217       | Control Board              | 40                          | W10684155       | Cover, Terminal Block   |
| 12                          | W10111027       | Jumper, Transformer           | 27                          | W10581952       | Power Cord                 |                             |                 |                         |
| 13                          | W10678216       | Facia Console                 | 28                          | W10135263       | Card Reader Conversion Kit |                             |                 |                         |
| 14                          | W10137769       | Cover, Card Reader            | 29                          | W10239515       | Harness, Card Reader       |                             |                 |                         |
| 15                          | W10133268       | Cover, Display                |                             |                 |                            |                             |                 |                         |


# LOWER CABINET AND FRONT PANEL PARTS



# LOWER CABINET AND FRONT PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                   | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                |
|-----------------------------|-----------------|---------------------------------------------------|-----------------------------|-----------------|--------------------------------------|-----------------------------|-----------------|-----------------------------------|
| 1                           |                 | Literature Parts<br>(Located Behind Toe<br>Panel) | 16                          | 3387242         | Seal, Front Panel                    | 40                          | W10116360       | Handle, Door                      |
|                             | W10761033       | Installation<br>Instructions                      | 17                          | 3391915         | Screw                                | 41                          | 3406109         | Switch, Door                      |
|                             | W10135168       | Tech Sheet                                        | 18                          | 8066134         | Switch Assembly                      | 42                          | W10291934       | Clip                              |
|                             | W10738549       | Wiring Diagram                                    | 19                          | 8066120         | Lever Switch                         | 43                          |                 | Hinge & Pin Assembly              |
|                             | W10135291       | Instructions,<br>Installation (Card<br>Reader)    | 20                          | 3394881         | Switch - Belt                        |                             | W10279703       | Silver                            |
| 2                           | 693152          | Bumper                                            | 21                          | 3398948         | Wire, Jumper (Broken<br>Belt Switch) | 44                          | 98997           | Clip                              |
| 3                           | 3390663         | Screw                                             | 22                          | W10167612       | Wire, Belt Switch                    | 45                          | 3389889         | Bracket, Support                  |
| 4                           | 3391846         | Clip, Front Panel                                 | 23                          | 98129           | Screw                                | 46                          | W10576519       | Seal, Deflector                   |
| 5                           |                 | Plug, Hinge                                       | 24                          | 3390647         | Screw                                | 47                          | 3391943         | Boot, Foot                        |
|                             | W10191265       | White                                             | 25                          | W10323061       | Door, Rear                           | 48                          | 3401797         | Burner Assembly (60<br>Hz)        |
| 6                           | 3400077         | Screw                                             | 26                          | 3388229         | Retainer                             | 49                          | 3393909         | Screw                             |
| 7                           |                 | Cabinet                                           | 27                          | W10396031       | Motor                                | 50                          | 686590          | Ignitor                           |
|                             | W10547697       | White                                             | 28                          | 3393657         | Restrainer, Belt                     | 51                          | 3387057         | Screw                             |
| 8                           | 3392100         | Foot, Dryer                                       | 29                          | 3394341         | Pulley, Motor                        | 52                          | 8281911         | Valve, Gas (Complete)<br>60 Hz    |
| 9                           | 660658          | Clamp, Motor                                      | 30                          | 3387610         | Belt, Drive                          | 53                          | 343641          | Screw                             |
| 10                          | W10446781       | Spring, Idler                                     | 31                          | 342055          | Screw                                | 54                          | 693995          | Screw                             |
| 11                          | 3389420         | Screw                                             | 32                          | 3387118         | Bracket, Motor                       | 55                          | 8529757         | Bracket, Burner                   |
| 12                          | W10344193       | Pulley-Idler Assembly                             | 33                          | 3392186         | Washer                               | 56                          | 3387561         | Clamp, Pipe                       |
| 13                          | 697773          | Screw                                             | 34                          | W10702046       | Harness                              |                             |                 | DRYER EXHAUST<br>KIT NOT INCLUDED |
| 14                          |                 | Panel, Front                                      | 35                          | 3390735         | Seal, Door                           |                             |                 |                                   |
|                             | W10192882       | White                                             | 36                          | 3392538         | Assembly, Door Catch                 |                             |                 |                                   |
| 15                          | 696144          | Strike, Door                                      | 37                          | W10322546       | Door, Front                          |                             | W10470674       | Kit, 4-Way Venting                |
|                             |                 |                                                   | 38                          | 8283298         | Jumper, Door Switch                  |                             |                 |                                   |
|                             |                 |                                                   | 39                          |                 | Panel, Toe                           |                             |                 |                                   |
|                             |                 |                                                   |                             | 697215          | White                                |                             |                 |                                   |


# UPPER CABINET AND FRONT PANEL PARTS



# UPPER CABINET AND FRONT PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|-----------------------------------|-----------------------------|-----------------|---------------------|-----------------------------|-----------------|--------------------------------|
| 1                           | 3390663         | Screw                             | 23                          | 98129           | Screw               | 46                          |                 | Plug, Hinge                    |
| 2                           | 693152          | Bumper                            | 24                          | W10116360       | Handle, Door        |                             | W10191265       | White                          |
| 3                           | 3391846         | Clip, Front Panel                 | 25                          | 3389233         | Bushing             | 47                          | 98997           | Clip                           |
| 4                           | 3391915         | Screw                             | 26                          | 3387118         | Bracket, Motor      | 48                          | 3389889         | Bracket, Support               |
| 5                           | W10702046       | Harness                           | 27                          | W10396031       | Motor               | 49                          | W10576519       | Seal, Deflector                |
| 6                           | 3392538         | Assembly, Door Catch              | 28                          | 3393657         | Restrainer, Belt    | 50                          | 3391943         | Boot, Foot                     |
| 7                           |                 | Cabinet                           | 29                          | 3394341         | Pulley, Motor       | 51                          | 3401797         | Burner Assembly (60 Hz)        |
|                             | W10547697       | White                             | 30                          | 3387610         | Belt, Drive         | 52                          | 3393909         | Screw                          |
| 8                           | 689172          | Foot, Dryer Plastic               | 31                          |                 | Panel, Front        | 53                          | 686590          | Ignitor                        |
|                             |                 |                                   |                             | W10192882       | White               | 54                          | 3387057         | Screw                          |
| 9                           | 660658          | Clamp, Motor                      | 32                          | 696144          | Strike, Door        | 55                          | 8281911         | Valve, Gas (Complete) 60 Hz    |
| 10                          | W10446781       | Spring, Idler                     | 33                          | 3387242         | Seal, Front Panel   |                             |                 |                                |
| 11                          | 3389420         | Screw                             | 34                          |                 | Panel, Toe          | 56                          | 343641          | Screw                          |
| 12                          | W10344193       | Pulley-Idler Assembly             |                             | 697215          | White               | 57                          | 693995          | Screw                          |
| 13                          | 697773          | Screw                             | 35                          |                 | Top                 | 58                          | 8529757         | Bracket, Burner                |
| 14                          |                 | Hinge & Pin Assembly              |                             | 3389351         | White               | 59                          | 3387561         | Clamp, Pipe                    |
|                             | W10279703       | Silver                            | 36                          | W10322546       | Door, Front         | 60                          | 3400077         | Screw                          |
| 15                          | W10291934       | Clip                              | 37                          | W10323061       | Door, Rear          |                             |                 | DRYER EXHAUST KIT NOT INCLUDED |
| 16                          | 3390647         | Screw                             | 38                          | 8283298         | Jumper, Door Switch |                             |                 |                                |
| 17                          | 3390735         | Seal, Door                        | 39                          | 3388229         | Retainer            |                             | W10470674       | Kit, 4-Way Venting             |
| 18                          | 8066134         | Switch Assembly                   | 40                          | W10117347       | Cotter Pin          |                             |                 |                                |
| 19                          | 8066120         | Lever Switch                      | 41                          | 3406109         | Switch, Door        |                             |                 |                                |
| 20                          | 3394881         | Switch - Belt                     | 42                          | 3979115         | Bracket, Angle      |                             |                 |                                |
| 21                          | 3398948         | Wire, Jumper (Broken Belt Switch) | 43                          | 3400523         | Bolt, Security      |                             |                 |                                |
|                             |                 |                                   | 44                          | 3392186         | Washer              |                             |                 |                                |
| 22                          | W10167612       | Wire, Belt Switch                 | 45                          | 342055          | Screw               |                             |                 |                                |

# UPPER AND LOWER BULKHEAD PARTS




# UPPER AND LOWER BULKHEAD PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>       | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            |
|-----------------------------|-----------------|----------------------------------------|-----------------------------|-----------------|--------------------------|-----------------------------|-----------------|-------------------------------|
| 1                           | 3394346         | Assembly, Air Duct                     | 16                          | W10219342       | Screw                    | 35                          | W10135254       | Housing, Blower               |
| 2                           | 8533971         | Screw                                  | 17                          | 8066086         | Plug, Drum Hole          | 33                          | 3392519         | Fuse, Thermal (91C)           |
| 3                           | 8520836         | Bulkhead, Rear                         | 18                          | W10521118       | Seal, Drum               | 34                          | W10131836       | Thermostat                    |
| 4                           | 3390647         | Screw                                  | 19                          | W10692558       | Grill, Outlet            | 35                          | W10193019       | Thermostat, Electronic (155F) |
| 5                           | 8578825         | Bracket, Drum Light                    | 20                          | 3387230         | Screw                    | 36                          | 693995          | Screw                         |
| 6                           | 3402841         | Lens, Drum Light                       | 21                          | 695240          | Screw                    | 37                          | 8066224         | Pipe, Exhaust                 |
| 7                           | W10001120       | Nut, Hex (Left Hand Thread)            | 22                          | W10685669       | Assembly, Outlet Housing | 38                          | 8572105         | Clip, Exhaust                 |
| 8                           | 3387459         | Washer                                 | 23                          |                 | Screen, Lint             | 39                          | 3391912         | Thermostat, Hi Limit          |
| 9                           | W10512946       | Washer, Tri Ring                       |                             | W10596627       | White                    | 40                          | 8573713         | Cut-Off, Thermal              |
| 10                          | W10359272       | Shaft, Drum Roller - Left Hand Thread  | 24                          | 697557          | Bulkhead, Front          | 41                          | 338906          | Sensor, Radiant               |
| 11                          | W10314171       | Roller, Support                        | 25                          | 3357011         | Screw                    | 42                          | 90767           | Screw                         |
| 12                          | W10359271       | Shaft, Drum Roller - Right Hand Thread | 26                          | 697814          | Seal, Drum Front         | 43                          | 8573824         | Funnel, Burner                |
| 13                          | 3934666         | Nut, Hex                               | 27                          | 8066168         | Assembly, Lint Duct      | 44                          | 3401707         | Jumper, Wire                  |
| 14                          | W10545923       | Assembly, Drum                         | 28                          | 489463          | Screw                    |                             |                 |                               |
| 15                          | 697693          | Baffle, Drum                           | 29                          | W10345456       | Clip, Spring             |                             |                 |                               |
|                             |                 |                                        | 30                          | W10349492       | Wheel, Blower            |                             |                 |                               |
|                             |                 |                                        | 31                          | 697770          | Seal, Plate Cover        |                             |                 |                               |

# BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL  
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



# BURNER ASSEMBLY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u>     | <u>Part No.</u> | <u>Description</u>                               |
|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|---------------------------------------------------|---------------------------------|-----------------|--------------------------------------------------|
| 1                           | 3401797         | Burner Assembly (60 Hz)     | 11                          | 694421          | Screw, Coil                                       | 20                              | 697441          | Valve, Gas                                       |
| 2                           | 688617          | Tube, Burner                | 12                          | 694538          | Bracket, Coil                                     | 21                              | 233076          | Nut, Compression                                 |
| 3                           | 694298          | Bracket, Ignitor            | 13                          | 694540          | Coil, 60 Hz. (2 Terminal) (Main)                  | 22                              | 3393767         | Pipe, Tail                                       |
| 4                           | 686590          | Ignitor                     | 14                          | 694539          | Coil, 60 Hz (Split) (3 Terminal) (Pilot Position) | Following Parts Not Illustrated |                 |                                                  |
| 5                           | 3393909         | Screw                       |                             |                 |                                                   |                                 |                 |                                                  |
| 6                           | 343641          | Screw                       |                             |                 |                                                   | 49572A                          |                 | Conversion Kit (Type 1 and 2) to Type (4) L.P.G. |
| 7                           | 3389871         | Base, Burner                | 15                          | 694424          | Leak, Limiter                                     |                                 |                 |                                                  |
| 8                           | 3387057         | Screw                       | 16                          | 694423          | Screw, Regulator Adjustment                       |                                 |                 |                                                  |
| 9                           |                 | Orifice, Burner             |                             |                 |                                                   |                                 |                 |                                                  |
|                             | 3397656         | Type 1 (Natural Gas)        | 17                          | 694422          | Spring, Regulator                                 |                                 |                 |                                                  |
| 10                          | 8281911         | Valve, Gas (Complete) 60 Hz | 18                          | 239822          | Plug, Pipe                                        |                                 |                 |                                                  |
|                             |                 |                             | 19                          | W10110395       | Pipe, Gas Supply                                  |                                 |                 |                                                  |

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 4392067         | Kit, Dryer Repair       |
|                             | 285875          | Kit, Security           |
|                             | 8522199         | Kit, Dryer Vent Testing |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 350938          | Gray Primer        |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 72017           | White              |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |