




COMMERCIAL GAS DRYER

MODELS:

MLG26PRFWW0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651083	Facia	16	W10899602	Assembly, Lock Access Door	29	W10143462	Screw
2	W10386302	Screw	17	W10913660	Cam, Locking	30	W10163036	Bezel
3	W10137769	Cover, Card Reader	18	W10160652	Bracket-Switch	31	W10807484	Harness, Collar
4	W10145157	Retainer, Facia Cover	19	W10447152	Switch, Service Access	32	W10188051	Jumper, Line Filter
5	3400618	Screw	20	3400408	Screw	33	W10769481	Jumper, Coin Box
6	W10133268	Cover, Display	21	3396795	Cover, Terminal Block	34	W10111027	Jumper, Transformer
7	W10657185	Plate, Control Mounting	22	W10850065	Cover, Terminal Block	35	W10807493	Jumper, Lower to Collar
8	W10140652	Screw	23	3390814	Screw	36	W10155270	Cable Tie
9	W11582595	Control Board	24	W11332324	Power Cord			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
10	W11455510	Collar	25	W10773242	Screw			Greenwald Industries
11	W10133514	Standoff, Circuit Board	26	694415	Clip, Strain Relief			212 Middlesex Ave
12	W10139046	Nut	27	W11498818	Instructions, Installation (Card Reader)			Chester, CT 06412
13	W10133285	Transformer 120Vac To 22.5Vac	28	W10239515	Harness, Card Reader			1-800-221-0982
14	W10306592	Filter, RFI						sales@greenwaldindustries.com
15	8533971	Screw						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	15	W11325273	Boot, Foot	34	693152	Bumper
	W11647897	Installation Instructions	16	W10836097	Panel, Dampening	35	W10191265	Plug, Hinge (White)
	W11651037	Tech Sheet	17	98997	Clip	36	696144	Strike, Door
	W11463414	Installation Instructions, Card Reader	18	3390735	Seal, Door	37	W10192882	Panel, Front (White)
2	3391915	Screw	19	W10291934	Clip	38	8283298	Jumper, Door Switch
3	3390663	Screw	20	W10807483	Harness, Upper/Lower	39	3392538	Assembly, Door Catch
4	3391846	Clip, Front Panel	21	W10279703	Assembly, Hinge and Pin (Silver)	40	697215	Panel, Toe (White)
5	3393657	Restrainer, Belt	22	8066134	Switch Assembly	41	W10237959	Switch, Door
6	697773	Screw	23	3394881	Switch, Belt	42	W10322546	Door, Front
7	W11161907	Cabinet (White)	24	8066120	Lever, Belt Switch	43	W10323061	Door, Rear
8	3392100	Foot, Dryer	25	98129	Screw	44	3387242	Seal, Front Panel
9	660658	Clamp, Motor	26	W10167612	Wire, Belt Switch	45	342055	Screw
10	W10446781	Spring, Idler	27	3398948	Wire, Jumper (Broken Belt Switch)	46	3388229	Retainer
11	3389420	Screw	28	W10396031	Motor	47	345670	Lock Top
12	W10116360	Handle, Door	29	3394341	Pulley, Motor	48	W11378153	Cover, Terminal
13	W10344193	Pulley-Idler Assembly	30	W10131172	Belt, Drive	49	8529757	Bracket, Burner
14	W10879744	Screw	31	3390647	Screw	50	693995	Screw
			32	3387118	Bracket, Motor			DRYER EXHAUST KIT NOT INCLUDED
			33	W10576519	Seal, Deflector		W10470674	Kit, 4-Way Venting


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	21	8066134	Switch Assembly	40	W10117347	Cotter Pin
2	3391915	Screw	22	3394881	Switch, Belt	41	W10237959	Switch, Door
3	3393657	Restrainer, Belt	23	8066120	Lever, Belt Switch	42	W10192882	Panel, Front (White)
4	W10879744	Screw	24	98129	Screw	43	3389233	Bushing
5	W10322546	Door, Front	25	W10167612	Wire, Belt Switch	44	3387242	Seal, Front Panel
6	697773	Screw	26	3398948	Wire, Jumper (Broken Belt Switch)	45	342055	Screw
7	W11384447	Cabinet (White)	27	W10396031	Motor	46	3388229	Retainer
8	W10836097	Panel, Dampening	28	3979115	Bracket, Angle	47	W10191265	Plug, Hinge (White)
9	660658	Clamp, Motor	29	3394341	Pulley, Motor	48	W10323061	Door, Rear
10	W10446781	Spring, Idler	30	W10131172	Belt, Drive	49	345670	Lock Top
11	3389420	Screw	31	3390735	Seal, Door	50	W11378153	Cover, Terminal
12	3389351	Top (White)	32	3387118	Bracket, Motor	51	8529757	Bracket, Burner
13	W10344193	Pulley-Idler Assembly	33	693152	Bumper	52	693995	Screw
14	697215	Panel, Toe (White)	34	W10807483	Harness, Upper/Lower			DRYER EXHAUST KIT NOT INCLUDED
15	W10116360	Handle, Door	35	3390647	Screw			
16	98997	Clip	36	W10576519	Seal, Deflector	W10470674		Kit, 4-Way Venting
17	3391846	Clip, Front Panel	37	3400523	Bolt, Security			
18	3392538	Assembly, Door Catch	38	8283298	Jumper, Door Switch			
19	W10291934	Clip	39	696144	Strike, Door			
20	W10279703	Assembly, Hinge and Pin (Silver)						

UPPER AND LOWER BULKHEAD PARTS




UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359272	Shaft, Drum Roller - Left Hand Thread	15	8573824	Funnel, Burner	29	8066086	Plug, Drum Hole
2	8544362	Housing, Blower	16	W10001120	Nut, Hex (Left Hand Thread)	30	697693	Baffle, Drum
3	8533971	Screw	17	W11162455	Bulkhead, Rear	31	695240	Screw
4	90767	Screw	18	3387459	Washer	32	697557	Bulkhead, Front
5	W10865336	Assembly, Air Duct	19	W10359271	Shaft, Drum Roller - Right Hand Thread	33	3402841	Lens, Drum Light
6	W10685669	Assembly, Outlet Housing	20	W10512946	Washer, Tri Ring	34	3392519	Fuse, Thermal (91C)
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	35	697770	Seal, Plate Cover
8	3934666	Nut, Hex	22	338906	Sensor, Radiant	36	W10049370	Screen, Lint
9	8066224	Pipe, Exhaust	23	8573713	Cut-Off, Thermal	37	W10349492	Wheel, Blower
10	8572105	Clip, Exhaust	24	3391912	Thermostat, Hi Limit	38	W10193019	Thermostat, Electronic (155F)
11	3357011	Screw	25	W10545923	Assembly, Drum	39	3387230	Screw
12	W10345456	Clip, Spring	26	W10219342	Screw	40	W10131836	Thermostat
13	3390647	Screw	27	W10521118	Seal, Drum	41	489463	Screw
14	8066168	Assembly, Lint Duct	28	8578825	Bracket, Drum Light	42	693995	Screw

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11566859	Burner Assembly	11	694421	Screw, Coil	19	W10097610	Pipe, Gas Supply
2	688617	Tube, Burner	12	694538	Bracket, Coil	20	697441	Valve, Gas
3	694298	Bracket, Ignitor	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	21	233076	Nut, Compression
4	686590	Ignitor				22	3393767	Pipe, Tail
5	W10366705	Screw	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			FOLLOWING PARTS NOT ILLUSTRATED
6	343641	Screw						
7	3389871	Base, Burner	15	694424	Leak, Limiter		49572A	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
8	3387057	Screw	16	694423	Screw, Regulator Adjustment			
9	3397656	Orifice, Burner Type 1 (Natural Gas)	17	694422	Spring, Regulator			
10	8281911	Valve, Gas (Complete) 60 Hz	18	239822	Plug, Pipe			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	Paint, Touch-up (White 1/2 oz)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	Paint, Spray (White 12 oz)
	350938	Paint, Spray (Gray Primer 12 oz)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	Paint, Bulk (White Uncut 1 qt)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing