




## **COMMERCIAL GAS DRYER**

### **MODELS:**

MLG27PDBWW0 (White)

# CONTROL PANEL AND SEPARATOR PARTS




# CONTROL PANEL AND SEPARATOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-----------------------------|-----------------|----------------------------------|
| 1                           | W10702047       | Harness, Collar                  |
| 2                           | W10139762       | Nut, Hex                         |
| 3                           | W10155270       | Cable Tie                        |
| 4                           | W10773242       | Screw                            |
| 5                           | W10140652       | Screw                            |
| 6                           | W10133285       | Transformer 120Vac To<br>22.5Vac |
| 7                           | 8533971         | Screw                            |
| 8                           | W10177242       | Nut, Hex                         |
| 9                           | W10139046       | Nut                              |
| 10                          | W10386302       | Screw                            |
| 11                          | W10657185       | Plate, Control Mounting          |
| 12                          | W10111027       | Jumper, Transformer              |
| 13                          | W10684165       | Facia Console                    |
| 14                          | W10133242       | Assembly, Single Coin<br>Drop    |
| 15                          | W10133268       | Cover, Display                   |
| 16                          | W10447152       | Switch, Service Access           |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                  |
|-----------------------------|-----------------|-----------------------------------------------------|
| 17                          | W10159907       | Assembly, Mounting<br>Strap Weld                    |
| 18                          | W10133264       | Assembly, Lock Access<br>Door                       |
| 19                          | W10702055       | Jumper, Lower to Collar                             |
| 20                          | 3400408         | Screw                                               |
| 21                          | W10160652       | Bracket-Switch                                      |
| 22                          | W10137319       | Bolt, Hex Bar                                       |
| 23                          | W10159849       | Collar                                              |
| 24                          | 3396795         | Cover, Terminal Block                               |
| 25                          | W10133258       | Assembly, Vault Body                                |
| 26                          | W10133248       | Box, Coin                                           |
| 27                          | W10678217       | Control Board                                       |
| 28                          | W10169579       | Kit-Coin Box, Security<br>(To be serviced as a kit) |
| 29                          |                 | Coin Optic Sensor<br>Assembly                       |
|                             | W10247389       | White                                               |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|--------------------------------|
| 30                          | W10142655       | Screw                          |
| 31                          | W10239314       | Cord, Power                    |
| 32                          | W10131838       | Switch, Vault Service<br>Door  |
| 33                          | 3401850         | Harness, Gas                   |
| 34                          | W10140858       | Key, Access Door               |
| 35                          | W10188051       | Jumper, Line Filter            |
| 36                          | W10133266       | Cam, Locking                   |
| 37                          | W10133514       | Standoff, Circuit Board        |
| 38                          | W10001120       | Nut, Hex (Left Hand<br>Thread) |
| 39                          | 3400000         | Screw                          |
| 40                          | 694415          | Clip, Strain Relief            |
| 41                          | W10306592       | Filter, RFI                    |


# LOWER CABINET AND FRONT PANEL PARTS



# LOWER CABINET AND FRONT PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                |
|-----------------------------|-----------------|---------------------------------------------------|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|-----------------------------------|
| 1                           |                 | Literature Parts<br>(Located Behind Toe<br>Panel) | 18                          | 3393657         | Restrainer, Belt              | 38                          | 8283298         | Jumper, Door Switch               |
|                             | W10761035       | Installation Instructions                         | 19                          | W10291934       | Clip                          | 39                          | 3403431         | Strike, Door                      |
|                             | W10135168       | Tech Sheet                                        | 20                          | 3405160         | Belt, Drive (Blower<br>Wheel) | 40                          | W10694688       | Panel, Front                      |
| 2                           | 3391915         | Screw                                             | 21                          | 3391943         | Boot, Foot                    | 41                          | 3406109         | Switch, Door                      |
| 3                           | 3390663         | Screw                                             | 22                          | W10212660       | Motor, Sound Pad              | 42                          | 98129           | Screw                             |
| 4                           | 3391846         | Clip, Front Panel                                 | 23                          | 98997           | Clip                          | 43                          | 3388229         | Retainer                          |
| 5                           | 8564010         | Assembly, Switch and<br>Actuator                  | 24                          | 3387561         | Clamp, Pipe                   | 44                          | 3387242         | Seal, Front Panel                 |
| 6                           | 697773          | Screw                                             | 25                          | 8564011         | Bracket, Switch               | 45                          | 342055          | Screw                             |
| 7                           |                 | Cabinet                                           | 26                          |                 | Panel, Toe                    | 46                          | W10135231       | Burner Assembly (60<br>Hz)        |
|                             | W10547697       | White                                             |                             | 697215          | White                         | 47                          | W10141728       | Valve, Gas (60 Hz -<br>Complete)  |
| 8                           | 3392100         | Foot, Dryer                                       | 27                          | W10396034       | Assembly, Motor 60 HZ.        | 48                          | 3387057         | Screw                             |
| 9                           | 660658          | Clamp, Motor                                      | 28                          | W10167613       | Wire, Belt Switch             | 49                          | 3393909         | Screw                             |
| 10                          | W10446781       | Spring, Idler                                     | 29                          | 3394341         | Pulley, Motor                 | 50                          | 686590          | Ignitor                           |
| 11                          | 3389420         | Screw                                             | 30                          | W10131172       | Belt, Drive                   | 51                          | 343641          | Screw                             |
| 12                          | 693995          | Screw                                             | 31                          |                 | Cover, Strike                 |                             |                 | OPTIONAL PARTS<br>NOT ILLUSTRATED |
| 13                          | W10344192       | Assembly, Idler                                   |                             | W10521429       | White                         | W10470674                   |                 | Kit, 4-Way Venting                |
| 14                          | 3400077         | Screw                                             | 32                          | W10135695       | Bracket, Motor                |                             |                 |                                   |
| 15                          | W10576519       | Seal, Deflector                                   | 33                          | 3392186         | Washer                        |                             |                 |                                   |
| 16                          | 8539892         | Wire, Motor To Belt<br>Switch                     | 34                          | 693152          | Bumper                        |                             |                 |                                   |
| 17                          | 8529757         | Bracket, Burner                                   | 35                          | W10155571       | Switch, Assembly              |                             |                 |                                   |
|                             |                 |                                                   | 36                          | W10702046       | Harness                       |                             |                 |                                   |
|                             |                 |                                                   | 37                          | 3390647         | Screw                         |                             |                 |                                   |


# UPPER CABINET AND FRONT PANEL PARTS



# UPPER CABINET AND FRONT PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|------------------------|-----------------------------|-----------------|--------------------------------|
| 1                           | 3390663         | Screw                         | 20                          | W10212660       | Motor, Sound Pad       | 38                          | 8283298         | Jumper, Door Switch            |
| 2                           | 3391915         | Screw                         | 21                          | 3391846         | Clip, Front Panel      | 39                          | 3390647         | Screw                          |
| 3                           | 8539892         | Wire, Motor To Belt Switch    | 22                          | 98997           | Clip                   | 40                          | 3400523         | Bolt, Security                 |
| 4                           | 3400077         | Screw                         | 23                          | 3979115         | Bracket, Angle         | 41                          | 3406109         | Switch, Door                   |
| 5                           | W10155571       | Switch, Assembly              | 24                          | 3387561         | Clamp, Pipe            | 42                          | 98129           | Screw                          |
| 6                           | 697773          | Screw                         | 25                          | 8564011         | Bracket, Switch        | 43                          | 3389233         | Bushing                        |
| 7                           |                 | Cabinet                       | 26                          | W10117347       | Cotter Pin             | 44                          | 3387242         | Seal, Front Panel              |
|                             | W10547697       | White                         | 27                          | W10396034       | Assembly, Motor 60 HZ. | 45                          | 342055          | Screw                          |
| 8                           | 689172          | Foot, Dryer Plastic           | 28                          | W10167613       | Wire, Belt Switch      | 46                          | 3388229         | Retainer                       |
| 9                           | 660658          | Clamp, Motor                  | 29                          | 3394341         | Pulley, Motor          | 47                          | 3403431         | Strike, Door                   |
| 10                          | W10446781       | Spring, Idler                 | 30                          | W10131172       | Belt, Drive            | 48                          | W10694688       | Panel, Front                   |
| 11                          | 3389420         | Screw                         | 31                          |                 | Cover, Strike          | 49                          | W10135231       | Burner Assembly (60 Hz)        |
| 12                          | 3405160         | Belt, Drive (Blower Wheel)    |                             | W10521429       | White                  | 50                          | W10141728       | Valve, Gas (60 Hz - Complete)  |
| 13                          | W10344192       | Assembly, Idler               | 32                          | W10135695       | Bracket, Motor         | 51                          | 3387057         | Screw                          |
| 14                          | 693995          | Screw                         | 33                          | 693152          | Bumper                 | 52                          | 3393909         | Screw                          |
| 15                          | W10576519       | Seal, Deflector               | 34                          |                 | Top                    | 53                          | 686590          | Ignitor                        |
| 16                          | 8564010         | Assembly, Switch and Actuator |                             | 3389351         | White                  | 54                          | 343641          | Screw                          |
| 17                          | 8529757         | Bracket, Burner               | 35                          |                 | Panel, Toe             |                             |                 | OPTIONAL PARTS NOT ILLUSTRATED |
| 18                          | 3393657         | Restrainer, Belt              |                             | 697215          | White                  |                             |                 |                                |
| 19                          | W10291934       | Clip                          | 36                          | 3392186         | Washer                 |                             | W10470674       | Kit, 4-Way Venting             |
|                             |                 |                               | 37                          | W10702046       | Harness                |                             |                 |                                |


# UPPER AND LOWER BULKHEAD PARTS



# UPPER AND LOWER BULKHEAD PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|-------------------------------------------|-----------------------------|-----------------|---------------------------------------|-----------------------------|-----------------|---------------------|
| 1                           | W10359271       | Shaft, Drum Roller - Right Hand Thread    | 16                          | W10001120       | Nut, Hex (Left Hand Thread)           | 31                          | 695240          | Screw               |
| 2                           | 8544362         | Housing, Blower                           | 17                          | 8520836         | Bulkhead, Rear                        | 32                          | 697557          | Bulkhead, Front     |
| 3                           | 8533971         | Screw                                     | 18                          | 3387459         | Washer                                | 33                          | 8578825         | Bracket, Drum Light |
| 4                           | 90767           | Screw                                     | 19                          | W10359272       | Shaft, Drum Roller - Left Hand Thread | 34                          | 3392519         | Fuse, Thermal (91C) |
| 5                           | 3394346         | Assembly, Air Duct                        | 20                          | W10512946       | Washer, Tri Ring                      | 35                          | 697770          | Seal, Plate Cover   |
| 6                           | W10181929       | Assembly, Outlet Grill Housing (Complete) | 21                          | W10314171       | Roller, Support                       | 36                          |                 | Screen, Lint        |
| 7                           | 697814          | Seal, Drum Front                          | 22                          | 338906          | Sensor, Radiant                       |                             | W10596627       | White               |
| 8                           | 3934666         | Nut, Hex                                  | 23                          | W10193019       | Thermostat, Electronic (155F)         | 37                          | W10349492       | Wheel, Blower       |
| 9                           | 8066224         | Pipe, Exhaust                             | 24                          | 3391912         | Thermostat, Hi Limit                  | 38                          | 8573713         | Cut-Off, Thermal    |
| 10                          | 8572105         | Clip, Exhaust                             | 25                          | W10545923       | Assembly, Drum                        | 39                          | 3387230         | Screw               |
| 11                          | 3357011         | Screw                                     | 26                          | W10219342       | Screw                                 | 40                          | W10131836       | Thermostat          |
| 12                          | W10345456       | Clip, Spring                              | 27                          | W10521118       | Seal, Drum                            |                             |                 |                     |
| 13                          | 3390647         | Screw                                     | 28                          | 3402841         | Lens, Drum Light                      |                             |                 |                     |
| 14                          | 8066168         | Assembly, Lint Duct                       | 29                          | 8066086         | Plug, Drum Hole                       |                             |                 |                     |
| 15                          | 8573824         | Funnel, Burner                            | 30                          | 697693          | Baffle, Drum                          |                             |                 |                     |

# DOOR PARTS



# DOOR PARTS


| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 1                           | W10513690       | Assembly, Inner Door |
| 2                           | 8519354         | Retainer, Window     |
| 3                           |                 | Hinge & Pin Assembly |
|                             | W10279703       | Silver               |
| 4                           | 342055          | Screw                |
| 5                           | W10354795       | Seal, Door           |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 6                           | 3393258         | Screw                |
| 7                           | W10192860       | Screw                |
| 8                           | W10284122       | Seal, Window         |
| 9                           | 690081          | Assembly, Door Catch |
| 10                          | W10470571       | Door, Inner          |
| 11                          | W10284121       | Glass, Door          |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 12                          |                 | Door, Outer Assembly |
|                             | W10284127       | White                |
| 13                          |                 | Plug-Hinge Screw     |
|                             | W10191265       | White                |

# BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,  
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASSES



# BURNER ASSEMBLY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u>                              | <u>Description</u> |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|---------------------------------------------------|-----------------------------|----------------------------------------------|--------------------|
| 1                           | W10135231       | Burner Assembly (60 Hz)       | 12                          | 694538          | Bracket, Coil                                     | 24                          | 3387561                                      | Clamp, Pipe        |
| 2                           | 688617          | Tube, Burner                  | 13                          | 694540          | Coil, 60 Hz. (2 Terminal) (Main)                  | W10135245                   | Following Parts Not Illustrated              |                    |
| 3                           | 694298          | Bracket, Ignitor              | 14                          | 694539          | Coil, 60 Hz (Split) (3 Terminal) (Pilot Position) |                             | Conversion Kit (Type 1 and 2) to Type L.P.G. |                    |
| 4                           | 686590          | Ignitor                       | 15                          | 694424          | Leak, Limiter                                     |                             |                                              |                    |
| 5                           | 3393909         | Screw                         | 16                          | 694423          | Screw, Regulator Adjustment                       |                             |                                              |                    |
| 6                           | 343641          | Screw                         | 17                          | 694422          | Spring, Regulator                                 |                             |                                              |                    |
| 7                           | 3389871         | Base, Burner                  | 18                          | 239822          | Plug, Pipe                                        |                             |                                              |                    |
| 8                           | 3387057         | Screw                         | 19                          | 697441          | Valve, Gas                                        |                             |                                              |                    |
| 9                           |                 | Orifice, Burner               | 20                          | 233076          | Nut, Compression                                  |                             |                                              |                    |
|                             | 234870          | Type 1 (Natural)              | 21                          | 3393767         | Pipe, Tail                                        |                             |                                              |                    |
|                             | 234868          | Type 4 (Propane)              | 22                          | W10110395       | Pipe, Gas Supply                                  |                             |                                              |                    |
| 10                          | W10141728       | Valve, Gas (60 Hz - Complete) | 23                          | 3389889         | Bracket, Support                                  |                             |                                              |                    |
| 11                          | 694421          | Screw, Coil                   |                             |                 |                                                   |                             |                                              |                    |

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 4392067         | Kit, Dryer Repair       |
|                             | 285875          | Kit, Security           |
|                             | 8522199         | Kit, Dryer Vent Testing |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 72017           | White              |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 350938          | Gray Primer        |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |