




COMMERCIAL GAS DRYER

MODELS:

MLG27PDFWW0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10807484	Harness, Collar	18	W10899602	Assembly, Lock Access Door	33	W10306592	Filter, RFI
2	W10139762	Nut, Hex				34	W10140858	Key, Access Door
3	W10155270	Cable Tie	19	W10807493	Jumper, Lower to Collar	35	W10188051	Jumper, Line Filter
4	W10773242	Screw				36	W10913660	Cam, Locking
5	W10140652	Screw	20	3400408	Screw	37	W10133514	Standoff, Circuit Board
6	W10133285	Transformer 120Vac To 22.5Vac	21	W10160652	Bracket-Switch	38	W10001120	Nut, Hex (Left Hand Thread)
7	8533971	Screw	22	W10137319	Bolt, Hex Bar			
8	W10177242	Nut, Hex	23	W11455498	Collar	39	337686	Screw
9	W10139046	Nut	24	3396795	Cover, Terminal Block	40	694415	Clip, Strain Relief
10	W10386302	Screw	25	W11109083	Assembly, Vault Body			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
11	W10657185	Plate, Control Mounting	26	W11109086	Box, Coin			ESD 270 New Jersey Dr. Fort Washington, PA 19034 1-800-523-1510 info@esdcoin.com
12	W10111027	Jumper, Transformer	27	W11582595	Control Board			
13	W11651080	Console	28	W10169579	Kit-Coin Box, Security (To be serviced as a kit)			
14	W10133242	Assembly, Single Coin Drop	29		Coin Optic Sensor Assembly			
15	W10133268	Cover, Display		W10247389	White			
16	W10447152	Switch, Service Access	30	W10142655	Screw			
			31	W11332324	Power Cord			
17	W10159907	Assembly, Mounting Strap Weld	32	W10131838	Switch, Vault Service Door			


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	20	W10131172	Belt, Drive	40	W10694688	Panel, Front
	W11647897	Installation Instructions	21	3391943	Boot, Foot	41	W10237959	Switch, Door
	W11651037	Tech Sheet	22	W10836094	Pad, Sound	42	98129	Screw
2	3391915	Screw	23	98997	Clip	43	3388229	Retainer
3	3390663	Screw	24	3387561	Clamp, Pipe	44	3387242	Seal, Front Panel
4	3391846	Clip, Front Panel	25	3390647	Screw	45	342055	Screw
5	W10807483	Harness, Upper/Lower	26		Panel, Toe	46	W11566857	Burner Assembly
6	697773	Screw		697215	White	47	W10141728	Valve, Gas (60 Hz - Complete)
7		Cabinet	27	W10918085	Assembly, Motor 60 HZ.	48	3387057	Screw
	W11161907	White	28	3393657	Restrainer, Belt	49	W10366705	Screw
8	3392100	Foot, Dryer	29	3394341	Pulley, Motor	50	686590	Ignitor
9	660658	Clamp, Motor	30	3405160	Belt, Drive (Blower Wheel)	51	343641	Screw
10	W10446781	Spring, Idler	31		Cover, Strike	52	W11378153	Cover, Terminal
11	3389420	Screw		W10521429	White	53	3390814	Screw
12	693995	Screw	32	W10135695	Bracket, Motor			DRYER EXHAUST KIT NOT INCLUDED
13	W10344192	Assembly, Idler	33	3392186	Washer			
14	W10879744	Screw	34	693152	Bumper		W10470674	Kit, 4-Way Venting
15	W10576519	Seal, Deflector	35	W11233966	Switch, Assembly			
16	W11224633	Strike, Door	36	8564010	Assembly, Switch and Actuator			
17	8529757	Bracket, Burner	37	W11159569	Bracket, Switch			
18	8283298	Jumper, Door Switch	38	W10167613	Wire, Belt Switch			
19	W10291934	Clip	39	8539892	Wire, Motor To Belt Switch			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	22	98997	Clip	39	3390647	Screw
2	3391915	Screw	23	3979115	Bracket, Angle	40	3400523	Bolt, Security
3	660658	Clamp, Motor	24	3387561	Clamp, Pipe	41	W10237959	Switch, Door
4	W10879744	Screw	25		Cabinet	42	98129	Screw
5	W11233966	Switch, Assembly		W11161907	White	43	3389233	Bushing
6	8564010	Assembly, Switch and Actuator	26	W10117347	Cotter Pin	44	3387242	Seal, Front Panel
7	W11159569	Bracket, Switch	27	W10918085	Assembly, Motor 60 HZ.	45	342055	Screw
8	W10167613	Wire, Belt Switch	28	3393657	Restrainer, Belt	46	3388229	Retainer
9	8539892	Wire, Motor To Belt Switch	29	3394341	Pulley, Motor	47	W11224633	Strike, Door
10	W10446781	Spring, Idler	30	3405160	Belt, Drive (Blower Wheel)	48	W10694688	Panel, Front
11	3389420	Screw	31		Cover, Strike	49	W11566857	Burner Assembly
12	W10131172	Belt, Drive		W10521429	White	50	W10141728	Valve, Gas (60 Hz - Complete)
13	W10344192	Assembly, Idler	32	W10135695	Bracket, Motor	51	3387057	Screw
14	693995	Screw	33	693152	Bumper	52	W10366705	Screw
15	W10576519	Seal, Deflector	34		Top	53	686590	Ignitor
16	697773	Screw		3389351	White	54	343641	Screw
17	8529757	Bracket, Burner	35		Panel, Toe	55	W11378153	Cover, Terminal
18	W11325273	Boot, Foot		697215	White	56	3390814	Screw
19	W10291934	Clip	36	3392186	Washer			DRYER EXHAUST KIT NOT INCLUDED
20	W10836094	Pad, Sound	37	W10807483	Harness, Upper/Lower			
21	3391846	Clip, Front Panel	38	8283298	Jumper, Door Switch	W10470674		Kit, 4-Way Venting


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Inner Door	6	3393258	Screw	12		Door, Outer Assembly
	W10513690	White	7	W10192860	Screw		W10284127	White
2	8519354	Retainer, Window	8	W10284122	Seal, Window	13		Plug-Hinge Screw
3		Hinge & Pin Assembly	9	690081	Assembly, Door Catch		W10191265	White
	W10279703	Silver	10		Door, Inner			
4	342055	Screw		W10470571	White			
5	W10354795	Seal, Door	11	W10284121	Glass, Door			

UPPER AND LOWER BULKHEAD PARTS




UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359272	Shaft, Drum Roller - Left Hand Thread	15	8573824	Funnel, Burner	29	8066086	Plug, Drum Hole
2	8544362	Housing, Blower	16	W10001120	Nut, Hex (Left Hand Thread)	30	697693	Baffle, Drum
3	8533971	Screw	17	W11162455	Bulkhead, Rear	31	695240	Screw
4	90767	Screw	18	3387459	Washer	32	697557	Bulkhead, Front
5	W10865336	Assembly, Air Duct	19	W10359271	Shaft, Drum Roller - Right Hand Thread	33	3402841	Lens, Drum Light
6	W10685669	Assembly, Outlet Housing	20	W10512946	Washer, Tri Ring	34	3392519	Fuse, Thermal (91C)
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	35	697770	Seal, Plate Cover
8	3934666	Nut, Hex	22	338906	Sensor, Radiant	36	W10049370	Screen, Lint
9	8066224	Pipe, Exhaust	23	8573713	Cut-Off, Thermal	37	W10349492	Wheel, Blower
10	8572105	Clip, Exhaust	24	3391912	Thermostat, Hi Limit	38	W10193019	Thermostat, Electronic (155F)
11	3357011	Screw	25	W10545923	Assembly, Drum	39	3387230	Screw
12	W10345456	Clip, Spring	26	W10219342	Screw	40	W10131836	Thermostat
13	3390647	Screw	27	W10521118	Seal, Drum	41	489463	Screw
14	8066168	Assembly, Lint Duct	28	8578825	Bracket, Drum Light			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASSES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11566857	Burner Assembly	12	694538	Bracket, Coil	22	W10110395	Pipe, Gas Supply
2	688617	Tube, Burner	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	23	3389889	Bracket, Support
3	694298	Bracket, Ignitor				24	3387561	Clamp, Pipe
4	686590	Ignitor	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			FOLLOWING PARTS NOT ILLUSTRATED
5	W10366705	Screw				W10135245		Conversion Kit (Type 1 and 2) to Type L.P.G.
6	343641	Screw	15	694424	Leak, Limiter			
7	3389871	Base, Burner	16	694423	Screw, Regulator Adjustment	W10233219		LP Conversion Kit (EU Type 4)
8	3387057	Screw				W10832960		LP Conversion Kit (FR/BE Nat Gas)
9		Orifice, Burner	17	694422	Spring, Regulator	W10832961		LP Conversion Kit (AUS Type 4)
	234870	Type 1 (Natural)	18	239822	Plug, Pipe			
	234868	Type 4 (Propane)	19	697441	Valve, Gas			
10	W10141728	Valve, Gas (60 Hz - Complete)	20	233076	Nut, Compression			
11	694421	Screw, Coil	21	3393767	Pipe, Tail			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing