




COMMERCIAL GAS DRYER

MODELS:

MLG27PRFWW0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651083	Facia	16	W10899602	Assembly, Lock Access Door	29	W10143462	Screw
2	W10386302	Screw	17	W10913660	Cam, Locking	30	W10163036	Bezel
3	W10137769	Cover, Card Reader	18	W10160652	Bracket-Switch	31	W10807484	Harness, Collar
4	W10145157	Retainer, Facia Cover	19	W10447152	Switch, Service Access	32	W10188051	Jumper, Line Filter
5	3400618	Screw	20	3400408	Screw	33	W10769481	Jumper, Coin Box
6	W10133268	Cover, Display	21	3396795	Cover, Terminal Block	34	W10111027	Jumper, Transformer
7	W10657185	Plate, Control Mounting	22	W10850065	Cover, Terminal Block	35	W10807493	Jumper, Lower to Collar
8	W10140652	Screw	23	3390814	Screw	36	W10155270	Cable Tie
9	W11582595	Control Board	24	W11332324	Power Cord			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
10	W11455510	Collar	25	W10773242	Screw			Greenwald Industries
11	W10133514	Standoff, Circuit Board	26	694415	Clip, Strain Relief			212 Middlesex Ave
12	W10139046	Nut	27	W11498818	Instructions, Installation (Card Reader)			Chester, CT 06412
13	W10133285	Transformer 120Vac To 22.5Vac	28	W10239515	Harness, Card Reader			1-800-221-0982
14	W10306592	Filter, RFI						sales@greenwaldindustries.com
15	8533971	Screw						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	18	8283298	Jumper, Door Switch	39	8539892	Wire, Motor To Belt Switch
	W11647897	Installation Instructions	19	W10291934	Clip	40	W10694688	Panel, Front
	W11651037	Tech Sheet	20	W10131172	Belt, Drive	41	W10237959	Switch, Door
	W11463414	Installation Instructions, Card Reader	21	3391943	Boot, Foot	42	98129	Screw
2	3391915	Screw	22	W10836094	Pad, Sound	43	3388229	Retainer
3	3390663	Screw	23	98997	Clip	44	3387242	Seal, Front Panel
4	3391846	Clip, Front Panel	24	3387561	Clamp, Pipe	45	342055	Screw
5	W10807483	Harness, Upper/Lower	25	3390647	Screw	46	W11566857	Burner Assembly
6	697773	Screw	26	697215	Panel, Toe (White)	47	W10141728	Valve, Gas (60 Hz - Complete)
7	W11161907	Cabinet (White)	27	W10918085	Assembly, Motor 60 HZ.	48	3387057	Screw
8	3392100	Foot, Dryer	28	3393657	Restrainer, Belt	49	W10366705	Screw
9	660658	Clamp, Motor	29	3394341	Pulley, Motor	50	686590	Ignitor
10	W10446781	Spring, Idler	30	3405160	Belt, Drive (Blower Wheel)	51	343641	Screw
11	3389420	Screw	31	W10521429	Cover Strike (White)	52	W11378153	Cover, Terminal
12	693995	Screw	32	W10135695	Bracket, Motor	53	3390814	Screw
13	W10344192	Assembly, Idler	33	3392186	Washer	54	345670	Lock Top
14	W10879744	Screw	34	693152	Bumper			DRYER EXHAUST KIT NOT INCLUDED
15	W10576519	Seal, Deflector	35	W11233966	Switch, Assembly	W10470674		Kit, 4-Way Venting
16	W11224633	Strike, Door	36	8564010	Assembly, Switch and Actuator			
17	8529757	Bracket, Burner	37	W11159569	Bracket, Switch			
			38	W10167613	Wire, Belt Switch			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	21	3391846	Clip, Front Panel	40	3400523	Bolt, Security
2	3391915	Screw	22	98997	Clip	41	W10237959	Switch, Door
3	660658	Clamp, Motor	23	3979115	Bracket, Angle	42	98129	Screw
4	W10879744	Screw	24	3387561	Clamp, Pipe	43	3389233	Bushing
5	W11233966	Switch, Assembly	25	W11384447	Cabinet (White)	44	3387242	Seal, Front Panel
6	8564010	Assembly, Switch and Actuator	26	W10117347	Cotter Pin	45	342055	Screw
7	W11159569	Bracket, Switch	27	W10918085	Assembly, Motor 60 HZ.	46	3388229	Retainer
8	W10167613	Wire, Belt Switch	28	3393657	Restrainer, Belt	47	W11224633	Strike, Door
9	8539892	Wire, Motor To Belt Switch	29	3394341	Pulley, Motor	48	W10694688	Panel, Front
10	W10446781	Spring, Idler	30	3405160	Belt, Drive (Blower Wheel)	49	W11566857	Burner Assembly
11	3389420	Screw	31	W10521429	Cover Strike (White)	50	W10141728	Valve, Gas (60 Hz - Complete)
12	W10131172	Belt, Drive	32	W10135695	Bracket, Motor	51	3387057	Screw
13	W10344192	Assembly, Idler	33	693152	Bumper	52	W10366705	Screw
14	693995	Screw	34	3389351	Top (White)	53	686590	Ignitor
15	W10576519	Seal, Deflector	35	697215	Panel, Toe (White)	54	343641	Screw
16	697773	Screw	36	3392186	Washer	55	W11378153	Cover, Terminal
17	8529757	Bracket, Burner	37	W10807483	Harness, Upper/Lower	56	3390814	Screw
18	W11325273	Boot, Foot	38	8283298	Jumper, Door Switch	57	345670	Lock Top
19	W10291934	Clip	39	3390647	Screw			DRYER EXHAUST KIT NOT INCLUDED
20	W10836094	Pad, Sound				W10470674		Kit, 4-Way Venting


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10513690	Assembly, Inner Door (White)	5	W10354795	Seal, Door	11	W10284121	Glass, Door
2	8519354	Retainer, Window	6	3393258	Screw	12	W10284127	Assembly, Door Outer (White)
3	W10279703	Assembly, Hinge and Pin (Silver)	7	W10192860	Screw	13	W10191265	Plug, Hinge (White)
4	342055	Screw	8	W10284122	Seal, Window			
			9	690081	Assembly, Door Catch			
			10	W10470571	Inner Door (White)			

UPPER AND LOWER BULKHEAD PARTS




UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359272	Shaft, Drum Roller - Left Hand Thread	15	8573824	Funnel, Burner	29	8066086	Plug, Drum Hole
2	8544362	Housing, Blower	16	W10001120	Nut, Hex (Left Hand Thread)	30	697693	Baffle, Drum
3	8533971	Screw	17	W11162455	Bulkhead, Rear	31	695240	Screw
4	90767	Screw	18	3387459	Washer	32	697557	Bulkhead, Front
5	W10865336	Assembly, Air Duct	19	W10359271	Shaft, Drum Roller - Right Hand Thread	33	3402841	Lens, Drum Light
6	W10685669	Assembly, Outlet Housing	20	W10512946	Washer, Tri Ring	34	3392519	Fuse, Thermal (91C)
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	35	697770	Seal, Plate Cover
8	3934666	Nut, Hex	22	338906	Sensor, Radiant	36	W10049370	Screen, Lint
9	8066224	Pipe, Exhaust	23	8573713	Cut-Off, Thermal	37	W10349492	Wheel, Blower
10	8572105	Clip, Exhaust	24	3391912	Thermostat, Hi Limit	38	W10193019	Thermostat, Electronic (155F)
11	3357011	Screw	25	W10545923	Assembly, Drum	39	3387230	Screw
12	W10345456	Clip, Spring	26	W10219342	Screw	40	W10131836	Thermostat
13	3390647	Screw	27	W10521118	Seal, Drum	41	489463	Screw
14	8066168	Assembly, Lint Duct	28	8578825	Bracket, Drum Light			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASSES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11566857	Burner Assembly	12	694538	Bracket, Coil	22	W10110395	Pipe, Gas Supply
2	688617	Tube, Burner	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	23	3389889	Bracket, Support
3	694298	Bracket, Ignitor				24	3387561	Clamp, Pipe
4	686590	Ignitor	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			FOLLOWING PARTS NOT ILLUSTRATED
5	W10366705	Screw				W10135245		Conversion Kit (Type 1 and 2) to Type L.P.G.
6	343641	Screw	15	694424	Leak, Limiter			
7	3389871	Base, Burner	16	694423	Screw, Regulator Adjustment	W10233219		LP Conversion Kit (EU Type 4)
8	3387057	Screw				W10832960		LP Conversion Kit (FR/BE Nat Gas)
9		Orifice, Burner	17	694422	Spring, Regulator	W10832961		LP Conversion Kit (AUS Type 4)
	234870	Type 1 (Natural)	18	239822	Plug, Pipe			
	234868	Type 4 (Propane)	19	697441	Valve, Gas			
10	W10141728	Valve, Gas (60 Hz - Complete)	20	233076	Nut, Compression			
11	694421	Screw, Coil	21	3393767	Pipe, Tail			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	Paint, Touch-up (White 1/2 oz)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	Paint, Spray (White 12 oz)
	350938	Paint, Spray (Gray Primer 12 oz)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	Paint, Bulk (White Uncut 1 qt)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing