




**COMMERCIAL GAS DRYER
MULTI-LOAD COIN SERVICE PARTS LIST**

MODELS:

MDG30PCDWW. (White) (as of January 2017)


COIN CONTROL DOOR ASSEMBLY



COIN CONTROL DOOR ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR160038	High-Security MK-100 Lock Assembly with Key	5	WFR817289	Black Trim	9	WFR102603	Control Door Rod Support Catch
	WFR160140	Key ONLY (key number XX4451)	6	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)	10	WFR102601	Control Door Rod Retainer Clip
2	WFR160066	Lock Cam Only	7	WFR152014	Serrated Hex Flange Nut 1/4-20	11	WFR102502	Control Door Support Rod
3	WFR112354	Maytag Badge	8	WFR150317	Screw 10-32 x 1/4 in (TORX PLUS®)			
4	WFR823301	Control Door Assembly with Black Trim						


MICROPROCESSOR CONTROL PANEL ASSEMBLY



MICROPROCESSOR CONTROL PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR818232	25¢ Coin Assembly	7	WFR137250	Phase 7 Coin Ribbon Cable	10	WFR814957	Phase 7 Coin Control Panel Complete
2	WFR883774	Hanke Optical Switch Assembly with Connector	8	WFR887011	Phase 7.3 Gen 2 Coin Board, No SAFE/FSS		WFR814917	Phase 7 Coin Control Panel ONLY
3	WFR112575	Phase 7.3 Coin Keyboard	9	WFR136111	Fuse 5 Amp (Slo-Blo)	11	WFR152102	Nut M3
4	WFR137270	Liquid Crystal Display						
5	WFR153010	Lock Washer #6						
6	WFR150005	Screw 6-32 x 1/4 in						


COIN VAULT ASSEMBLY



COIN VAULT ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR884050	Coin Vault Assembly Complete	4	WFR875061	Key Lock Assembly Complete (1/4 Turn)	8	WFR102601	Control Door Rod Retainer Clip
	WFR823143	Coin Vault ONLY	5	WFR160028	Cam ONLY (1/4 Turn)	9	WFR102603	Control Door Rod Support Catch
2	WFR802018	Coin Box Faceplate ONLY (1/4 Turn)	6	WFR152014	Serrated Hex Flange Nut 1/4-20			
3	WFR802020	Coin Box Assembly (1/4 Turn)	7	WFR102502	Control Door Support Rod			
	WFR802019	Coin Box ONLY (1/4 Turn)						


FRONT PANEL ASSEMBLY



FRONT PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR825643	Front Panel Assembly	4	WFR121405	Rubber Grommet	6	WFR152014	Serrated Hex Flange Nut 1/4-20
2	WFR102004	Round Door Magnet 3/4 in	5	WFR814756	Main Door Hinge Assembly	7	WFR150313	Screw 10-16 x 1/2 in (TORX®)
3	WFR152223	Screw 10-32 x 1/2 in (TORX®)						


MAIN DOOR ASSEMBLY



MAIN DOOR ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR102210	Door Glass	5	WFR150120	Screw 10-32 x 7/16 in	8	WFR882991	Black Main Door Assembly with Hinge Assembly
2	WFR102328	Handle Edge	6	WFR151010	Nut 10-32 (Black)			(includes No(s) 1 through 8)
3	WFR152014	Serrated Hex Flange Nut 1/4-20	7	WFR102349	Door Gasket	9	WFR152014	Serrated Hex Flange Nut 1/4-20
4	WFR814756	Main Door Hinge Assembly						

MAIN DOOR SWITCH ASSEMBLY




MAIN DOOR SWITCH ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR152013	Nut 6-32
2	WFR153010	Lock Washer #6
3	WFR137005	Switch, Single Pole Door
4	WFR121028	Insulated Female Terminal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	WFR154281	Standard Nylon Spacer 3/8 in
6	WFR814756	Main Door Hinge Assembly
7	WFR153565	Self Clinching Stud 6-32 x 1 in

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	WFR313218	Main Door Switch Housing ONLY
9	WFR150201	Screw 10-32 x 1/4 in
10	WFR121405	Rubber Grommet


TUMBLER / SUPPORT ASSEMBLIES



TUMBLER / SUPPORT ASSEMBLIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR800803	Tumbler and Support Assembly Complete (includes No(s) 1 to 9)	3	WFR301304	Galvanized Tumbler Rib	8	WFR152027	Lock Nut 3/8-16
	WFR800703	Tumbler ONLY	4	WFR115986	Felt Tumbler Pad	9	WFR153005	Split Lock Washer 3/8 in
2	WFR150313	Screw 10-16 x 1/2 in (TORX®)	5	WFR100915	Tie Rod 3/8 -16 x 31 1/8 in			
	WFR150429	TORX® Hand Driver T25 (for removal of TORX® head screw)	6	WFR153004	Washer 3/8 x 1 in			
			7	WFR800603	Tumbler Support ONLY			


TUMBLER BEARING ASSEMBLY



TUMBLER BEARING ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR880203	Flange Bearing 1 3/8 in	7	WFR153004	Washer 3/8 x 1 in	14	WFR150610	Set Screw 5/16-18 x 1 1/2 in
2	WFR153005	Split Lock Washer 3/8 in	8	WFR829120	Set Screws 5/16-24 x 3/8 in (2 pcs)	15	WFR822735	Rotational Sensor Assembly
3	WFR152005	Nut 3/8-16	9	WFR170608	Sintered 8 Magnet	16	WFR101100	Pulley 18 in
4	WFR883387	Bearing Assembly Complete	10	WFR152004	Nut 5/16-18	17	WFR100108	V BELT 5L680R
	WFR800980	Bearing Support ONLY	11	WFR150621	Tap Bolt 5/16-18 x 1 1/2 in	18	WFR100713	Key 1/4 x 1/4 x 7/8 in
5	WFR880779	Pillow Block Bearing 1 3/8 in	12	WFR153002	Split Lock Washer 5/16 in			
6	WFR150601	Bolt 3/8 x 2 in	13	WFR150501	Tap Bolt 5/16-18 x 3/4 in			


IDLER BEARING ASSEMBLY



IDLER BEARING ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR100108	V BELT 5L680R	6	WFR882576	Idler Bearing Assembly Complete	9	WFR153004	Washer 3/8 x 1 in
2	WFR101129	Pulley				10	WFR801009	Idler Square Washer
3	WFR100110	V-Belt 4L500R			(includes No(s) 5 through 12)	11	WFR152004	Nut 5/16-18
4	WFR154301	Set Screw 5/16-18 x 1 in	7	WFR150617	Bolt 3/8-16 x 1 in	12	WFR150509	Bolt 5/16-18 x 3 in
5	WFR100705	Key 3/16 x 3/16 x 1 3/8 in	8	WFR153005	Split Lock Washer 3/8 in			


LINT DOOR ASSEMBLY



LINT DOOR ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR160039	Lock Assembly (no key)	5	WFR884046	White Drop Lint Door Assembly	7	WFR117603	Neoprene Gasket Tape (When Ordering Specify Length, sold by the inch)
	WFR160140	Key ONLY (key number XX4451)			(includes No(s) 4 through 8)	8	WFR884045	Black Trim Plate
2	WFR160014	Cam ONLY	6	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)	9	WFR152014	Serrated Hex Flange Nut 1/4-20
3	WFR108120	Chain, Drop Lint Door						
4	WFR150419	Screw Tamperproof #6 x 1/2 in						


LINT SCREEN ASSEMBLY



LINT SCREEN ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR800408	Lint Trap Assembly Complete (includes No(s) 1 through 4)	2	WFR304102	Lint Screen Holder	5	WFR154200	Rivet 5/32 in
			3	WFR150300	Screw 10-16 x 1/2 in (Hex Washer TEK Crimptite®)	6	WFR122116	Lint Door Switch
	WFR800409	Lint Trap ONLY	4	WFR108201	Lint Screen	7	WFR323724	Lint Drawer Switch Bracket
						8	WFR150425	Screw #12-24 x 3/8 in


MOTOR MOUNT ASSEMBLY



MOTOR MOUNT ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR100110	V-Belt 4L500R	7	WFR122701	Female Crimp Socket	14	WFR100604	Impellor 12 1/2 in
2	WFR101104	Motor Pulley 1/2 x 2 in		WFR122801	Pin / Socket Extraction Tool (Not Illustrated)	15	WFR152006	Nut 1/2-20
3	WFR150501	Tap Bolt 5/16-18 x 3/4 in	8	WFR137030	8 Pin Connector	16	WFR100702	Key 1/8 x 1/8 x 1-1/2 in
4	WFR153002	Split Lock Washer 5/16 in	9	WFR152004	Nut 5/16-18			
5	WFR153001	Washer 5/16 in	10	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)			
6	WFR803938	Motor Assembly Complete (includes No(s) 2 through 15)	11	WFR154000	Tinnerman® Nut 5/16-18			
	WFR181049	Motor with Plug 1/2 hp 100-230v 1ø 50/60 Hz	12	WFR850017	Motor Mount ONLY			
			13	WFR153050	Washer 1/2 x 1 1/6 in			


SENSOR BRACKET ASSEMBLY



SENSOR BRACKET ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR884614	Temperature Sensor Probe Assembly (includes No(s) 1 and 5 through 8)	4	WFR152000	Nut 6-32	9	WFR150005	Screw 6-32 x 1/4 in
2	WFR130103	Hi-Limit Thermostat 225°	5	WFR121028	Insulated Female Terminal	10	WFR805846	Temperature Sensor Assembly Complete
3	WFR153010	Lock Washer #6	6	WFR122643	Pin Crimp Socket		WFR305007	Temperature Sensor Bracket ONLY
			7	WFR122649	4 Pin Connector	11	WFR150301	Screw 8-18 x 7/16 in
			8	WFR154007	Push On Fastener 1/4 in			


DIRECT SPARK IGNITION BURNER ASSEMBLY



DIRECT SPARK IGNITION BURNER ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR809725	Natural Gas Burner Assembly Complete (includes No(s) 1, 2, and 4 through 18)	5	WFR128979	Gas Valve (Natural Gas)	12	WFR150300	Screw 10-16 x 1/2 in (Hex Washer TEK Crimptite®)
	WFR850858	Burner Box ONLY	6	WFR345590	Gas Valve Bracket	13	WFR152013	Nut 6-32
2	WFR141105	Large Burner Tube	7	WFR150309	Screw 10-16 x 1/2 in (Hex Head TEK Crimptite®)	14	WFR153017	SAE Washer #6
3	WFR140820	Burner Orifice #29 (Natural Gas) ONLY	8	WFR150108	Screw 8-32 x 1/2 in	15	WFR128937	Direct Spark Ignition Module (3 Tries)
	WFR874050	L.P. Conversion Kit (includes orifices) (Consult factory for elevations +2K Ft)	9	WFR151001	Nut 8-32	16	WFR810029	Direct Spark Ignition Module Mounting Bracket
			10	WFR128915	Ignitor Probe ONLY	17	WFR141317	Union Elbow 1/2 in
			11	WFR829999	High Voltage Wire with 1/4 in. Spade Connection	18	WFR142809	Pipe 1/2 x 29 1/8 in


SAIL SWITCH / BURNER SUB ASSEMBLY



SAIL SWITCH / BURNER SUB ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR350283	Sail Switch Box Cover and Bracket ONLY	6	WFR319202	Sail Switch Damper	11	WFR151000	Nut 6-32
2	WFR150300	Screw 10-16 x 1/2 in (Hex Washer TEK Crimptite®)	7	WFR154002	Push-On Fastener 1/8 in	12	WFR150001	Screw 6-32 x 1/2 in
3	WFR122200	Service Switch	8	WFR319200	Sail Switch Bracket ONLY	13	WFR130201	Thermostat Hi-Limit Reset Switch 330°
4	WFR150303	Screw #4 x 3/4 in	9	WFR142809	Pipe 1/2 x 29 1/8 in			
5	WFR105500	Sail Switch Rod Assembly	10	WFR319704	Hi-Limit Mounting Bracket			


120V (1Ø) REAR ELECTRICAL PANEL ASSEMBLY



120V (1Ø) REAR ELECTRICAL PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR398301	Rear Electric Panel	6	WFR150301	Screw 8-18 x 7/16 in	10	WFR121010	Lug Terminal 14-4 (Ground)
2	WFR120766	Terminal Block Bracket	7	WFR824081	RC Network Assembly	11	WFR120910	Screw 10-32 x 3/8 in
3	WFR120758	Terminal Block	8	WFR132498	DP Contactor 24V 2-Pole			
4	WFR136101	Fuse 800mA (SLO-BLO)	9	WFR132109	Transformer – 24 vac Assembly (for 120V 60 Hz Models Only)			
5	WFR136008	Fuse Block						

OUTER TOP / BACK GUARD ASSEMBLIES



OUTER TOP / BACK GUARD ASSEMBLIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR322935	Electrical Box Cover	4	WFR150300	Screw 10-16 x 1/2 in (Hex Washer TEK Crimptite®)	6	WFR314513	Bottom Back Guard
2	WFR150301	Screw 8-18 x 7/16 in				7	WFR103500	Adjustable Leveling Leg
3	WFR330077	Top Back Guard	5	WFR312510	Outer Top			