




COMMERCIAL INDUSTRIAL GAS DRYER SERVICE PARTS LIST

MODELS:

MLG45PDC


CONTROL PANEL ASSEMBLY



CONTROL PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR125797	Assembly, Single Coin Drop	7	WFR114524	Keypad Label White	19	WFR328873	Microprocessor Board Cover
2	WFR828489	Optic Switch Assembly		WFR114542	Keypad Label Clear (Stainless Steel Model)	20	WFR150310	Screw 8 x 1/2 in
3	WFR150002	Screw 6-32 x 1 in	8	WFR160070	Control Door Lock Assembly			
4	WFR153010	Lock Washer #6	9	WFR112543	Display Cover			
5	WFR152102	Nut M3	10	WFR117605	Foam Tape (When Ordering Specify Length)			
6	WFR845921	White Control Panel Assembly Complete (includes No(s) 1 through 20)	11	WFR112544	Keypad Push Buttons			
	WFR845920	Control Panel ONLY (Specify Color When Ordering)	12	WFR112541	Keypad Membrane			
	WFR845949	Stainless Control Panel Assembly Complete (includes No(s) 1 through 20)	13	WFR800949	Microprocessor Mounting Panel			
	WFR845948	Stainless Control Panel ONLY	14	WFR153022	Washer #10			
			15	WFR152001	Nut 8-32 x 3/8 in			
			16	WFR154008	Nut, "U"			
			17	WFR137300	Microprocessor ONLY			
			18	WFR152013	Nut 6-32			


COIN VAULT ASSEMBLY



COIN VAULT ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845936	Coin Box Assembly with Magnet and Faceplate	4	WFR845923	Coin Vault ONLY	8	WFR154200	Rivet 5/32 in
	WFR345084	Black Coin Box Faceplate ONLY	5		Lower Front Panel (refer to Lower Front Panel Assembly page)	9	WFR836224	Magnetic Reed Switch Assembly
2	WFR160036	ACE® Lock Assembly with Key	6	WFR152014	Serrated Hex Flange Nut 1/4-20			
3	WFR160136	ACE® Key ONLY (Specify key number when ordering)	7	WFR102102	Door Magnet			


REAR ELECTRICAL PANEL



REAR ELECTRICAL PANEL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR121010	Lug Terminal 14-4 (Ground)	7	WFR153073	Nut 8-32	11	WFR845954	Microprocessor Control Panel Assembly
2	WFR132498	DP Contactor 24V 2-Pole	8	WFR824828	R.C. Network with Connectors			(includes No(s) 1 through 13)
3	WFR136057	Fuse 1/2 Amp (Slo-Blo)	9	WFR112075	Ground Symbol Label		WFR845772	Microprocessor Control Panel ONLY
4	WFR137241	Interconnect Board	10	WFR114506	Disconnect Supply Fuse Label	12	WFR835503	Transformer Assembly 24V
5	WFR150005	Screw 6-32 x 1/4 in				13	WFR132068	Transformer
6	WFR150300	Screw 10-16 x 1/2 in (Hex Washer TEK Crimptite®)						


UPPER FRONT PANEL ASSEMBLY



UPPER FRONT PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845913	White Top Front Panel Assembly (includes No(s) 1 to 3 and 5 to 8)	2	WFR152223	Screw 10-32 x 1/2 in (TORX®)	8	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)
	WFR845952	Stainless Top Front Panel Assembly (includes No(s) 1 to 3 and 5 to 8)	3	WFR102008	Round Door Magnet 3/4 in	9	WFR845917	Black Front Panel Middle Trim
	WFR845914	White Top Front Panel ONLY	4	WFR150313	Screw 10-16 x 1/2 in (TORX®)	10	WFR150319	Screw 10-32 x 1/2 in (Black)
	WFR845950	Stainless Top Front Panel ONLY	5	WFR814755	Main Door Hinge Assembly			
			6	WFR152014	Serrated Hex Flange Nut 1/4-20			
			7	WFR121405	Rubber Grommet			


LOWER FRONT PANEL ASSEMBLY



LOWER FRONT PANEL ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845915	White Bottom Front Panel Assembly (includes No(s) 1 to 3 and 5 to 8)	2	WFR152223	Screw 10-32 x 1/2 in (TORX®)	8	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)
	WFR845953	Stainless Bottom Front Panel Assembly (includes No(s) 1 to 3 and 5 to 8)	3	WFR102008	Round Door Magnet 3/4 in	9	WFR845959	Black Front Panel Lower Trim
	WFR845916	White Bottom Front Panel ONLY	4	WFR150313	Screw 10-16 x 1/2 in (TORX®)	10	WFR150319	Screw 10-32 x 1/2 in (Black)
	WFR845951	Stainless Bottom Front Panel ONLY	5	WFR814755	Main Door Hinge Assembly			
			6	WFR152014	Serrated Hex Flange Nut 1/4-20			
			7	WFR121405	Rubber Grommet			


MAIN DOOR SWITCH ASSEMBLY



MAIN DOOR SWITCH ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR152013	Nut 6-32	5	WFR154281	Standard Nylon Spacer 3/8 in	8	WFR313647	Main Door Switch Housing ONLY
2	WFR153010	Lock Washer #6				9	WFR150201	Screw 10-32 x 1/4 in
3	WFR137005	Switch, Single Pole Door	6	WFR814755	Main Door Hinge Assembly	10	WFR121405	Rubber Grommet
4	WFR121028	Insulated Female Terminal	7	WFR153576	Black Clinching Stud 6-32 x 1 in			

MAIN DOOR ASSEMBLY




MAIN DOOR ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR185498	Door Glass	4	WFR110006	Black Strapping Tape 1/2 in
2	WFR845946	Black Main Door Assembly (includes No(s) 1 through 5)	5	WFR185502	Door Gasket
3	WFR152014	Serrated Hex Flange Nut 1/4-20			

TUMBLER / SUPPORT ASSEMBLIES


UPPER TUMBLER SUPPORT



TUMBLER / SUPPORT ASSEMBLIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845908	Tumbler and Support Assembly Complete with Felt Collar (includes No(s) 1 through 8)	5	WFR153005	Split Lock Washer 3/8 in	11	WFR130117	Thermistor
	WFR845909	Tumbler ONLY without Felt Collar	6	WFR845752	Tumbler Support	12	WFR130118	170° Automatic High Limit
2	WFR100915	Tie Rod 3/8 -16 x 31 1/8 in	7	WFR115917	Tumbler Front Felt	13	WFR150005	Screw 6-32 x 1/4 in
3	WFR153004	Washer 3/8 x 1 in	8	WFR115918	Rear Tumbler Felt	14	WFR153010	Lock Washer #6
4	WFR152027	Lock Nut 3/8-16	9	WFR845941	Thermostat Bracket Complete	15	WFR152000	Nut 6-32
				WFR345089	Temperature Sensor Bracket	16	WFR150331	Screw 8-18 x 1/2 in
			10	WFR130119	190° Automatic High Limit	17	WFR845926	Lint Drawer Switch Bracket Assembly
							WFR122002	Lint Drawer Switch Only

TUMBLER BEARING ASSEMBLY




TUMBLER BEARING ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR880220	Flange Bearing 1 3/4 in	6	WFR150601	Bolt 3/8 x 2 in	14	WFR150501	Tap Bolt 5/16-18 x 3/4 in
2	WFR153025	Split Lock Washer 9/16 in	7	WFR153004	Washer 3/8 x 1 in	15	WFR170608	Sintered 8 Magnet
3	WFR152050	Nut 9/16-12	8	WFR153005	Split Lock Washer 3/8 in	16	WFR836224	Magnetic Reed Switch Assembly
4	WFR845785	Bearing Assembly Complete	9	WFR152005	Nut 3/8-16	17	WFR150610	Set Screw 5/16-18 x 1 1/2 in
		(includes No(s) 4 to 15 and 17)	10	WFR154384	Set Screw 5/16-24 x 5/16 in (Black)	18	WFR100147	V-Belt
	WFR845784	Bearing Support ONLY	11	WFR152004	Nut 5/16-18	19	WFR100713	Key 1/4 x 1/4 x 7/8 in
5	WFR880779	Pillow Block Bearing 1 3/8 in	12	WFR150621	Tap Bolt 5/16-18 x 1 1/2 in	20	WFR884042	Pulley 18 in
			13	WFR153002	Split Lock Washer 5/16 in			

LINT DRAWER (BASKET) ASSEMBLY

UPPER LINT DRAWER (BASKET) ASSEMBLY




Note: Duplicate All Components
for Lower Lint Drawer (Basket) Assembly

LINT DRAWER (BASKET) ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845930	Lint Drawer Assembly (includes No(s) 1 through 9)	4	WFR160140	Key ONLY (key number XX4451)	8	WFR345048	Lint Drawer Stop
	WFR845928	Lint Drawer Body	5	WFR160014	Cam ONLY	9	WFR154220	Rivet 3/16 in
2	WFR845929	Lint Drawer Handle	6	WFR117605	Foam Tape (When Ordering Specify Length)			
3	WFR160039	Lock Assembly (no key)	7	WFR154211	Rivet 5/32 in			


IDLER BEARING ASSEMBLY



IDLER BEARING ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR100147	V-Belt	6	WFR100705	Key 3/16 x 3/16 x 1 3/8 in	10	WFR153005	Split Lock Washer 3/8 in
2	WFR101129	Pulley	7	WFR152004	Nut 5/16-18	11	WFR153004	Washer 3/8 x 1 in
3	WFR100181	V-Belt (To Motor Pulley)	8	WFR150509	Bolt 5/16-18 x 3 in			
4	WFR154301	Set Screw 5/16-18 x 1 in	9	WFR150617	Bolt 3/8-16 x 1 in			
5	WFR882777	Idler Bearing Assembly Complete						


MOTOR MOUNT ASSEMBLY



MOTOR MOUNT ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845783	Impellor 13 in	8	WFR153002	Split Lock Washer 5/16 in	13	WFR116010	Felt Motor Seal ONLY
2	WFR152006	Nut 1/2-20	9	WFR153001	Washer 5/16 in	14	WFR101132	Motor Pulley 2 x 5/8 in
3	WFR153050	Washer 1/2 x 1 1/6 in	10	WFR154000	Tinnerman® Nut 5/16-18	15	WFR100181	V-Belt (To Motor Pulley)
4	WFR100705	Key 3/16 x 3/16 x 1 3/8 in	11	WFR845758	Motor Mount ONLY			
5	WFR117604	Foam Tape (When Ordering Specify Length, sold by the inch)		WFR845935	Motor Mount Assembly Complete 3/4 hp 115-230v 1ø 60 Hz			
6	WFR150331	Screw 8-18 x 1/2 in	12	WFR100069	Motor with Plug 3/4 hp 115-230v 1ø 60 Hz			
7	WFR150501	Tap Bolt 5/16-18 x 3/4 in						


GAS BURNER ASSEMBLY



GAS BURNER ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR845933	Gas Burner Assembly Complete (includes No(s) 1 through 16)	9	WFR141131	Flame Spreader	16	WFR345108	Gas Valve Hold Down Bracket
	WFR128979	Gas Valve (Natural Gas)	10	WFR140834	Burner Orifice (Natural #4)	17	WFR152013	Nut 6-32
2	WFR150331	Screw 8-18 x 1/2 in		WFR140818	Burner Orifice (Propane #31)	18	WFR153017	SAE Washer #6
3	WFR318009	Burner Tube Bracket		WFR887193	Conversion Kit (Natural Gas to Propane)	19	WFR887133	Direct Spark Ignition Module with 3 Tries
4	WFR153012	Washer #8	11	WFR845934	Burner Tube Bracket	20	WFR845756	Direct Spark Ignition Module Bracket
5	WFR152001	Nut 8-32 x 3/8 in	12	WFR128918	Flame Sensor	21	WFR121502	Standoff Clip 1/2 in
6	WFR323393	Gas Valve Bracket	13	WFR121300	Open/Closed Bushing			
7	WFR150301	Screw 8-18 x 7/16 in	14	WFR829998	H.V. Cable Assembly			
8	WFR141235	Manifold Port 1/2 in	15	WFR141320	Union-Shutoff Valve 1/2M x 1/2F in			


BACK GUARDS AND BURNER BOX



BACK GUARDS AND BURNER BOX

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR345211	Back Guard	4	WFR130101	Thermostat 180°	6	WFR845822	Flue Exhaust Assembly
2	WFR150331	Screw 8-18 x 1/2 in	5	WFR845931	Burner Box Assembly ONLY			
3	WFR130201	Thermostat Hi-Limit Reset Switch 330°				7		Exhaust Assembly, Please contact factory for any parts.

SAIL SWITCH ASSEMBLY



SAIL SWITCH ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WFR345090	Sail Switch Damper	3	WFR154002	Push-On Fastener 1/8 in	7	WFR345092	Service Switch Bracket
	WFR845942	Sail Switch Assembly Complete (includes No(s) 1 through 10)	4	WFR345091	Service Switch Cover	8	WFR122200	Service Switch
			5	WFR150331	Screw 8-18 x 1/2 in	9	WFR150303	Screw #4 x 3/4 in
2	WFR105500	Sail Switch Rod Assembly	6	WFR835516	Sail Switch L.E.D. Light Assembly	10	WFR154004	Twin Speed Nut