

## TECHNICAL INFORMATION INDEX

TI Number	Subject	Models affected
1001	Main power terminal mounting	W75-W185
1002E-1004B	Obsolete	---
1005	Conversion to drain pump	W74
1006	Out of balance switch mounting	EX7
1007B	Conversion to normally-closed drain	W75-W184
1008B	Time delay relay installation	Hydro extractors
1009	Door lock servicing	W74-W184
1010A	Installing electronic centrifugal switch	W123 through W185
1011	Conversion to non-metered operation	W74-W244
1012B-1014C	Obsolete	---
1015	Motor overload protector installation	W123-W185
1016	Conversion to non-metered operation	EX7
1017A	Conversion to non-metered operation	W75-W185
1018	Motor gear replacement	P10
1019	Conversion to non-metered operation	Hydro extractors
1020	Conversion to drain pump	EX7
1021	Motor clutch and gear replacement	P10
1022	Door bellows replacement	P10
1023	Obsolete	---
1024	4 pushbutton to rotary cycle selector conversion	W73-W183
1025	Obsolete	---
1026	Conversion to non-metered operation	P10
1027	Conversion to non-metered operation	P12
1028C	6 pushbutton to rotary cycle selector conversion	W73-W183
1029	Independent wash capacitor installation	W/FL125
1030	Belt tensioning kit installation	W/FL185
1031A	Conversion to warm water rinses	W75-W125 (early models)
1032	Time delay relay installation	C40, C60
1033	Independent wash capacitor installation	W/FL185
1034	Hydro-extractor installation notes	C41, C61, C91
1035-1036D	Obsolete	---
1037	Keltner coin meter installation w/no-soak option	W74-W184
1038	Liquid supply signal connections	FL125, FL185
1039-1046D	Obsolete	---
1047B	Liquid supply signal details for factory-equipped washers	W75-W185
1048A	Liquid supply signal details	FL244
1049B	Conversion to liquid supplies	W244
1050A	Aqua Clean cold water bottom-fill	50 pound ACS
1051B	Installing X-10 price reduction system	W75ES -W245ES
1052A	Set-O-Matic coin meter installation	W75-W185 (incl ES)
1053A	Obsolete	W75, W105, EX7, EX10
1054	Conversion to liquid supplies	W75-W125 (early models)
1055	Conversion to liquid supplies	W185 (early models)
1056	Soap box flush temperature modification	W185ES
1057A	Precautions when servicing electronic controls	All
1058	Locking lever replacement	EX12, EX22, EXSM230&350
1059	Obsolete	---
1060A	Interlocking extract relay with wash relay	W75-W185

1061	Rotation guard warning label	FL125, FL185
1062	Card programmed operation	FL models
1063A	Greenwald coin meter installation and adjustment	All coin models
1064	Obsolete	---
1065A	Installing Munzprufer coin meter	All coin models
1066	Servicing P12 motor	P12
1067	Obsolete	---
1068	Energy savings options	W75-W185
1069A	Conversion to liquid supplies	W75-W125 w/timer 89781x
1070	Conversion to powdered supplies	W75-W125 w/timer 89781x
1071	Conversion to motorized drain valve	W75-W185
1072	Conversion to coin operation	W75-W185
1073	Repairing ON/OFF and RESTART switches	FL125, FL185
1074	Belt adjustment on dual-motor washers	All dual-motor models
1075	External drain pump kit	W75, W105, EX7, EX10
1076	Conversion to liquid supplies	W185 w/timer 897812 & 822
1077A	Coin meter installation	WE16
1078A	Doorlock update (S/N dependant)	W73-W183
1079	Doorlock update (S/N dependant)	W73-W183
1080	WE16 in-use lamp re-wiring	WE16
1081B	Obsolete	---
1082	Drum to front panel gap adjustment	TD30, TD50, TD75
1083B	Installing Set-O-Matic on Gen 6 Emerald	Gen 6 Emerald
10084	Installing Set-O-Matic on Gen 6 Classic	Gen 6 Classic
1085	Obsolete	---
1086	Obsolete	---
1087	Electric motor replacement	All
1088	Dealer installation guidelines	TD3030
1089	E 99 error on TD3030	TD3030
1090	E 18 error on TD3030	TD3030
1091	45E (Emerald) OR door remains locked at end of cycle	Gen 6 Emerald and Classic
1092	LP nozzle for TD3030	TD3030
1093	E 08 error on TD3030	TD3030
1094	Front panel installation	Gen 6 washers
1095	Displaced drain solenoid tube	Gen 6 washers
1096	TD3030 lint drawer tracks	TD3030
1097	Interpreting dryer error codes	TD3030
1098	TD3030 lint drawer and control locks	TD3030
1099	TD3030 control circuit change to 120V	TD3030
1100	TD3030 lint drawer noise	TD3030
1101	TD dryer belt tension	TD30, TD50, TD75
1102	Seal lubrication on EX630, EX640 and EX655	EX630, EX640, EX655
1103	Gen 6 door skirt gasket	W/SU 620-675
1104	TD dryer gas pipe notification	TD30/TD50/TD75 gas
1105	TD3030 preventive maintenance	TD3030
1106	Installation & Operating Instructions for Coin Meter Kit 482 991393	Gen 6 Classic Washers
1107	No-Step Rules for TD Dryers	All Dryers
1108	Motor Overload Protection in Single-Phase W Series Gen 6 Washers	Gen 6 1-Phase W Series Washers
1109	TD3030 Drum Bearing Fasteners	TD3030 Dryers, s/n < 2300/009169
1110	Installation of Spray Pump, Air Filter & Steam Valve on Gen 6 Aqua-Clean Washer	Gen 6 Aqua-Clean Washers

3/10/05