

IMPORTANT !!

- NOTICE TO INSTALLER -

Step 6 on the attached instruction sheet refers to a “jumper wire”, installed between the “LED” terminals of the Coin 1 (X221) and Coin 2 (X321) connectors on the coin-meter-connection circuit board. Although the instructions indicate that the jumper is only required for coin meters equipped with optical switches having a part number ending in the digits “-78”, you must install this jumper on ALL of your Generation 6 Emerald Series washers.

The jumper increases the intensity of the light-emitting device in the coin meter, insuring that the meter’s optical sensor functions reliably.

If you have questions concerning this information, or any Wascomat product, please contact our Technical Support Department at 516-371-0700. Technicians are available to assist you between 8 AM and 5 PM Eastern time, Monday through Friday.