

Puff Irons Model PIA16 & PIA38

OWNER'S MANUAL

THIS MANUAL MUST BE GIVEN TO THE EQUIPMENT OWNER.

Equipment is subject to manufacturer's standard warranty. Accuracy of illustration and description of equipment shown herein applies to product as manufactured at time of publication.

AJ0112R1

PUFF IRON

TABLE OF CONTENTS


GENERAL INFORMATION & INSTALLATION

Operating Instructions, Safety Warnings	3
Specifications, Dimensions	4
Installation Drawings	5-6
Steam Connection Instructions	7
PARTS SHEETS	
Panel Assembly for Fabric Pressing Heads	8
Panel Assembly for Fabric Pressing Heads	9
Backs, Corners, Extensions, Braces	10
Tee Pipes and Vacuum Manifolds	11
Valves and Linkage Parts	12
Central Air Vacuum and Upstem Valve	13
Steam Vacuum Valves	
Heads	
Head and Valve Assemblies	
Fabric Pressing Heads	
SERVICE AND ADJUSTMENTS	
Spring Pre-Load Adjustment	
Replacing Valve Packing Rings, Spring Replacement	20
Reseat Leaky Valve, Replace Valve Seat, Leaky Pack Nut	

OPERATING INSTRUCTIONS

CAUTION: Compliance with ANSI Z8.1-1990 (Standard for Commercial Laundry and Drycleaning Operations) requires that each Puff Iron head be covered with at least one thickness of double-face flannel and suitable cloth cover. Refer to Page 23 for part numbers for required covers.


- 1. Open, first the return line, then the globe valve in steam line and allow Puff Iron to warm up. Do not operate machine until it is hot.
- 2. Place area of garment to be finished over the head and press foot pedal for steaming.
- 3. If unit is equipped with vacuum, after steaming, press foot pedal to activate the vacuum.




CAUTION To prevent damage follow instructions listed below.

(Before installing the Puff Iron "E" Model,

the sleever head must be rotated to the working position.)



15 2 SINGLE TABLE



Steam	Pressure	60-100 P.S.I.G.
		(4.14-6.9 Bars)
Steam	Supply	½" Pipe Connection
Steam	Return	½" Pipe Connection
Vacuur	n Connection	1¼" Connection
Vacuur	n Requirement.	⅓ Press Capacity


Boiler Horsepower

Single Table.....1/8 H.P. Double Table.....1/4 H.P. Triple Table.....3/8 H.P.


33" DOUBLE TABLE


SUPPLY

33"




38" TRIPLE TABLE





Page 5



Page 6

INSTRUCTIONS FOR STEAM CONNECTIONS FOR PUFF IRONS IMPORTANT: INSTALL STEAM PIPING IN ACCORDANCE WITH ALL LOCAL REGULATIONS AND REQUIREMENTS.

- 1. Set and anchor machine in position. Machine should be level to assure proper steam circulation.
- 2. To prevent condensate draining from headers to machine, piping should have a minimum riser 12" above each respective header as illustrated. Do not make steam connection to header with a horizontal or downwardly facing tee or elbow.
- 3. Whenever possible, horizontal runs of steam must drain, by gravity, to respective steam header. Water pocket or an improperly drained steam header will provide wet steam cauing unecessary wetting-out of head covers.
- 4. In both the steam supply and steam return line, it is recommended that each have a 1/2" union and 1/2" globe valve. This will enable you to disconnect the steam connections and block steam flow to and from machine while servicing machine.
- 5. Before installing trap and check valve in steam return line, open globe valve in steam supply line to allow steam to flow through machine to flush out any dirt and scale from machine. This will assure proper operation of trap when connected.
- 6. After flushing system, install bucket trap (with built-in stainer) and check valve as illustrated. For sucessful operation of machine, install trap as close to floor and as near to machine as possible. Inspect trap carefully for inlet and outlet marking and install according to manufacturer instructions.

If steam is gravity-returned to boiler, omit trap but install check valve in return line near machine.


7. Install union and globe valve to return line and make final pipe connection to return header.

CAUTION:

Before operating Puff Iron, open globe valves in steam lines and allow Puff Iron to warm up. Under no circumstances should machine be operated until hot.

RECOMMENDATIONS

- 1. Use a separate trap for each unit. Always keep the trap clean and in good working condition.
- 2. When machine is on the end of a line of equipment, extend headers at least 4 ft. beyond machine. Install globe valve, union, check valve trap and optional by-pass at the end of a line. If gravity return to boiler, omit trap.
- 3. Insulate steam supply and return line for safety of operator and safety while servicing machine.
- 4. Keep machine in good working condition. Repair or replace any worn or defective parts.




PANEL ASSEMBLY FOR FABRIC PRESSING HEADS

Ref.	Part		Ref.	Part	
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>No.</u>	<u>No.</u>	Description
1	P154	Single Table Top	10	RC344	1/4 - 20 Ph. Hd. Screw (Pkg. of 6)
			11	TU4934	1/4 - 20 Hex Nut (Pkg. of 6)
3	P153	33" Table Top	12	TU2846	1/4 Lockwasher (Pkg. of 6)
4	P165	38" Table Top	13	TU2847	1/4 Cut Washer (Pkg. of 6)
5	P454	Table Leg, R or L	14	P274	1/4 - 20 x 3/4 Tr. Hd. Screw
*6	P511	Front Panel Asm. 15 1/2"			(Pkg. of 6)
*8	P512	Front Panel Asm. 33"			
*9	P513	Front Panel Asm. 38"			

^{*} Consists of Front Panel, Ajax Nameplate, screws, and washers.

Note: For servicing, new design allows easy access from front of machine by removing front panel screws. Nuts are welded to table leg.




PANEL ASSEMBLY FOR NON-FABRIC PRESSING HEADS

Ref.	Part		Ref.	Part	
<u>No.</u>	<u>No.</u>	Description	<u>No.</u>	<u>No.</u>	Description
1A	P637	1-Head Top w/Extension	5	P454	Table Leg, R or L
		Left & Back	*6	P511	Front Panel Asm. 15 1/2"
1B	P631	1-Head Top w/Back	*8	P512	Front Panel Asm. 33"
1C	P634	1-Head Top w/Extension	*9	P513	Front Panel Asm. 38"
		Right & Back	10	P509	1/4 - 20 Ph. Hd. Screw (Pkg. of 6)
3A	P638	2-Head Top w/Extension	11	TU4934	1/4 - 20 Hex Nut (Pkg. of 6)
		Left & Back	12	TU2846	1/4 Lockwasher (Pkg. of 6)
3B	P632	2-Head Top w/Back	13	TU2847	1/4 Cut Washer (Pkg. of 6)
3C	P635	2-Head Top w/Extension	14	P274	1/4 - 20 x 3/4 Tr. Hd. Screw
		Right & Back			(Pkg. of 6)
4A	P639	3-Head Top w/Extension			, -
		Left & Back			
4B	P633	3-Head Top w/Back			
4C	P636	3-Head Top w/Extension			
		Right & Back			

^{*} Consists of Front Panel, Ajax Nameplate, screws, and washers.


Note: For servicing, new design allows easy access from front of machine by removing front panel screws. Nuts are welded to table leg.

BACKS, CORNERS, EXTENSIONS & BRACES





Ref.	Part <u>No.</u>	Description	Ref. <u>No.</u>	Part <u>No.</u>	Description
1	P155	Back Single Table	10	P157	15" Angular Corner and Back
			11	P156	12" x 12" Sq. Extension
3	P158	Back Single Table	12	P192	7" x 10 1/2" Spacer
		w/Extension	13	P484	Long Brace for 33" Table
4	P159	Back 33" Double Table			w/Extension (L or R)
			14	P483	Short Brace for 15 1/2" & 38"
6	P167	Back 38" Triple			Tables w/Extension (L or R)
7	P161	Back (Used on 33" Table		P507	12" Square Extension w/Brace
		w/Extension)		for 33" Table	(Not Illustrated)
8	P166	Back (Used on 38" Triple		P505	12" Square Extension w/Brace
		w/Extension			for 15 1/2" & 38" Table (Not
9	P189	17" Angular Corner Back			Illustrated)
			15	P219	1/4" - 20 x 1/2" Truss
					Head Screw (Pkg. of 6)
			16	TU2846	1/4" Lock Washer (Pkg. of 6)
			17	TU4934	1/4 - 20 Hex Nut (Pkg. of 6)
			18	P270	Center Brace (Triple Table)
			19	TU7733	Self Drill Screw (Pkg. of 6)
			20	P508	Center Brace Support

TEE PIPE & VACUUM MANIFOLD PARTS



Part	
<u>No.</u>	<u>Description</u>
P557	Tee Pipe for 33" Double Table
P551	Tee Pipe for 38" Triple Table
P549	Tee Pipe for Single Table
P550	Straight Pipe for 38" Triple Table
P251	Vacuum Manifold for 38" Triple Table 40 5/8" Lg.
P257	Vacuum Manifold for 33" Double Table 31 5/8" Lg.
P259	Vacuum Manifold for 15 1/2" Single Table 18" Lg.
P271	3/4" I.D. Plastic Cap
P253	1 1/2" I.D. Plastic Cap
P256	1 1/4" Pipe Clamp
P276	1 3/4" O.D. x 1 1/2" I.D. "O" Ring
P277	1 1/4" Union with "O" Ring
M263	#8 - 3/8" S.M.S. (Pkg. of 6)
P252	Hose Adapter
	No. P557 P551 P549 P550 P251 P257 P259 P271 P253 P256 P276 P277 M263






WITHOUT VACUUM

WITH VACUUM

Ref. No.	Part <u>No.</u>	Description	Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>
1	P261	3/4" x 13" Black Pipe	13	P228	Pedal
2	P262	Jacket (Regular)	14	P260	3/8" x 7 1/2" Black Pipe
3	P298	Jacket (Vacuum)	15	P299	Flange Adapter (Vacuum)
4	M280	1/4" - 20 x 1" Carriage Bolt	16	P542	2/3 - 3/4" Union - NPT
		(Pkg. of 6)	17	P267	Flange (Vacuum)
5	P273	5/16" - 18 x 3/4" Carriage (Pkg. of 6)	18	P266	Flange (Regular)
6	TU2846	1/4" Lock Washer (Pkg. of 6)	19		(See separate page)
7	TU4934	1/4" - 20 Hx. Hd. Nut (Pkg. of 6)	20		(See separate page)
8	C249	5/16" - 18 Hex Nut (Pkg. of 6)	21	P255	Pedal Rod & Yoke Ass'y.
9	TU2814	5/16" Lock Washer (Pkg. of 6)	22	P36	Pedal Bearing Wrench (1/8")
10	P98	Collar			• • • • • • • • • • • • • • • • • • • •
11	P126	1/4" - 20 Allen Set Screw (Pkg. of 6)			
12	P132	Support Bar for 15 1/2" Table			
	P177	Support Bar for 33" Table			
	P133	Support Bar for 38" Table			

CENTRAL AIR VACUUM VALVE & UPSTREAM VALVE SINGLE OR DOUBLE PARTS



P368 Central Air Vacuum Valve - Consists of Ref. No. 1-10.

P543 Single Upstream Valve Asm. (No Vacuum) - Consists of 8-10 & 14-27.


P548 Double Upstream Valve Asm. (No Vacuum) - Consists of 8-10 & 14-27.

P544 Double Upstream Valve Asm. (With Vacuum) - Consists of 1-11, 14-16, & 18-27.

P546 Single Upstream Valve Asm. (With Vacuum) - Consists of 1-11, 14-16, & 18-27.


Ref.	Part		Ref.	Part	
<u>No.</u>	<u>No.</u>	Description	No.	No.	<u>Description</u>
1	P301	Rubber Tubing w/Spring	14	K361	Single Valve Body NPT w/Union
2	P226	Valve Seat		K362	Double Valve Body NPT w/Union
3	P246	Valve Seal w/Stem	15	P236	Copper Gasket (Pkg. of 6)
4	P244	Spring (Pkg 6)	16	P536	Packing Body Asm.
5	P223	Valve Body	17	P372	Support Bracket
6	P252	Hose Adapter			• •
7	P232	Rubber Tubing			
8	OP547	3/4" - 16 x 1/4" Lock Nut	* 20	P695	"O" Ring
9	V15	Small Lock Nut (Pkg. of 6)	21	V05	Large Pack Nut
10	P237	Pivot	22	P33H	Spring Retainer
11	P371	Support Bracket	23	P126	1/4" - 20 x 1" Aln St Scr. (Pkg. of 6)
12	**P254	Pedal Rod	24	V345	Spring (Pkg. of 6)
13	**SF49	Yoke Assembly	25	P375	Spring Holder
			* 26	P238	Valve Stem
**Inci	luded in the P255	assembly and is used on all valves			
		•	28	K605	Valve Repair Kit

^{*}Included in the K605 Repair Kit



STEAM VACUUM VALVE - P140


Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>
1	P86	Bonnet
2	P103	Large Copper Gasket (Pkg. of 6)
3	V330	Spring (Pkg. of 6)
4	P88	Disc. Holder
5	P99	Disc
6	P104	Flat Washer (Pkg. of 6)
7	V15	Lock Nut (Pkg. of 6)
8	P89	Short Stem
9	P542	2/3 of 3/4" Union NPT
10	P102	3/4" Black Pipe Cap (2 Req'd)
11	P87	Valve Body
12	P93	Orifice
13	P269	Hose Adapter
14	P115	(3/4" x 3/4" x 3/8") Black Tee
15	SF15	Fork
16	V13N	Large Split Pack Ring (Set of 3)
17	P144	Long Stem
18	OP547	Large Lock Nut
19	V12	Gland
20	V05	Large Pack Nut
21	VSB128	Roll Pin (Pkg. of 6)
22	FB15	Lever
<u>NOT IL</u>	LUSTRATED	
23	SF49	Yoke Assembly
24	PV138	Pedal Rod 19 3/8"
25	PV134	Pedal Rod & Yoke Assembly



(see next page for Head & Valve Assemblies)
WHEN ORDERING SPECIFY POLISHED OR SANDED HEAD FINISH

Ref. No.	Part No.			Description
	Regular	Vacuum	Nomex Cover	
	(Sanded)	(Sanded)	& Flannel Pad	
1	PS209	PVS209	P146N	No. 4C (22") Sleever Head
2	PS208	PVS208	P78N	No. 4X (22") Sleever Head
3	PS207	PVS207	P77N	No. 4 (14") Sleever Head
4	PS203	PVS203	P74N	No. 1L Ladies Shoulder
				Head
5	PS206	PVS206	P75N	No. 2 Mushroom Head
6	PS204	PVS204	P112N	No. 1E Men's Shoulder Head
7	PS205	PVS205	P83N	No. 1M Men's Shoulder
				Head
8	P202		P76N	No. 3 Egg Head
9	P28			Seat (Typical for All Heads
			Except Egg)	
	PA28			Seat (For Egg Head Only)
10	P44			Copper Gasket
11			P145	8-Inch Nylon Hand Pad
				(Optional)
12	P37			Head Seat Wrench 5/16"


(Specify if polished heads are desired)




HEADS WITH UPSTEAM VALVE ASSEMBLIES

These assemblies include the head with valve and all other parts shown below. Furnished w/sanded heads. *Specify if polished heads are desired!*

	Single Valve Body		<u>Double V</u>	<u>alve Body</u>
Description	less vacuum	with vacuum	less vacuum	with vacuum
1L Ladies Shoulder	P592	PV592	P600	PV600
1E Men Shoulder	P593	PV593	P601	PV601
1M Men Shoulder	P594	PV594	P602	PV602
2 Mushroom	P595	PV595	P603	PV603
3 Egg	P591		P599	
4 Sleever	P596	PV596	P604	PV604
4X Sleever	P597	PV597	P605	PV605
4C Sleever	P598	PV598	P606	PV606






Page 16

When ordering fabric pressing head, please specify type:


PIF215	No. 1E Men's Shoulder Head or No. 1	L Ladie's Shoulder H	ead
PIF216	No. 2 Mushroom Head	PIF217	No. 1M Men's Shoulder Head
PIF218	No. 4 (14") Sleever Head	PIF219	No. 4X (22") Sleever Head
PIF220	No. 4c (22") Sleever Head		




FABRIC PRESSING HEAD PARTS - PIF224

Ref.	Part		Ref.	Part	
No.	No.	Description	No.	<u>No.</u>	Description
1	PIF163	Swinging Arm	16	C396	Crown Nut 1/4 - 20*
2	PIF162	Support Upright	17	TU2846	Lock Washer, 1/4"*
3	PIF161	Support Base	18	P219	Tr. Hd. Scw., 1/4 - 20 x 1/2"*
4	X54	Handle End	19	S20	#8 - 32 Crown Nut*
5	X56	Cork Handle	20	FB187	Split Lockwasher #10*
6	S9	Handle Bolt	21	TU4820	Cut Washer, #10*
7	PIF169	Support Holder	22	RC355	Hex Cap Scw., 1/4 - 28 x 1 1/2"*
8	PIF204	Stop	23	IB143	Hex Nut, 1/4 - 28*
9	PIF172	Delrin Bushing (Pkg. of 2)	24	TU2847	Cut Washer, 1/4"*
10	PIF164	Spacer	25	P302	Tr. Hd. Scw., 1/4 - 20 x 1"*
11	PIF167	Pivot Stud	26	J10	Eye Bolt
12	V12	Gland	27	VSB154	Wing Nut, #10 - 24
13	V345	Spring*	28	P163	Large Adapter, 4C or 4X
14	PIF202	Latch	29	P164	Small Adapter, 4 Sleever
15	PIF154	Extension Spring	30	TU4934	Hex Nut, 1/4 - 20*

^{*} Indicates a Package of 6



Ref. No.	Part <u>No.</u>	Description	Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>
1	PIF155	Fabric Head Support Arm	9	PIF160	Fabric Head Support Arm
2	PIF148	Fabric Head Ring w/Screen and Cloth (For No. 1E Men's or No. 1L Ladies Shoulder)	10	PIF153	Fabric Head Ring w/Screen and Cloth (For No. 4C (22") Sleever)
3	PIF157	Fabric Head Support Arm	11	PIF159	Fabric Head Support Arm
4	PIF152	Fabric Head Ring w/Screen and Cloth (For No. 1M Men's Shoulder)	12	PIF151	Fabric Head Ring w/Screen and Cloth (For No. 4X (22") Sleever)
5	PIF156	Fabric Head Support Arm	13	IB143	1/4" - 28 Hex. Hd. Nut
6	PIF149	Fabric Head Ring w/Screen			(Pkg. of 6)
		and Cloth (For No. 2	14	TU2846	1/4" Lock Washer (Pkg. of 6)
7	PIF158	Mushroom) Fabric Head Support Arm	15	FB190	1/4" - 20 x 2" Hex Head Screw (Pkg. of 6)
8	PIF150	Fabric Head Ring w/Screen and Cloth (For #4 (14")	16	P302	1/4" - 20 x 1" Truss Hd. Mach Screw
		Sleever)	17	TU4934	1/4" - 20 Hex Nut (Pkg. of 6)



Page 19

PUFF IRON

INSTRUCTIONS FOR REPLACING VALVE "O" RINGS

- 1. Shut steam off to Puff Iron, depress foot pedal to release steam pressure and allow machine to cool.
- 2. Remove cotter pin and pin to yoke. Remove pedal rod from pivot.
- 3. Use a 1/8" allen wrench to loosen set screw located in spring retainer. After spring tension is relaxed, remove spring holder.
- 4. Remove large pack nut.
- 5. Remove old "O" Rings and replace with new "O" Rings.
- 6. After installing new "O" Rings, reinstall large pack nut and tighten securely.
- 7. Make sure the upper seal of the stem engages and seats. Raise the spring retainer and spring into position. Install spring holder into its original position.
- 8. To set spring into position, a dimension of about 3/4" should be maintained. After 3/4" is established, tighten set screw securely.
- 9. Reinstall pivot, lock nut, pedal rod, pin, and cotter pin. Establish pedal clearance of 1-5/8" from the floor.
- 10. Open steam line, allow Puff Iron to heat up, and test for leaks.

REPLACEMENT OF SPRING

- 1. Shut off steam to Puff Iron, depress foor pedal to release steam pressure and allow machine to cool.
- 2. Remove cotter pin and pin from yoke. Remove pedal rod from pivot.
- 3. Remove pivot and small lock nut from the valve stem.
- 4. Using a 1/8" allen wrench, loosen set screw located in spring retainer. After spring tension is relaxed, remove spring holder.
- 5. After removing spring holder, old spring will slide down valve stem and new spring will slide into position.
- 6. Reinstall spring holder.
- 7. To set spring into position, a dimension of about 3/4" should be kept. After 3/4" is established, tighten set screw securely.
- 8. Reinstall pivot and small lock nut on valve stem as shown on opposite page.
- 9. Reinstall pedal rod, pin, and cotter key. Re-establish pedal clearance 1-5/8" from floor.
- 10. Open steam line, allow Puff Iron to heat up and test for leaks.

CAUTION: When working on Puff Iron Valve Heads...

- 1. Turn off Steam to Puff Irons.
- 2. Depress foot Pedal to release Steam pressure; then allow to cool.
- Remove "Padded Nylon Covers" from Unpolished Heads.

TO REPLACE VALVE SEAT IN PUFF IRON (Figure 1)...

(A) Insert 5/16" Allen Wrench (3) into hex opening in Seat. Hit wrench with hammer, (two or more very firm hits) to break corrosion bond between threads of Brass Seat and Aluminum Head. Unscrew Seat (1) counter-clockwise and remove with old Gasket (2).

NOTE: After removing old Gasket scrape and clean gasket seat in Aluminum Head with a small flat scraper before installing new Seat and new Gasket.

(B) Screw in new Seat using new Gasket and be sure that Stem enters opening in Seat as the Seat comes down over the needle. Tighten Seat securely with 5/16" Allen Wrench.

NOTE: It is necessary to loosen Stem to replace Valve Seat.

- (C) Turn on Main Steam Supply to Puff Iron and check for leaks.
- (D) After installing new Seat, file or gring extended part of Valve Seat to match contour of Head.NOTE: On Polished Heads use "Fine" emory cloth to remove sharp burrs and file marks, Polish if desired.

